



BULLETIN 254B

ADJUSTMENTS AND LUBRICATION

MODEL 28

TRANSMITTER DISTRIBUTOR  
LCXD

**TELETYPE<sup>®</sup>**  
CORPORATION  
SUBSIDIARY OF *Western Electric Company* INC.  
SKOKIE, ILLINOIS, U. S. A.

COPYRIGHT 1958 BY TELETYPE CORPORATION IN UNITED STATES. COPYRIGHT  
IN ALL COUNTRIES PARTICIPATING IN INTERNATIONAL CONVENTION AND PAN  
AMERICAN CONVENTIONS. ALL RIGHTS RESERVED INCLUDING RIGHTS OF TRANS-  
LATIONS INTO ALL LANGUAGES.

Printed in U.S.A




## LIST OF EFFECTIVE PAGES

MAY, 1962

(Supersedes Issue of May, 1958)

PAGE NUMBER	CHANGE IN EFFECT
A to D	Change 1
1-1 to 1-40	Change 1
1-40a to 1-40b	Change 1
1-41 to 1-48	Change 1
2-1 to 2-2	Change 1
3-1 to 3-12	Change 1

The above list indicates the effective pages as of the date of issue. Upon receipt of change pages, insert them numerically and discard any superseded pages.



TRANSMITTER DISTRIBUTOR-LCXD  
(PIVOTED AND FIXED HEAD, MULTI-CONTACT)

## CONTENTS

<u>Paragraph</u>	<u>Page</u>	<u>Paragraph</u>	<u>Page</u>
SECTION 1 - ADJUSTMENTS			
1. INTRODUCTION	1-1	Tape Out and Tape Lid Switch	1-29
2. GENERAL	1-1	Tape Out and Tape Lid Switch Bracket	1-30
3. ADJUSTMENTS AND SPRING TENSIONS	1-2	Tape Out Pin	1-32
ADJUSTMENTS		Tape Out Pin Spring Bracket	1-30
Cam Shaft Bearing Retainer	1-3	Tape Out Switch	1-32
Cam Sleeve End Play	1-3	Tape Out Switch Bracket	1-32
Check Pawl	1-25	Tape Retaining Lid Latch	1-26
Clutch Armature Air Gap	1-4	Tight Tape Arm	1-31
Clutch Shoe Lever	1-6	Tight Tape Switch	1-31
Clutch Trip Assembly Adjusting Plate	1-4	Tight Tape Switch Bracket	1-31
Clutch Trip Lever Upper Extension	1-6	Top Plate (Fixed Head)	1-16
Code Hole - Sensing Pin Alignment	1-39	Top Plate (Pivoted Head)	1-26
Contact Slide Lever	1-23	Transmitter Driving and Distributor Shaft Driven Gear Mesh	1-25
Control Lever Switch Bracket	1-34	Vertical Alignment of Pivoted Sensing Head and Punch	1-35
Cover Plate	1-17	SPRING TENSIONS	
Distributor Block Assembly	1-8	Armature Bail Spring	1-4
Distributor Cam Follower Guide	1-7	Auxiliary Lever Spring	1-19
Distributor Contact Gap	1-8	Cam Follower Lever Spring	1-7
Feed Lever Set Collar	1-9	Check Pawl Spring	1-25
Feed Pawl	1-15	Clutch Latch Lever Spring	1-5
Feed Pawl (Final)	1-25	Clutch Shoe Lever Spring	1-2
Feed Pawl (Preliminary)	1-25	Clutch Shoe Spring	1-2
Feed Wheel Detent	1-14	Clutch Trip Lever Spring	1-5
Horizontal Alignment of Pivoted Sensing Head and Punch	1-36	Contact Slide Lever Springs	1-10
Idler Gear Assembly	1-3	Control Lever Detent Spring	1-12
Last Character Contact Assembly (Enclosed)	1-40	Cover Plate Detent Spring	1-17
Last Character Contact Switch	1-38	Distributor Rocker Compression Springs	1-7
Last Character Switch Spring Leaf	1-28	Feed Lever Spring (Fixed Head)	1-9
Magnet Bracket	1-5	Feed Lever Spring (Pivoted Head)	1-9
Oil Reservoir	1-20	Feed Pawl Spring	1-15
Push Lever	1-19	Feed Ratchet Detent Spring	1-14
Sensing Head Pivot Screws	1-24	Last Character Contact Leaf Spring (Enclosed)	1-40
Sensing Pins (Pivoted and Fixed Heads)	1-18	Latch Lever Spring	1-21
Storing Switch Assembly Replacement	1-20	Latch Stripper Bail Spring	1-21
Storing Switch Contact	1-23	Push Lever Spring	1-21
Storing Switch Contacts	1-10	Pusher Stripper Bail Spring	1-19
Storing Switch Guides	1-10	Sensing Bail Springs	1-17
Tape Deflector	1-24	Sensing Pin Springs (Fixed Head)	1-22
Tape Deflector Bracket	1-24	Sensing Pin Springs (Pivoted Head)	1-22
Tape Depressor	1-27	Start-Stop Bail Yield Spring	1-34
Tape Depressor (Chadless Tape)	1-37	Storing Switch Contact Lever Extension Spring	1-10
Tape Depressor (Fully-Perforated Tape)	1-38	Tape Deflector Spring	1-28
Tape Guide	1-13	Tape Depressor Spring	1-28
Tape Guide Plate	1-13	Tape Lid Pin Spring	1-30
Tape Lid	1-11	Tape Lid Release Plunger Spring	1-12
Tape Lid Pin	1-30	Tape Lid Spring	1-12
Tape Out and Tape Lid Pin Downstop	1-30	Tape Out Bail Yield Spring	1-33
		Tape Out Extension Bail Spring	1-33
		Tape Out Pin Spring	1-33
		Tape Out (6th) Pin Spring	1-22
		Tight Tape Bail Yield Spring	1-31

## CONTENTS (Cont'd.)

<u>Paragraph</u>	<u>Page</u>	<u>Paragraph</u>	<u>Page</u>
4. DISTRIBUTOR AND TRANSMITTER CONTACT STROBING	1-40a	c. Tape Guide Plate Assembly (Fixed Reader)	2-1
a. Contact Strobing - Pivoted Head Transmitter Distributor	1-41	d. Cover Plate (Pivoted Reader)	2-1
(1) Distributor Contacts - Stop and #1 through #5 (368, 390, 428, 460, 600, and 635 OPM)	1-41	e. Idler Gear Assembly	2-1
(2) Distributor Auxiliary Contacts "A", "B", and "C"	1-43	f. Sensing Shaft Assembly (Pivoted Reader)	2-1
(3) Transmitter Contacts (Sensing) - #1 through #5	1-44	g. Distributor and Sensing Shaft Assembly (Pivoted and Fixed Reader)	2-1
(4) Transmitter Contacts - Auxiliary, Tape Out and Distributor Clutch Trip	1-46	h. Clutch Trip Assembly	2-1
b. Contact Strobing - Fixed Head Transmitter Distributor	1-47	i. Pivot Shaft	2-2
(1) Distributor Contacts - Stop and #1 through #5 (368, 460, and 600 OPM)	1-47	j. Pivoted Sensing Head (Pivoted Reader)	2-2
(2) Transmitter Contacts - (Sensing) - #1 through #5	1-47	k. Storing Switch Assembly	2-2
(3) Transmitter Contacts - Auxiliary and Distributor Clutch Trip	1-48	l. Distributor Block Assembly	2-2
SECTION 3 - LUBRICATION			
SECTION 2 - DISASSEMBLY AND REASSEMBLY		1. INTRODUCTION	3-1
1. GENERAL	2-1	2. GENERAL	3-1
2. DISASSEMBLY AND REASSEMBLY	2-1	3. LUBRICATION	3-2
a. Cover Plate Assembly (Fixed Reader)	2-1	3.01 Clutch Trip Assemblies	3-2
b. Top Plate Assembly (Fixed Reader)	2-1	3.02 Storing Switch Assembly	3-3
		3.03 Distributor Block Assembly	3-4
		3.04 Clutch Assemblies	3-4
		3.05 Cam Sleeve Assemblies	3-5
		3.06 Oil Reservoir Assembly	3-5
		3.07 Pivoted Sensing Head	3-6
		3.08 Check Pawl and Feed Wheel	3-7
		3.09 Pivoted Sensing Mechanism	3-7
		3.10 Fixed Sensing Mechanism	3-8
		3.11 Sensing Mechanisms	3-8
		3.12 Sensing Mechanism	3-9
		3.13 Feed Mechanism	3-9
		3.14 Feed Mechanism	3-10
		3.15 Tape Lid and Tape Guide	3-11
		3.16 Tight Tape Sensing Mechanism	3-11
		3.17 Tape-Out and Tape Lid Mechanism	3-12

## SECTION 1

## ADJUSTMENTS

## 1. INTRODUCTION

a. This bulletin presents maintenance information for the Teletype Model 28 LCXD Transmitter Distributor. It is divided into three sections covering, respectively, adjustments, disassembly and reassembly, and lubrication.

b. It is assumed that the mechanisms illustrated in this bulletin are being viewed from a position in front of the equipment, unless the illustrations are specifically labeled otherwise. In the line drawings, fixed pivot points are shown by solid black circles and moveable points are shown by cross-hatched circles. References in the text to LEFT or RIGHT, UP or DOWN, FRONT or REAR apply to the unit in its normal operating position with the pivoted head to the viewer's right.

## 2. GENERAL

a. Section 1 contains adjustment information common to all LCXD Transmitter Distributor units. Also included in this section is the strobing procedure to be followed for proper timing of the transmitter and distributor contacts.

b. In the adjustments and spring tensions covered in this section, location of clearance, position of parts, and point and angle of scale applications are illustrated by drawings. A complete adjusting procedure should be read before making the adjustment or checking the spring tension. The adjustments are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken.

c. The spring tensions given in this bulletin are indicated values and should be checked with Teletype scales in the positions shown in the drawings. Springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and re-

placed by new springs.

d. When rotating the drive shaft gear by hand, the rotation is counterclockwise as viewed from the exposed side of the drive shaft gear.

e. When the requirement calls for a clutch to be **DISENGAGED**, the clutch shoe lever must be fully latched between its trip lever and latch lever so that the clutch shoes release their tension on the clutch drum. When **ENGAGED**, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

## NOTE


When rotating either the sensing or distributor shaft by hand, the respective clutch may not fully disengage upon reaching its stop position. To disengage the clutch, rotate the clutch to its stop position, apply a screwdriver to the cam disk stop lug, and move the disk in the normal direction of shaft rotation until the latch lever seats in its notch in the disk.

f. Tools required to make adjustments and check spring tensions are not supplied with the equipment, but are listed in Teletype Bulletin 1124B. If parts are removed, all adjustments which the removal of parts might facilitate should be made before the parts are replaced. When a part mounted on shims is removed, the number of shims at each mounting screw should be noted so that the identical shim pile-up can be made when the part is remounted. Unless stated otherwise, all nuts and screws that were loosened should be tightened after an adjustment has been made.

g. The covers may be removed for inspection and minor repair of the unit. However, when more extensive maintenance is to be undertaken, it is recommended that the unit be removed from its sub-base to disconnect the power and to permit the unit to be inverted.

3. ADJUSTMENTS AND SPRING TENSIONS


**NOTE:** REQUIREMENTS A AND B ARE ADJUSTED AT THE FACTORY AND SHOULD NOT BE DISTURBED UNLESS ASSOCIATED MECHANISMS HAVE BEEN REMOVED FOR SERVICING OR THERE IS REASON TO BELIEVE THAT THE REQUIREMENTS ARE NOT MET. THE FOLLOWING REQUIREMENTS APPLY TO BOTH THE SENSING CLUTCH AND DISTRIBUTOR CLUTCH.



(A) CLUTCH SHOE LEVER SPRING

**REQUIREMENT**

CLUTCH ENGAGED AND CAM DISK HELD TO PREVENT TURNING. SCALE PULLED AT TANGENT TO CLUTCH. MIN. 15 OZS. MAX. 20 OZS. TO MOVE CLUTCH SHOE LEVER IN CONTACT WITH STOP LUG.



(B) CLUTCH SHOE SPRING

**NOTE:** IT IS NECESSARY TO REMOVE THE CLUTCH FROM THE MAIN SHAFT TO FACILITATE THIS CHECK.


**REQUIREMENT**

CLUTCH DRUM REMOVED. SCALE APPLIED TO PRIMARY SHOE AT A TANGENT TO THE FRICTION SURFACE. MIN. 3 OZS. MAX. 5 OZS. TO START PRIMARY SHOE MOVING AWAY FROM SECONDARY SHOE AT POINT OF CONTACT.

FIGURE 1-1. CLUTCH MECHANISM



NOTE  
THE FOLLOWING REQUIREMENTS APPLY TO BOTH THE DISTRIBUTOR AND SENSING CAM SLEEVES. THESE MECHANISMS SHOULD NOT BE DISTRIBUTED UNLESS ABSOLUTELY NECESSARY.




NOTE  
ADJUSTMENT TO BE MADE PRIOR TO ASSEMBLY OF DRIVE GEAR TO CLUTCH DRUM.  
REQUIREMENT  
MIN. SOME  
MAX. 0.010 INCH  
PLAY BETWEEN CAM SLEEVES AND SPACERS  
TO ADJUST  
REMOVE CLUTCH DRUM DRIVE GEAR AND LOOSEN DRUM MOUNTING SCREW. RELEASE CLUTCH AND POSITION CAM SLEEVE. TIGHTEN DRUM MOUNTING SCREW AND REINSTALL DRIVE GEAR.

(C) IDLER GEAR ASSEMBLY

REQUIREMENT  
CLEARANCE BETWEEN IDLER GEAR AND SENSING SHAFT GEAR, AND BETWEEN IDLER GEAR AND DISTRIBUTOR SHAFT GEAR AT POINT WHERE BACKLASH IS MINIMUM:  
MIN. SOME  
MAX. 0.003 INCH  
TO ADJUST  
POSITION IDLER GEAR ASSEMBLY WITH LOCK NUT LOOSENED. RECHECK GEAR PLAY THROUGH ONE REVOLUTION OF GEARS.

(B) CAM SHAFT BEARING RETAINER





REQUIREMENT  
WHEN MOUNTING SHAFT ASSEMBLY, BEARING SHALL SEAT PROPERLY. (NO CLEARANCE PERMISSIBLE BETWEEN BEARING AND MOUNTING SURFACE.)  
TO ADJUST  
ROTATE BEARING RETAINER 180 DEGREES AND POSITION BY PUSHING DOWNWARD FIRMLY.

FIGURE 1-2. CAM SHAFTS

NOTE: REQUIREMENTS APPLY TO BOTH CLUTCH TRIP MECHANISMS.


(A) CLUTCH ARMATURE AIR GAP  
 REQUIREMENT  
 AIR GAP BETWEEN ARMATURE AND MAGNET  
 ASSEMBLY BRACKET WITH ARMATURE FLUSH  
 AGAINST MAGNET CORE.  
 MIN. 0.004 INCH  
 MAX. 0.008 INCH  
 TO ADJUST  
 REMOVE ARMATURE EXTENSION SPRING.  
 POSITION HINGE WITH SPRING POST AND  
 HINGE MOUNTING SCREW LOOSENED.  
 RECHECK AIR GAP AND REPLACE SPRING.



(B) CLUTCH TRIP ASSEMBLY MOUNTING PLATE

REQUIREMENT  
 CLEARANCE BETWEEN END OF  
 ARMATURE BAIL AND LATCHING  
 SURFACE OF CLUTCH  
 TRIP LEVER LOWER EXTENSION  
 WITH CLUTCH TRIP  
 LEVER RESET EXTENSION ON  
 HIGH PART OF CAM. (TAKE-  
 UP PLAY IN PARTS FOR MIN-  
 IMUM CLEARANCE.)  
 MIN. 0.020 INCH  
 MAX. 0.030 INCH

TO ADJUST  
 POSITION PLATE WITH  
 SCREWDRIVER IN LOWER  
 ADJUSTING SLOT WITH  
 PLATE ADJUSTING SCREW  
 AND PLATE MOUNTING  
 SCREW LOOSENED. (TAKE-  
 UP PLAY IN TRIP LEVER IN  
 DIRECTION OF CAM.)



(C) ARMATURE BAIL SPRING

REQUIREMENT  
 INVERT UNIT. TRIP CLUTCH MAGNET AND  
 ROTATE SHAFT MANUALLY UNTIL TRIP LEVER  
 RESET EXTENSION IS ON HIGH PART OF ITS  
 CAM.  
 MIN. 3 OZS.  
 MAX. 4-1/2 OZS.  
 TO START ARMATURE BAIL MOVING.

FIGURE 1-3. CLUTCH TRIP MECHANISM

NOTE  
REFER TO REQUIREMENTS ON PAGE 1-4




FIGURE 1-4. CLUTCH TRIP MECHANISM

NOTE  
REQUIREMENTS (A) AND (B) APPLY TO ALL CLUTCHES




FIGURE 1-5. CLUTCH MECHANISM

NOTE  
REMOVE OIL RESERVOIR AND DISTRIBUTOR BLOCK ASSEMBLY FOR FOLLOWING ADJUSTMENTS.







FIGURE 1-6. DISTRIBUTOR CONTACT MECHANISM

NOTE  
REPLACE DISTRIBUTOR BLOCK



NOTE  
FOR REFINEMENT OF DISTRIBUTOR CONTACT ADJUSTMENTS, REFER TO PARA-  
GRAPH 4, DISTRIBUTOR AND TRANSMITTER CONTACT STROBING.

FIGURE 1-7. DISTRIBUTOR CONTACT MECHANISM





FIGURE 1-8. FEED LEVER MECHANISM




(A) STORING SWITCH CONTACTS

TO CHECK  
 REMOVE STORING SWITCH ASSEMBLY.  
 REQUIREMENT  
 CONTACT LEVER EXTENSIONS SHOULD  
 BE PERPENDICULAR TO STORING BLOCK.  
 TO ADJUST  
 TURN EACH CONTACT SCREW WITH  
 ALLEN WRENCH. GAUGE BY EYE.

(B) STORING SWITCH CONTACT LEVER  
 EXTENSION SPRING

- (1) REQUIREMENT  
 MIN. 1-3/4 OZS.  
 MAX. 3-1/2 OZS.  
 TO START EACH CONTACT LEVER  
 EXTENSION MOVING.
- (2) REQUIREMENT  
 MIN. 1/2 OZ.  
 MAX. 1 OZ.  
 TO START TAPE-OUT (6TH) CON-  
 TACT LEVER EXTENSION MOVING.



(C) STORING SWITCH GUIDES

PRELIMINARY - BEFORE SWITCH ASSEMBLY IS SECURED  
 TO UNIT, ROTATE SLIDE ECCENTRIC TO MAKE CLEAR-  
 ANCE BETWEEN SLIDE STOP POST AND END CONTACT  
 LEVER SLIDES MINIMUM.

- (1) REQUIREMENT  
 MIN. 0.005 INCH  
 MAX. 0.012 INCH  
 CLEARANCE BETWEEN END SLIDES AND STOP  
 POST. (HOLD SLIDES AWAY FROM STOP POST).

NOTE

AFTER CONTACT LEVER SLIDE ADJUSTMENT  
 (FIGURE 1-22), CLEARANCE MAY BE 0.005 TO  
 0.015 INCH.

- (2) REQUIREMENT  
 CONTACT LEVER SLIDES FREE IN GUIDE  
 SLOTS AND PARALLEL TO SIDE PLATES (GAUGE BY  
 EYE).  
 TO ADJUST  
 POSITION GUIDE WITH ITS MOUNTING SCREWS  
 LOOSENED.

(D) CONTACT SLIDE LEVER SPRINGS

TO CHECK  
 SELECT BLANK COMBINATION, TRIP SENSING CLUTCH AND ROTATE  
 SHAFT TO STOP POSITION. HOLD EXTENSION LEVERS AWAY.

- (1) REQUIREMENT  
 MIN. 4 OZS.  
 MAX. 6 OZS.  
 TO START EACH SLIDE LEVER SPRING MOVING.
- (2) REQUIREMENT  
 MIN. 1-1/2 OZS.  
 MAX. 3 OZS.  
 TO START TAPE-OUT (6TH) SLIDE LEVER SPRING MOVING.

FIGURE 1-9. STORING SWITCH MECHANISM




TAPE LID

## NOTE

REMOVE TOP AND TAPE GUIDE PLATES. LUBRICATE MATING SURFACES PRIOR TO ADJUSTMENT.

- (1) REQUIREMENT  
 MIN. SOME  
 MAX. 0.010 INCH  
 CLEARANCE BETWEEN PIVOT SHOULDER AND TAPE LID WHEN LID IS PRESSED AGAINST NOTCH IN TAPE GUIDE PLATE, AND FEED WHEEL SLOTS AND TAPE-OUT PIN HOLES ARE LINED UP.  
 TO ADJUST  
 LOOSEN TAPE LID BRACKET MOUNTING NUTS. USING A 156743 GAUGE, LINE UP FEED WHEEL GROOVE IN TAPE LID WITH SLOT IN TAPE GUIDE PLATE. POSITION TAPE LID BRACKET TO MEET REQUIREMENT.

- (2) REQUIREMENT - (SEE FIGURE 1-11).



- (3) REQUIREMENT  
 SOME END PLAY IN RELEASE PLUNGER WHEN LID IS LATCHED AGAINST TAPE GUIDE PLATE  
 TO ADJUST  
 WITH ECCENTRIC MOUNTING POST NUT FRICTION TIGHT AND TAPE LID RAISED, ROTATE HIGH PART OF ECCENTRIC POST TOWARDS MOUNTING BRACKET. CLOSE TAPE LID. ROTATE ECCENTRIC COUNTERCLOCKWISE (AS VIEWED FROM SLOTTED END OF ECCENTRIC POST) UNTIL FLAT OF LATCH POST FULLY ENGAGES LATCH BAIL FLAT. ROTATE ECCENTRIC CLOCKWISE TO TAKE UP ALL PLAY IN PARTS, AND TO SEAT OPEN END OF TAPE LID AGAINST TAPE GUIDE PLATE.  
 TO CHECK  
 WITH TAPE LID HELD DOWN MANUALLY, LATCH TIP SHOULD CLEAR LATCH POST WHEN RELEASE BUTTON IS OPERATED. WITH TAPE LID LATCHED, TIP OF LATCH SHOULD PROJECT BEYOND FLAT OF LATCH POST, AND THERE SHOULD BE SOME END PLAY IN RELEASE BUTTON.

FIGURE 1-10. TAPE LID MECHANISM

(2) REQUIREMENT

WITH TAPE LID FRONT BEARING SURFACE TOUCHING TAPE GUIDE PLATE, CLEARANCE BETWEEN TAPE LID AND TAPE GUIDE PLATE:

MIN. 0.010 INCH

MAX. 0.018 INCH


MEASURED AT TAPE LID FIN IN LINE WITH REAR TAPE GUIDE. 2ND. FIN FROM REAR  
NOTE

WHEN BOTH TOP AND TAPE GUIDE PLATES ARE ASSEMBLED ON UNIT, LEFT EDGE OF LID MAY TOUCH TOP PLATE AND SOME CHANGE IN THIS CLEARANCE MAY BE EXPECTED.

TO ADJUST

WITH TAPE LID BEARING BRACKET MOUNTING SCREWS FRICTION TIGHT, AND TAPE LID PRESSED AGAINST TAPE GUIDE PLATE, POSITION BEARING BRACKET. RECHECK REQUIREMENT (1).

(1) AND (3) REQUIREMENTS - (SEE FIGURE 1-10).



TAPE LID SPRING  
TO CHECK

OPEN TAPE LID. HOLD UNIT SO TAPE GUIDE PLATE IS HORIZONTAL. APPLY SCALE AT TOP OF LID IMMEDIATELY LEFT OF TAPE-OUT PIN HOLE. HOLD PLUNGER FULLY DEPRESSED.

REQUIREMENT

MIN. 3 OZS.

MAX. 4-1/2 OZS.

TO MOVE OPEN END OF TAPE LID AGAINST TAPE GUIDE PLATE.



CONTROL LEVER DETENT SPRING  
TO CHECK

PLACE CONTROL LEVER IN RUN POSITION.

REQUIREMENT

MIN. 14 OZS.

MAX. 22 OZS.

TO START DETENT BAIL MOVING AWAY FROM CONTROL LEVER DETENT.



( VIEWED FROM REAR )

TAPE LID RELEASE PLUNGER SPRING  
TO CHECK

HOLD TAPE GUIDE PLATE SO TOP SURFACE IS HORIZONTAL. OPEN TAPE LID.


REQUIREMENT

MIN. 28 OZS.

MAX. 48 OZS.

TO START TAPE LID BAIL MOVING.

FIGURE 1-11. TAPE LID MECHANISM



**TAPE GUIDE REQUIREMENT**  
 WITH GAUGE PROPERLY POSITIONED:  
 MIN. SOME  
 MAX. 0.003 INCH  
 BETWEEN GAUGE AND TAPE GUIDES  
 TO ADJUST  
 LOOSEN TAPE GUIDE MOUNTING NUTS TO FRICTION TIGHT. PROPERLY POSITION GAUGE ON TAPE GUIDE PLATE. POSITION TAPE GUIDES TO MEET REQUIREMENT.

TAPE GUIDE PLATE





FIGURE 1-12. TAPE GUIDE PLATE

SKIP

254B



(A) FEED WHEEL DETENT

NOTE

IF UNIT IS EQUIPPED WITH A CONTROL LEVER, PLACE IT IN STOP POSITION

TO CHECK

PLACE A "LETTERS" PERFORATED TAPE OVER FEED WHEEL, TAKING UP PLAY IN FEED HOLES TOWARD THE RIGHT.

REQUIREMENT


SENSING PINS SHOULD BE CENTRALLY LOCATED IN CODE HOLES.

TO ADJUST

POSITION FEED WHEEL DETENT ECCENTRIC WITH ITS LOCK SCREW FRICTION TIGHT. HIGH PART OF ECCENTRIC SHOULD BE TOWARD RIGHT. HOLD ECCENTRIC AND TIGHTEN GUIDE POST AND LOCK SCREW. RECHECK ADJUSTMENT.

NOTE

FEED PAWL SHOULD BE HELD AWAY TO FACILITATE ADJUSTMENT.



(B) FEED RATCHET DETENT SPRING

REQUIREMENT

WITH FEED PAWL HELD AWAY FROM RATCHET WHEEL:

MIN. 7 OZS.

MAX. 13 OZS.

TO MOVE DETENT ROLLER AWAY FROM FULLY DETENTED POSITION.


*use screw driver  
not feed adj.*

FIGURE 1-13. TAPE FEED MECHANISM

SKIP

254B

(B) FEED PAWL SPRING  
 TO CHECK  
 REMOVE TOP PLATE. DISENGAGE CLUTCH.  
 REQUIREMENT  
 MIN. 1/4 OZ.  
 MAX. 1-1/2 OZS.  
 TO START FEED PAWL MOVING.



(A) FEED PAWL

NOTE

IF UNIT IS EQUIPPED WITH A CONTROL LEVER, PLACE IT IN RUN POSITION.

TO CHECK

REMOVE TOP PLATE. TRIP CLUTCH, AND ROTATE CAM SHAFT UNTIL FEED ROLLER IS ON HIGH PART OF CAM. ROTATE RATCHET WHEEL UNTIL OIL HOLE IS UP. TAKE UP PLAY BY PRESSING DOWN LIGHTLY ON RIGHT END OF FEED PAWL BAIL.

REQUIREMENT

MIN. SOME  
 MAX. 0.003 INCH  
 CLEARANCE BETWEEN FEED PAWL AND RATCHET TOOTH.

TO ADJUST

POSITION FEED LEVER BY MEANS OF THE ADJUSTING SLOT WITH ITS LOCK NUT LOOSENED.

FIGURE 1-14. TAPE FEED MECHANISM

TOP PLATE (FIXED HEAD)

## (1) REQUIREMENT

TOP PLATE FLUSH TO 0.003 INCH UNDER FLUSH WITH TAPE GUIDE PLATE WITHIN WIDTH OF TAPE LID.

## TO ADJUST


LOOSEN MOUNTING BRACKET NUTS UNTIL BRACKETS ARE FRICTION TIGHT. PRESS TOP PLATE INTO POSITION. TOP PLATE SHOULD REST ON AT LEAST THREE PROJECTIONS OF SIDE PLATES. MAKE SURE THE TIGHT-TAPE ARM EXTENSION IS UNDER THE TOP PLATE.

## (2) REQUIREMENT

FEED WHEEL SLOT AND TAPE GUIDE PLATE SLOT SHOULD LINE UP

## TO ADJUST

MOVE TOP PLATE TO LINE UP FEED WHEEL SLOT. DO NOT DISTURB REQUIREMENT (2) OF TAPE GUIDE PLATE ADJUSTMENT (SEE FIGURE 1-12).



## (3) REQUIREMENT

WITH TAPE LID LATCHED, CLEARANCE BETWEEN TAPE LID EXTENSION COVERING FEED WHEEL SLOT, AND TOP PLATE:

MIN. 0.010 INCH

MAX. 0.020 INCH

MEASURED AT CURVED PORTION OF TOP PLATE, AND

MIN. 0.010 INCH

MAX. 0.025 INCH

MEASURED AT FLAT PORTION OF TOP PLATE.

ALSO:

MIN. 0.010 INCH


MAX. 0.018 INCH

CLEARANCE BETWEEN TAPE LID AND TAPE GUIDE PLATE MEASURED IN AREA BETWEEN TAPE GUIDES (PLAY IN TAPE LID TAKEN TOWARD TAPE GUIDE PLATE).

## TO ADJUST

LOOSEN TWO SCREWS HOLDING TAPE LID MOUNTING BRACKETS TOGETHER, AND POSITION TAPE LID. RECHECK ADJUSTMENTS (1) AND (2) OF TAPE LID ADJUSTMENT (SEE FIGURE 1-10).


FIGURE 1-15. TOP PLATE ASSEMBLY



COVER PLATE DETENT SPRING  
TO CHECK  
REMOVE COVER PLATE.  
REQUIREMENT  
MIN. 28 OZS.  
MAX. 48 OZS.  
TO START PLUNGER MOVING

COVER PLATE

- (1) REQUIREMENT  
COVER PLATE HELD FLUSH AGAINST TOP PLATE BY DETENT ACTION.
- (2) REQUIREMENT  
COVER PLATE RESTS ON AT LEAST THREE SIDE FRAME PROJECTIONS.
- (3) REQUIREMENT  
FRONT EDGE OF COVER AND TOP PLATES IN LINE.  
TO ADJUST  
LOOSEN DETENT NUTS ON SIDE FRAMES AND MOVE THEM TO EXTREME LOWER RIGHT POSITION. TIGHTEN NUTS. LOOSEN FOUR BRACKET MOUNTING NUTS ON COVER PLATE. PLACE COVER INTO POSITION, AND POSITION TO MEET REQUIREMENTS. TIGHTEN NUTS. IF COVER PLATE DOES NOT DETENT PROPERLY (REQUIREMENT (1)), REPOSITION DETENT NUTS.



SENSING BAIL SPRINGS

TO CHECK  
WITH BLANK TAPE UNDER TAPE LID, TRIP CLUTCH MAGNET AND MANUALLY ROTATE SHAFT UNTIL SENSING BAIL IS IN UPPER-MOST POSITION. APPLY SCALE TO BAIL BETWEEN SPRINGS.  
REQUIREMENT  
MIN. 1/4 OZ.  
MAX. 2 OZ.  
TO START SENSING BAIL MOVING.

FIGURE 1-16. SENSING MECHANISM

36  
5/11/60  
1-17  
10




FIGURE 1-17. SENSING MECHANISM







FIGURE 1-18. SENSING MECHANISM

NOTE: REINSTALL STORING SWITCH ASSEMBLY.



(A) STORING SWITCH ASSEMBLY REPLACEMENT

REQUIREMENT


STORING SWITCH ASSEMBLY SHOULD ALIGN WITH LATCH LEVERS SO THAT LATCH LEVERS AND SLIDES FUNCTION WITHOUT BINDING.

TO CHECK

MANUALLY PUSH LATCH BAIL FOLLOWER AWAY FROM CAM UNTIL LATCHES ARE FREE FROM GUIDE. RELEASE LATCH BAIL FOLLOWER AND NOTE IF LATCHES FALL INTO THEIR RESPECTIVE SLOTS.

TO ADJUST

PIVOT STORING SWITCH WITH STORING SWITCH MOUNTING SCREWS LOOSENED. RECHECK REQUIREMENT.



(B) OIL RESERVOIR

*Removed*

REQUIREMENT

EACH OIL WICK RESTS LIGHTLY ON HIGH PARTS OF FRONT AND REAR CAM OF EACH CAM SLEEVE.

TO ADJUST

TRIP BOTH ARMATURES AND ROTATE SHAFT UNTIL HIGH PART OF FRONT AND REAR CAM OF EACH SLEEVE IS UNDER ITS WICK. POSITION OIL RESERVOIR ASSEMBLY WITH ITS MOUNTING SCREWS (2) LOOSENED. WHEN CAM SLEEVE IS ROTATED, TEETH OF WICK RETAINER SHOULD NOT DEFLECT UPWARD MORE THAN 1/32 INCH (GAUGE BY EYE). REFINE ADJUSTMENT BY SLIGHTLY BENDING TEETH ON WICK COMB SPRING.

FIGURE 1-19. STORING SWITCH MECHANISM




FIGURE 1-20. SENSING MECHANISM

(C) TAPE-OUT (6TH) PIN SPRING

TO CHECK

SENSING HEAD IN LOCKED POSITION, AND TAPE-OUT PIN IN UPPERMOST POSITION. APPLY SCALE IN LINE WITH PIN.

REQUIREMENT

MIN. 1 OZ.  
MAX. 2 OZS.

TO MOVE SENSING PIN FLUSH WITH TOP GUIDE PLATE.

NOTE

WHEN CHECKING THIS SPRING ALLOW THE PUSH LEVER TO REMAIN UNDER THE TRANSFER LEVER.

(B) SENSING PIN SPRINGS (PIVOTED HEAD)

TO CHECK

WITH SENSING HEAD IN LOCKED POSITION, TRIP SENSING CLUTCH AND ROTATE SENSING SHAFT UNTIL SENSING PINS ARE IN UPPERMOST POSITION. WHILE HOLDING PUSH LEVERS AWAY FROM TRANSFER LEVER, APPLY SCALE IN LINE WITH PIN.

REQUIREMENT

MIN. 3 OZS.  
MAX. 4 OZS.

TO MOVE SENSING PINS FLUSH WITH TOP GUIDE PLATE.





FIGURE I-21. SENSING MECHANISM



NOTE  
 THE ABOVE REQUIREMENTS ARE FINAL EXCEPT IN LOCATIONS WHERE A DXD OR LSS TEST SET IS AVAILABLE. SEE PARAGRAPH 4. FOR STROB INFORMATION.

FIGURE 1-22. STORING SWITCH MECHANISM





FIGURE I-23. PIVOTED SENSING HEAD


(A) FEED PAWL (PRELIMINARY)

**REQUIREMENT**  
 FEED LEVER FOLLOWER ROLLER SHALL BE OFF CAM WHEN FEED PAWL RESTS AGAINST ITS UPWARD STOP.  
**TO ADJUST**  
 TRIP CLUTCH AND ROTATE SHAFT UNTIL FEED PAWL IS IN ITS UPPER POSITION AND BOTTOMED ON ITS STOP. POSITION ROLLER WITH LOCK NUT LOOSENED.



(D) CHECK PAWL SPRING

**REQUIREMENT**  
 WITH SENSING CLUTCH IN STOP POSITION.  
 MIN. 4-1/2 OZS.  
 MAX. 8-1/2 OZS.  
 TO START CHECK PAWL MOVING.



(B) CHECK PAWL

- (1) **REQUIREMENT**  
 CHECK PAWL SHALL ENGAGE BOTH TEETH ON RATCHET WITH FEED PAWL IN ITS UP POSITION.  
**TO ADJUST**  
 ROTATE CHECK PAWL ECCENTRIC STUD.  
 NOTE: GROOVE ON ECCENTRIC STUD (HIGH PART OF ECCENTRIC) MUST BE ON LEFT SIDE DURING ADJUSTMENT.
- (2) **REQUIREMENT**  
 FEED WHEEL SHALL NOT MOVE WITH SENSING CLUTCH IN STOP POSITION (FEED PAWL DOWN FULLY).  
 NOTE: CHECK REQUIREMENT AROUND ENTIRE PERIPHERY OF RATCHET.  
**TO ADJUST**

REFINE REQUIREMENT NO. 1  
 NOTE: USE SLIGHT PRESSURE ON FEED WHEEL TO PREVENT FALSE INDICATION DUE TO OVER-RIDING CHECK PAWL SPRING.

(C) FEED PAWL (FINAL)

**REQUIREMENT**  
 CLEARANCE BETWEEN FEED PAWL AND FEED RATCHET TOOTH WITH CLUTCH IN STOP POSITION.  
 MIN. 0.030 INCH  
 MAX. 0.035 INCH  
**TO ADJUST**

REFINE FEED PAWL PRELIMINARY ADJUSTMENT (A).

FIGURE 1-24. PIVOTED SENSING HEAD




FIGURE 1-25. PIVOTED SENSING HEAD







FIGURE 1-26. TAPE DEPRESSOR



*OKP*

LAST CHARACTER SWITCH SPRING LEAF

REQUIREMENT  
MIN. 1/4 OZ.  
MAX. 1/2 OZ.  
TO JUST OPEN CONTACTS  
TO ADJUST  
WITH COVER REMOVED, BEND LONG CONTACT SPRING.





FIGURE 1-27. TAPE DEPRESSOR AND LAST CHARACTER CONTACT

TAPE-OUT AND TAPE LID SWITCH

## NOTE

MAKE THIS ADJUSTMENT BEFORE ASSEMBLING SWITCH TO UNIT.

- (1) REQUIREMENT  
 MIN. 8 GRAMS  
 MAX. 15 GRAMS  
 TO JUST SEPARATE NORMALLY CLOSED CONTACTS (APPLY SCALE TO CENTER OF NYLON PAD).  
 TO ADJUST  
 BEND CONTACT SWINGER WITH A 110445 SPRING BENDER.
- (2) REQUIREMENT  
 MIN. 0.008 INCH  
 MAX. 0.015 INCH  
 GAP BETWEEN NORMALLY OPEN CONTACTS.  
 TO ADJUST  
 BEND UPPER CONTACT LEAF WITH A 110445 SPRING BENDER.

TO REMOVE TAPE-OUT AND TAPE LID SWITCH ASSEMBLY

- (1) REMOVE COVER AND TOP PLATES.
- (2) REMOVE 111342 SPRING ATTACHED TO BRACKET ON 158535 GUIDE POST.
- (3) LOOSEN SCREW SECURING GUIDE POST TO REAR PLATE.
- (4) REMOVE SCREW AND LOCK WASHER FROM FRONT END OF GUIDE POST.
- (5) REMOVE ADJUSTING SCREW FROM LOWER END OF SWITCH BRACKET.
- (6) GUIDE POST AND SWITCH ASSEMBLY CAN NOW BE REMOVED. TAKE CARE NOT TO DISTORT SWITCH LEAF SPRINGS

TO REPLACE SWITCH ASSEMBLY

REVERSE DISASSEMBLY PROCEDURE.

## NOTE

ADJUSTMENTS ON THIS PAGE AND PAGE 1-30 ARE FOR UNITS WITHOUT A CONTROL LEVER. FOR UNITS WITH A CONTROL LEVER, REFER TO PAGES 1-32 AND 1-33.

FIGURE 1-28. TAPE-OUT AND TAPE LID SWITCH.

**(B) TAPE-OUT PIN SPRING BRACKET**

REQUIREMENT

MIN. 38 GRAMS

MAX. 45 GRAMS

TO DEPRESS TAPE-OUT PIN UNTIL FLUSH WITH TAPE GUIDE PLATE.

TO ADJUST

POSITION TAPE-OUT PIN SPRING BRACKET WITH ITS MOUNTING SCREWS FRICTION TIGHT. TIGHTEN SCREWS AND RECHECK REQUIREMENT.

**(A) TAPE-OUT AND TAPE LID SWITCH BRACKET**

REQUIREMENT

MIN. 0.006 INCH

MAX. 0.020 INCH

CLEARANCE BETWEEN TAPE-OUT PIN EXTENSION AND CONTACT SWINGER INSULATOR WHEN TAPE-OUT PIN IS HELD DOWN.

TO ADJUST

INSERT A LENGTH OF UN-PERFORATED TAPE UNDER TAPE LID. ADJUST SWITCH BRACKET WITH ITS MOUNTING SCREW LOOSENED.

**(C) TAPE-OUT AND TAPE LID PIN DOWNSTOP**

REQUIREMENT

WHEN DEPRESSED TO THEIR LOWERMOST POSITIONS, TAPE-OUT AND TAPE LID PINS SHOULD BE FLUSH TO 0.005 INCH BELOW SURFACE OF TAPE GUIDE PLATE.

TO ADJUST

POSITION RESPECTIVE DOWNSTOP POST WITH ITS MOUNTING NUT LOOSENED.

**(D) TAPE LID PIN SPRING**

REQUIREMENT

MIN. 1-1/2 OZS.

MAX. 3 OZS.

TO MOVE TAPE LID PIN FLUSH WITH TOP SURFACE OF TOP PLATE.

**(E) TAPE LID PIN**

TO CHECK

REMOVE COVER PLATE

(2) REQUIREMENT

WITH TAPE LID OPEN, AND NORMALLY OPEN CONTACTS CLOSED BY TAPE LID PIN:

MIN. 0.010 INCH

CLEARANCE BETWEEN SHOULDER ON PIN AND BOTTOM SURFACE OF TAPE GUIDE PLATE

(1) REQUIREMENT

WITH TAPE LID CLOSED:

MIN. 0.005 INCH

CLEARANCE BETWEEN TAPE LID PIN AND SWINGER INSULATOR.

TO ADJUST

LOOSEN CLAMP SCREW TO FRICTION TIGHT AND ADJUST TAPE LID PIN BY MEANS OF ITS PRY POINT.




FIGURE 1-29. TAPE-OUT AND TAPE LID PIN MECHANISM

NOTE  
FOR ALL ADJUSTMENTS ON THIS PAGE, CONTROL  
LEVER (IF PRESENT) MUST BE IN RUN POSITION




FIGURE 1-30. TIGHT TAPE SWITCH ASSEMBLY




FIGURE 1-31. TAPE-OUT SWITCH ASSEMBLY




FIGURE 1-32. TAPE-OUT PIN AND BAIL ASSEMBLY

START-STOP BAIL YIELD SPRING

TO CHECK

PLACE CONTROL LEVER IN RUN POSITION


REQUIREMENT

MIN. 4 OZS.  
MAX. 6 OZS.  
TO SEPARATE BAILS.

YIELD BAIL

YIELD SPRING

START-STOP  
SLIDE ARM  
ASSEMBLY



CONTROL LEVER SWITCH BRACKET

(1) REQUIREMENT

WITH CONTROL LEVER IN RUN POSITION:  
MIN. 0.006 INCH  
MAX. 0.015 INCH  
CLEARANCE BETWEEN SWITCH ACTUATOR  
AND BAKELITE PAD ON SWINGER.

(2) REQUIREMENT

START-STOP AND TIGHT TAPE SWITCH ACTUATORS SHOULD FULLY ENGAGE BAKELITE PAD ON SWINGER.

TO ADJUST

POSITION SWITCH BRACKET WITH ITS  
MOUNTING SCREWS LOOSENED.

NOTE

IF TIGHT TAPE SWITCH ACTUATOR RESTS  
AGAINST BAKELITE PAD, HOLD ACTUATOR  
AWAY.

ARM ASSEMBLY

START-STOP SLIDE ARM

TIGHT-TAPE SLIDE ARM

MOUNTING  
SCREWS




FIGURE 1-33. START-STOP SWITCH ASSEMBLY



NOTE

WHEN THIS EQUIPMENT IS USED ON THE ASR SET, THE FOLLOWING ADJUSTMENTS (FIGURES 1-34, 35, 36, 37, AND 38) COVER THE RELATIONSHIP BETWEEN THE PIVOTED HEAD TRANSMITTER DISTRIBUTOR AND THE TYPING OR NON-TYPING REPERFORATOR.


**VERTICAL ALIGNMENT OF PIVOTED SENSING HEAD AND PUNCH**

**REQUIREMENT**

WITH PIVOTED SENSING HEAD AGAINST PUNCH BLOCK, TOP PLATE OF SENSING HEAD SHOULD BE  
 MIN. FLUSH  
 MAX. 0.010 INCH BELOW  
 BOTTOM SURFACE OF TAPE SLOT IN PUNCH BLOCK.

**TO ADJUST**

POSITION HEIGHT ADJUSTING SCREW, ON SENSING END OF UNIT, WITH LOCK NUT AND MOUNTING SCREW LOOSENED.



**TRANSMITTER DRIVING AND DISTRIBUTOR SHAFT DRIVEN GEAR MESH**

**REQUIREMENT**

SOME BACKLASH  
 MAX. 0.003 INCH  
 BETWEEN DISTRIBUTOR SHAFT DRIVEN GEAR ON TRANSMITTER AND TRANSMITTER DRIVING GEAR ON BASE. CHECK THROUGHOUT ONE COMPLETE REVOLUTION OF LARGER GEAR.

**TO ADJUST**

POSITION TWO HEIGHT ADJUSTING SCREWS, ON DISTRIBUTOR END OF UNIT, WITH LOCK NUTS AND MOUNTING SCREWS LOOSENED. TURN SCREWS EVENLY TO MAINTAIN PARALLELISM BETWEEN UNITS. RECHECK VERTICAL ALIGNMENT OF PIVOTED SENSING HEAD AND PUNCH.





FIGURE 1-34. INTERRELATED ADJUSTMENTS



HORIZONTAL ALIGNMENT OF PIVOTED SENSING HEAD AND PUNCH  
REQUIREMENT


WHEN ONE TAPE LID EXTENSION IS CENTERED ON RESPECTIVE AREA BETWEEN PUNCH PIN SLOTS, REMAINING EXTENSIONS SHOULD BE FULLY WITHIN THEIR RESPECTIVE AREAS.  
TO ADJUST

LOOSEN TRANSMITTER DISTRIBUTOR AND HORIZONTAL POSITIONING ECCENTRIC MOUNTING SCREWS. SHIFT UNIT TO MEET REQUIREMENT. TIGHTEN UNIT MOUNTING SCREWS. POSITION ECCENTRIC AGAINST REAR PLATE OF TRANSMITTER DISTRIBUTOR AND TIGHTEN ITS MOUNTING SCREW.

NOTE

IT MAY BE NECESSARY TO POSITION THE REPERFORATOR UNIT IF THE REQUIREMENT CANNOT BE MET BY THE ADJUSTMENT OF THE TRANSMITTER DISTRIBUTOR. IF NECESSARY, POSITION THE REPERFORATOR IN THE SAME MANNER AS THE TRANSMITTER DISTRIBUTOR.

FIGURE 1-35. INTERRELATED ADJUSTMENTS



CHECK THE FOLLOWING AFTER COMPLETION OF THE ABOVE ADJUSTMENTS:

- (1) WITH THE TAPE FOLLOWING ITS NORMAL PATH, AND THE PIVOTED SENSING HEAD APPROXIMATELY 15 CHARACTERS AWAY FROM THE PUNCH BLOCK, THE EDGE OF THE TAPE SHOULD NOT TOUCH THE DEPRESSOR.  
TO ADJUST, REFINE THE TAPE DEPRESSOR ADJUSTMENT, FIGURE 1-27.
- (2) WITH THE TAPE FOLLOWING ITS NORMAL PATH, REPERFORATOR RUNNING, AND PIVOTED TRANSMITTER IN THE IDLE LINE CONDITION, THE DEPRESSOR SHOULD GUIDE THE TAPE TO THE TAPE WEDGES TO INSURE POSITIVE STUFFING OF THE TAPE INTO THE TAPE STORAGE BIN. RE-ADJUST THE DEPRESSOR EXTENSION IF NECESSARY.

FIGURE 1-36. INTERRELATED ADJUSTMENTS




FIGURE 1-37. INTERRELATED ADJUSTMENTS


CODE HOLE-SENSING PIN ALIGNMENT

## NOTE

ALL PRECEDING ADJUSTMENTS BETWEEN TRANSMITTER DISTRIBUTOR AND TYPING REPERFORATOR SHOULD BE COMPLETED AND REQUIREMENTS MET BEFORE PRECEEDING WITH FOLLOWING ADJUSTMENTS.

## TO CHECK

WITH A LOOP OF LETTERS TAPE (PERFORATED UNDER POWER BY THE REPERFORATOR) BETWEEN REPERFORATOR AND TRANSMITTER DISTRIBUTOR, AND PIVOTED SENSING HEAD RESTING AGAINST ITS BACKSTOP, MANUALLY TRIP SENSING SHAFT CLUTCH AND ROTATE SHAFT UNTIL SENSING PINS ARE IN THEIR UPPERMOST POSITION.



- (1) REQUIREMENT  
THE SENSING PINS SHOULD BE APPROXIMATELY CENTERED LATERALLY ON CODE HOLES.


## TO ADJUST

REFINE PUNCH FEED HOLE LATERAL ALIGNMENT (SEE TELETYPE BULLETIN 247B)

- (2) REQUIREMENT  
SENSING PINS SHOULD BE POSITIONED TOWARD REAR EDGE OF CODE HOLE  
MIN. 0.008 INCH  
CLEARANCE BETWEEN PIN AND REAR EDGE.  
CHECK FIVE PLACES.


## TO ADJUST

CHECK TAPE QUALITY FOR COMPLIANCE WITH 156011 TAPE GAUGE AND, IF NECESSARY, RE-FINE DETENT ADJUSTMENT (SEE TELETYPE BULLETIN 247B).



## NOTE

IF REQUIREMENT STILL IS NOT MET, POSITION PIVOTED SENSING HEAD TOP PLATE IN REQUIRED DIRECTION WITH ITS MOUNTING SCREWS LOOSENED. RECHECK LAST CHARACTER CONTACT SWITCH ADJUSTMENT (FIGURE 1-37).




- (3) REQUIREMENT  
AS CODE HOLES ARE PUNCHED BY SENSING PINS, THERE SHOULD BE SOME CLEARANCE BETWEEN SIDES OF HOLES AND TAPE LID EXTENSIONS.  
CHECK TEN PLACES.

## TO ADJUST

POSITION PIVOTED SENSING HEAD TOP PLATE LATERALLY WITH ITS MOUNTING SCREWS LOOSENED. RECHECK (2).

FIGURE 1-38. INTERRELATED ADJUSTMENTS




(A) LAST CHARACTER CONTACT LEAF SPRING (ENCLOSED) TO CHECK

REMOVE SWITCH COVER.

- (1) REQUIREMENT  
MIN. SOME  
MAX. 0.010 INCH  
CLEARANCE BETWEEN SWINGER BUTTON  
AND PLUNGER WHEN CONTACTS ARE CLOSED.
- (2) REQUIREMENT  
MIN. 1/4 OZ.  
MAX. 1/2 OZ.  
TO JUST OPEN CONTACTS

TO ADJUST  
REMOVE CONTACT ASSEMBLY FROM UNIT.  
BEND CONTACT SPRINGS TO MEET REQUIREMENTS.




(B) LAST CHARACTER CONTACT ASSEMBLY (ENCLOSED) TO CHECK

TRANSMITTER DISTRIBUTOR AND REPERFORATOR MOUNTED IN NORMAL OPERATING POSITION. TAPE INSERTED IN PUNCH AND PIVOTED READING HEAD.

- (1) REQUIREMENT  
MIN. 0.010 INCH  
MAX. 0.015 INCH  
CLEARANCE BETWEEN TAPE DEFLECTOR  
EAR AND SWITCH PLUNGER WHEN PIVOTED  
HEAD IS ONE CHARACTER AWAY FROM  
PUNCH BLOCK.

NOTE  
PLUNGER MUST TOUCH INSULATING  
BUTTON.



- (2) REQUIREMENT  
MIN. 0.005 INCH  
CLEARANCE BETWEEN CONTACTS WHEN  
PIVOTED HEAD IS AGAINST PUNCH  
BLOCK.

TO ADJUST  
POSITION SWITCH ASSEMBLY WITH BRACKET  
MOUNTING SCREWS LOOSENED. RE-  
PLACE SWITCH COVER.

FIGURE 1-39. FULLY ENCLOSED LAST CHARACTER CONTACT SWITCH

4. DISTRIBUTOR AND TRANSMITTER CONTACT STROBING

## GENERAL INFORMATION

- (1) The following adjustment procedure outlines pulse length requirements for transmitter distributor units operating at various speeds (OPM) and transmission patterns (i.e. 7.00, 7.42, or 7.50 unit code). In all cases, both the test set and the unit under test must be operating at the same speed for proper strobing. All pulse length requirements are made with respect to a 7.42 unit code test set scale, regardless of the cam arrangement of the transmitter distributor.
- (2) When discussing the operating speed of a unit, a number of different terms may be used to represent the same speed. A typical teletypewriter or data channel, for example, may be described in terms of modulation rate (BAUD), or rate of transmission of information (WPM or OPM). In the following strobing procedure, reference is made to both OPM and BAUD. In other parts of this bulletin, reference is also made to WPM. These three terms, although defined differently, can be used interchangeably to represent the operating speed of any Teletype Transmitter Distributor unit.
- (3) The term OPM is an abbreviation for operations per minute. OPM is defined as follows:

$$\text{Formula (1)} \quad \text{OPM} = \frac{c}{\text{sec}} \times 60 \frac{\text{sec}}{\text{min}}$$

That is, the speed of a unit, in operations per minute (OPM), is equal to the transmission rate, in characters per second (c/sec), times 60 sec/min. Since a character is transmitted each operation, this term provides a measure of the amount of information which may be transmitted by the unit.

- (4) The term WPM is an abbreviation for words per minute. WPM is defined as follows:

$$\text{Formula (2)} \quad \text{WPM} = \frac{c}{\text{sec}} \times 60 \frac{\text{sec}}{\text{min}} \div 6 \frac{c}{\text{word}}, \text{ or } \text{WPM} = \frac{c}{\text{sec}} \times 10$$

That is, the speed of a unit, in words per minute (WPM), is equal to the transmission rate, in characters per second (c/sec), times 60 sec/min, divided by 6 c/word. It may be noted, from observation of the defining formulas for OPM and WPM, that a close relationship exists between these terms. The only difference in the defining formulas is that equation (2) has an extra term (6 c/word) which appears as a denominator. From the above two equations, a third one may be derived. Since  $\text{OPM} = c/\text{sec} \times 60 \text{ sec}/\text{min}$ , we can replace the numerator of equation (2) -- which is  $c/\text{sec} \times 60 \text{ sec}/\text{min}$  -- by OPM. The result will be:

$$\text{Formula (3)} \quad \text{WPM} = \frac{\text{OPM}}{6 \frac{c}{\text{word}}}, \text{ and}$$

$$\text{OPM} = (\text{WPM}) \left( 6 \frac{c}{\text{word}} \right)$$

Formula (3) is a valid one to use when converting from one term to the other as long as the exact values, and not approximate values, for WPM or OPM are used. For example, one of the standard Teletype Transmitter Distributor operating speeds is generally stated as being 60 WPM. This value, however, is only an approximate one used to simplify discussion of the unit. In all cases, units transmitting 60 WPM are actually operating at 368 OPM. By formula (3), it can readily be calculated that the unit is transmitting not 60 WPM, but 61.33 WPM:

$$\text{WPM} = \frac{\text{OPM}}{6 \frac{c}{\text{word}}}; \quad \text{WPM} = \frac{368}{6} = \underline{\underline{61.33}}$$

The following table is provided to aid in determining the operating speed of a unit when either OPM or WPM (actual or approximate) is known. It is not a complete listing of all available speeds, but is representative of the speeds most in use.

Operations Per Minute (OPM)	Words Per Minute (WPM)	
	<u>ACTUAL</u>	<u>APPROXIMATE</u>
368	61.33	60
390	65.00	65
428.6	71.43	70
460	76.66	75
600	100.00	100
636	106.00	106
642	107.15	107

- (5) The remaining term, BAUD, is defined as a unit of telegraphic speed - or modulation rate - which indicates the time duration of the shortest signal element of a transmitted character. The defining formula for BAUD is:

$$\text{Formula (4) BAUD} = \frac{\text{OPM} \times \text{UNIT CODE}}{60 \frac{\text{sec}}{\text{min}}}, \text{ or}$$

$$\text{Formula (5) BAUD} = \frac{c}{\text{sec}} \times \text{UNIT CODE}$$

This term differs from the first two defined in that, while OPM and WPM provide an indication of the amount of information transmitted by a unit, the term BAUD is most correctly used when referring to the binary digital modulation rate of the information transmitted.

- (6) The objective of this discussion has been to introduce the technician to the above terms, so that their usage will be better understood by him. Finally, by use of the five defining formulas, the technician should be able to convert from one type of speed terminology to another, if the need should arise.



A. CONTACT STROBING - PIVOTED HEAD TRANSMITTER DISTRIBUTOR

NOTE

To strobe the distributor and sensing contacts, a Signal Distortion Test Set (DXD) or Stroboscopic Test Set (LSS) may be used. For operation of these sets, refer to Bulletin 181B or 261B, respectively.

- (1) Distributor Contacts - Stop and #1 through #5 (368, 390, 428, 460, 600, and 635 OPM)

PROCEDURE


- (a) Connect a test set to the output of the distributor contacts. Test set and transmitter distributor must be operating at the same speed.
- (b) Insert a "blank" perforated tape into the transmitter distributor pivoted sensing head. Trip the sensing shaft clutch (on some units, the sensing shaft clutch is tripped electrically via operation of the distributor shaft.) Orient the test set scale so the 142 mark of its stop segment is aligned with the end of the stop pulse image.

Requirement

Length of stop pulse to be:  
 106 scale divisions ( $\pm 3\%$ ) for 7.00 unit code cam  
 142 scale divisions ( $\pm 4\%$ ) for 7.42 unit code cam

To Adjust

Rotate the distributor stop contact adjusting screw to meet requirement.



NOTE

3% is equivalent to 3.18 scale divisions (7.00 unit code) and  
 4% is equivalent to 5.68 scale divisions (7.42 unit code).

- (c) Replace the "blank" perforated tape with the "R" perforated tape. Align the end of the stop pulse image with the 142 scale division on the stop segment of the test set scale.

## Requirement

#2 and #4 images equal in total length within  $\pm 4\%$  (7.42 unit code) or  $\pm 3\%$  (7.00 unit code) of each end of the #2 and #4 pulse image transition point on the test set scale (see Table 1).

## To Adjust

Rotate the #2 and #4 contact adjusting screws to meet requirement.

- (d) Replace the "R" perforated tape with a "Y" perforated tape. Align the end of the stop pulse image with the 142 scale division on the stop segment of the test set scale.

## Requirement

#1, #3, and #5 pulse images equal in total length within  $\pm 4\%$  (7.42 unit code) or  $\pm 3\%$  (7.00 unit code) of each end of the #1, #3, and #5 pulse image transition points of the test set scale (see Table 1).

## To Adjust

Rotate the #1, #3, and #5 contact adjusting screws to meet requirement.

## NOTE 1

3% is equivalent to 3.18 scale divisions (7.00 unit code) and  
4% is equivalent to 4.00 scale divisions (7.42 unit code).

## NOTE 2


In order to determine end of #5 Pulse image, it may be necessary  
to hold stop contact open.

TABLE 1


PULSE IMAGE TRANSITION POINTS ON TEST SCALE

TEST SET SEGMENT	7.00 UNIT CODE		7.42 UNIT CODE	
	BEGIN AT SCALE DIV.	END AT SCALE DIV.	BEGIN AT SCALE DIV.	END AT SCALE DIV.
STOP	36 IN STOP SEGMENT	142 IN STOP SEGMENT	0 IN STOP SEGMENT	142 IN STOP SEGMENT
1	6 IN #1 SEGMENT	12 IN #2 SEGMENT	0 IN #1 SEGMENT	100 IN #1 SEGMENT
2	12 IN #2 SEGMENT	18 IN #3 SEGMENT	0 IN #2 SEGMENT	100 IN #2 SEGMENT
3	18 IN #3 SEGMENT	24 IN #4 SEGMENT	0 IN #3 SEGMENT	100 IN #3 SEGMENT
4	24 IN #4 SEGMENT	30 IN #5 SEGMENT	0 IN #4 SEGMENT	100 IN #4 SEGMENT
5	30 IN #5 SEGMENT	36 IN STOP SEGMENT	0 IN #5 SEGMENT	100 IN #5 SEGMENT

DISTRIBUTOR CONTACTS #1 THROUGH #5 PULSE LENGTH REQUIREMENTS FOR  
7.00 UNIT CODE OPERATION AT 390, 428, AND 635 OPM (SEE TABLE 1).



DISTRIBUTOR CONTACTS #1 THROUGH #5 PULSE LENGTH REQUIREMENTS FOR  
7.42 UNIT CODE OPERATION AT 368, 460, AND 600 OPM (SEE TABLE 1).



(2) Distributor Auxiliary Contacts "A", "B", and "C"

- (a) Following requirements applicable for units transmitting 7.42 unit code at 368, 460, or 600 OPM:

Align the end of the stop pulse image with the 142 scale division on the stop segment of the test set scale.

Requirement - Auxiliary "A" Contact

Auxiliary "A" contact should:

Close at  $32 \pm 15$  divisions in start segment

Open at  $29 \pm 15$  divisions in stop segment

Requirement - Auxiliary "B" Contact

Auxiliary "B" contact should:

Close at  $25 \pm 15$  divisions in #1 segment

Open at  $75 \pm 15$  divisions in #5 segment

To Adjust

Rotate the distributor auxiliary "A" and "B" contact adjusting screws to meet requirements.

- (b) Following requirements applicable for units transmitting 7.00 unit code at 390, 428, or 635 OPM:

Requirement - Auxiliary "C" Contact


Auxiliary "C" contact should

Close at  $29.5 \pm 5$  divisions in start segment

Open at  $48 \pm 8$  divisions in stop segment.

To Adjust

Rotate the distributor auxiliary "C" contact adjusting screw to meet requirements.



(3) Transmitter Contacts (Sensing) - #1 through #5

PROCEDURE

- Test set connected to the output of the distributor contacts.
- Insert a "Letters" perforated tape into the transmitter distributor sensing head. Align the end of the distributor stop pulse image with the 142 scale division on the stop segment of the test set scale.
- Connect input of test set to respective contact (#1 through #5) of the storing switch.

NOTE

7.42 Unit Code

Contacts #1 through #5 shall have no electrical breaks during the transmitted (distributor) code pulses (see Table 1 for transition points) greater than 2-1/2 scale divisions at 600 OPM, 2 scale divisions at 460 OPM, and 1-1/2 scale divisions at 368 OPM. No more than one break is permissible.

7.00 Unit Code

Contacts #1 through #5 shall have no electrical breaks during the transmitted (distributor) code pulses. (Any electrical breaks occurring within the  $\pm 3\%$  tolerance limits of the distributor contacts are acceptable). When reading successive marking code perforations, the time of contact opening shall not exceed 1.5 ms.

Requirement - 7.42 unit code cam

At 600 OPM

The beginning and end of each contact trace shall occur:

Before 30 divisions in start segment

After 40 divisions in stop segment

At 460 OPM

The beginning and end of each contact trace shall occur:

Before 45 divisions in start segment

After 31 divisions in stop segment

At 368 OPM

The beginning and end of each contact trace shall occur:


Before 55 divisions in start segment

After 25 divisions in stop segment

To Adjust  
Position respective contact adjusting screw as necessary.

NOTE

Beginning and end of pulse image may overlap within transition area.




Requirement - 7.00 unit code cam  
At 390, 428, or 630 OPM  
The beginning and end of each contact trace shall occur:  
Before 80 divisions in start segment  
After 20 divisions in stop segment

To Adjust  
Position respective contact adjusting screw as necessary.

NOTE

Beginning and end of pulse image may overlap within transition area.



(4) Transmitter Contacts - Auxiliary, Tape Out, and Distributor Clutch Trip

PROCEDURE

- (a) Both magnets de-energized, distributor and transmitter shaft clutches latched and in the stop position. Turn motor off.
- (b) Hold distributor and transmitter shaft gears against rotation. Energize both clutch trip magnets.
- (c) Release gears and turn motor on.
- (d) Align the end of the distributor stop pulse image with the 142 scale division on the stop segment of the test set scale.
- (e) Pulse length requirements for 7.42 unit code operation at 368, 460, or 600 CPM.

Requirement - Auxiliary contact

Auxiliary contact should:

Close at  $12 \pm 30$  divisions in start segment

Open at  $70 \pm 30$  divisions in #4 segment

Requirement - Tape Out contact

With no tape in pivoted head transmitter, Tape Out Contact should:

Close at  $50 \pm 30$  divisions in #5 segment

Open at  $65 \pm 30$  divisions in #3 segment

Requirement - Clutch Trip Contact


With distributor clutch trip contact electrically isolated from circuit, clutch trip contact should:

Close at  $18 \pm 30$  divisions in #4 segment

Open at  $46 \pm 30$  divisions in #5 segment

To Adjust

Position respective contact adjusting screws as necessary.



- (f) Pulse length requirements for 7.00 unit code at 390, 428 or 635 OPM.

Requirement - Auxiliary "A" Contact

Auxiliary "A" contact should:

Close at  $90 \pm 8$  divisions in #5 segment

Open at  $36.5 \pm 20$  divisions in #1 segment

## Requirement - Auxiliary "B" Contact

Auxiliary "B" contact should:

Close at  $83 \pm 12$  divisions in start segmentOpen at  $33.5 \pm 8$  divisions in #4 segment


## Requirement - Tape Out (6th Pin)

With no tape in transmitter, tape out contact should:

Close at  $60 \pm 40$  divisions in #5 pulseOpen at  $35 \pm 40$  divisions in #3 pulse

## To Adjust

Position respective contact adjusting screws as necessary.

B. CONTACT STROBING - FIXED HEAD TRANSMITTER DISTRIBUTOR

- (1)
- Distributor Contacts - Stop and #1 through #5 (368, 460 and 600 CPM)

## NOTE

The following is merely a check on the operation of the fixed reader sensing contacts, and no readjustments should be necessary. Any signal breaks may be due to dirt or oil on the contacts, or low contact pressure.

- Insert a "blank" perforated tape into the transmitter distributor fixed sensing lead. Trip the fixed reader sensing shaft clutch (on some units, the sensing shaft clutch may be tripped electrically via operation of the pivoted head distributor shaft).
  - Align the end of the stop pulse image with the 142 scale division on the stop segment of the set scale (refer to paragraph 4.a. (1) (b)).
  - Recheck the distributor contacts according to the procedure in paragraphs 4.a. (1) and (2).
- (2) Transmitter Contacts (Sensing) - #1 through #5

Check the #1 through #5 transmitter contacts according to the procedure given in paragraph 4. a. (3).

(3) Transmitter Contacts - Auxiliary and Distributor Clutch Trip

PROCEDURE

- (a) Both magnets de-energized, pivoted reader distributor and fixed reader transmitter clutches latched and in the stop position. Turn motor off.
- (b) Hold fixed reader transmitter and pivoted reader distributor shaft gears against rotation. Energize both clutch trip magnets
- (c) Release gears and turn motor on.
- (d) Align the end of the distributor stop pulse image with the 142 scale division on the stop segment of the test set scale.
- (e) Pulse length requirement for 7.42 unit code operation at 368, 460, and 600 OPM.

Requirement - Auxiliary Contact

Auxiliary contact should:

Close at  $12 \pm 30$  divisions in start segment

Open at  $70 \mp 30$  divisions in #4 segment

Requirement


With distributor clutch trip contact electrically isolated from circuit, clutch trip contact should:

Close at  $39 \pm 30$  divisions in #4 segment

Open at  $67 \mp 30$  divisions in #5 segment

To Adjust

Position respective contact adjusting screws.



- (f) Pulse length requirement for 7.00 unit code operation at 390, 428, and 635 OPM. - Strobe contacts according to paragraph 4. a. (4) (f).



## SECTION 2

## DISASSEMBLY AND REASSEMBLY

## 1. GENERAL

a. This section presents disassembly and reassembly instructions necessary to break the transmitter distributor (LCXD) into its various subassemblies. The instructions are arranged in a sequence which should be followed only when a complete disassembly of the unit is required. Disassembly of a specific subassembly (for replacement or repair purposes) would normally require removal of associated subassemblies in the same area. Refer to Teletype Parts Bulletin 1171B for detailed illustrations of the parts referred to in the text.

b. Perform any necessary adjustments after reassembly of the unit.

## 2. DISASSEMBLY AND REASSEMBLY

## a. Cover Plate Assembly (Fixed Reader)

(1) To remove the cover plate assembly, lift the left end upward and slide the plate to the left to disengage the spring clip.

(2) To install the cover plate assembly, reverse the disassembly procedure.

## b. Top Plate Assembly (Fixed Reader)

(1) To remove the top plate assembly, loosen the front and rear mounting screw and lift the plate upward.

(2) To install the top plate assembly, guide the mounting screws into the notches in the front and rear plates on the unit. Align and adjust top plate position.

## c. Tape Guide Plate Assembly (Fixed Reader)

(1) To remove the tape guide plate assembly, loosen the front and rear mounting screws and slide the plate upward.

(2) To install the tape guide plate assembly, guide the mounting screws into the notches in the front and rear plates in the unit. Align and adjust the tape guide plate position.

## d. Cover Plate (Pivoted Reader)

(1) Loosen the captive screw on top. Loosen the two mounting screws on the left of the plate. Lift the plate up.

(2) To install the cover plate, reverse the disassembly procedure.

## e. Idler Gear Assembly

(1) To remove the idler gear assembly, remove the feed lever spring (82727) and latch stripper bail spring (125252).

(2) Remove the oil reservoir bar assembly by removing the screws, lock washers, and flat washers holding the bar to its mounting bracket.

(3) Pull out the idler gear oil retainer plug (158789), and remove the leather washer (85318).

(4) Remove the idler gear bearing stud lock nut, lock washer, and flat washer.

(5) Remove the idler gear bearing stud (158790), idler gear, and spacer as a unit.

(6) To install the idler gear assembly, reverse the disassembly procedure.

## f. Sensing Shaft Assembly (Pivoted Reader)

(1) To remove the sensing shaft assembly, remove the idler gear (see paragraph 2. e.)

(2) Remove the front bearing clamp (156788) by removing the three mounting screws and lock washers.

(3) Remove the rear bearing clamp (158847) by removing the two screws and lock washers.

(4) Remove the sensing shaft assembly.

(5) To install the sensing shaft assembly, reverse the disassembly procedure.

g. Distributor and Sensing Shaft Assembly (Pivoted and Fixed Reader) - Follow the sensing shaft procedure in step f. above.

## h. Clutch Trip Assembly

(1) To remove the clutch trip assembly, disconnect the wires leading to the clutch magnet (252M).

(2) Remove the plate mounting screw (with lock washer and flat washer), and the plate adjusting screw, lock washer, and flat washer.

(3) Withdraw the clutch trip assembly from the bottom side of unit.

(4) To install the clutch trip assembly, reverse the disassembly procedure.

## i. Pivot Shaft

(1) To remove the pivot shaft, remove the sensing shaft assembly (see paragraph 2. f.) or sensing and distributor shaft assembly (see paragraph 2. g.)

(2) Remove the two ring retainers (one is hidden under a felt washer).

(3) Loosen the collar set screws.

(4) Remove pivot shaft nut, lock washer, and flat washer.

(5) Remove the pivot shaft (158819) by pushing it toward the rear, being careful not to lose the feed lever collars and felt washers.

(6) To install pivot shaft, reverse disassembly procedure.

## j. Pivoted Sensing Head (Pivoted Reader)

(1) To remove sensing head and tape deflector, remove the last character contact assembly.

(2) Remove the check pawl spring (45104).

(3) Remove the tape deflector spring (82999).

(4) Loosen the rear pivot screw lock nut (76474), and run the rear pivot screw (158801) as far as possible into the casting.

(5) Pull the sensing pins down and free from

the top plate.

(6) Loosen the front pivot screw lock nut (112626).

(7) Turn front pivot screw (158800) until the deflector (159158) is free from the pivot screw.

(8) Remove the sensing head and tape deflector.

(9) To install the sensing head and tape deflector, reverse the disassembly procedure.

## k. Storing Switch Assembly

(1) To remove the storing switch assembly, disconnect the cable assembly.

(2) Remove the four mounting screws, lock washers, and flat washers.

(3) Remove the storing switch assembly.

(4) To install the storing switch assembly, reverse the disassembly procedure.

## l. Distributor Block Assembly

(1) To remove the distributor block assembly, disconnect the cable assembly.

(2) Remove the three mounting screws, lock washers, and flat washers.

(3) Remove the distributor block assembly.

(4) To install the distributor block assembly, reverse the disassembly procedure.

SECTION 3  
LUBRICATION

1. INTRODUCTION

a. This section provides lubrication information for the Teletype Model 28 (LCXD) Transmitter Distributor.

CAUTION

The transmitter distributor is shipped with the oil reservoir empty. Remove the cover plate for access to the reservoir. Fill the oil reservoir according to the lubrication instructions on page 3-5.

b. On the following pages, the general areas of the equipment are shown by photographs. The specific points to receive lubricant are indicated by line drawings and descriptive text. The symbols in the text indicate the following directions:

- O Apply one drop of oil.
- O2 Apply two drops of oil.
- O3 Apply three drops of oil, etc.
- G Apply thin coat of grease.
- SAT Saturate with oil (felt washers, etc.)

Teletype KS7470 oil and KS7471 grease should be used at all lubrication points.

2. GENERAL

a. The equipment should be thoroughly lubricated, but over-lubrication which might allow oil to drip or grease to be thrown on other parts, should be avoided. Exercise special care to prevent lubricant from getting between armature and pole faces. Keep all electrical contacts free from oil or grease.

b. The following general instructions supplement the specific lubricating points illustrated in this section.


- (1) Apply one drop of oil to all spring hooks.
- (2) Apply a light film of oil to all cam surfaces.
- (3) Apply a coat of grease to all gears.
- (4) Saturate all felt washers, oilers, etc.
- (5) Apply oil to all pivot points.
- (6) Apply oil to all sliding surfaces.

c. The transmitter distributor should be lubricated before being placed in service or prior to storage. After a few weeks of service, re-lubricate to make certain that all specified points have received lubricant. Thereafter, the following schedule should be adhered to:


<u>OPERATING SPEED</u>	<u>LUBRICATION INTERVAL</u>
60 W. P. M.	3000 hours or 1 year *
75 W. P. M.	2400 hours or 9 months *
100 W. P. M.	1500 hours or 6 months *

\*Whichever occurs first.



3. LUBRICATION




3.01 CLUTCH TRIP ASSEMBLIES




3.02 STORING SWITCH ASSEMBLY




3.03 DISTRIBUTOR BLOCK ASSEMBLY




3.04 CLUTCH ASSEMBLIES




3.05 CAM SLEEVE ASSEMBLIES




3.06 OIL RESERVOIR ASSEMBLY



NOTE  
OIL DEPTH NOT TO EXCEED 7/8 INCH. USE A 0.010 INCH FLAT GAUGE FROM 117781 SET OF GAUGES AS A DIP STICK.




3.07 PIVOTED SENSING HEAD







3.08 CHECK PAWL AND FEED WHEEL




3.09 PIVOTED SENSING MECHANISM




3.10 FIXED SENSING MECHANISM




3.11 SENSING MECHANISMS





3.12 SENSING MECHANISM




3.13 FEED MECHANISM




3.14 FEED MECHANISM



3.15 TAPE LID AND TAPE GUIDE



3.16 TIGHT TAPE SENSING MECHANISM



3.17 TAPE-OUT AND TAPE LID MECHANISM

