

TELETYPEWRITER SETS AN/FGC-25, AN/FGC-25X
 AN/FGC-26, AN/FGC-52, AN/FGC-52X, AND AN/FGC-57

TM 11-5815-244-35 }
 TO 31W4-2FGC-232 }
 CHANGES No. 1 }

DEPARTMENTS OF THE ARMY
 AND THE AIR FORCE
 WASHINGTON 25, D.C., 28 September 1962


TM 11-5815-244-35/TO 31W4-2FGC-232, 5 October 1960, is changed as indicated, so that the manual also applies to the following equipments on Order No. 42770-PC-59:

FGC-25 and AN/FGC-25X, respectively, except that 8.00 unit code is transmitted by the keyboard-transmitters and 7.00 unit code is transmitted by the transmitter-distributors. Except for this difference, which is specifically noted in this changes, information in the manual applicable to Teletypewriters TT-117A/FG and TT-119A/FG is equally applicable to Teletypewriters TT-269/FG and TT-271/FG respectively; information applicable to Reperforator-Transmitters TT-178A/FG and TT-179A/FG is equally applicable to TT-272/FG and TT-270/FG, respectively.

Nomenclature	Components		
	Teletypewriter	Reperforator-Transmitter	Table
Teletypewriter Set AN/FGC-52.	TT-269/FG	TT-270/FG	FN-65/FG
Teletypewriter Set AN/FGC-52X.	TT-271/FG	TT-272/FG	FN-65/FG

Note. Teletypewriter Sets AN/FGC-52 and AN/FGC-52X are identical to Teletypewriter Sets AN/

Change the title of the manual to: TELETYPEWRITER SETS AN/FGC-25, AN/FGC-25X, AN/FGC-26, AN/FGC-52, AN/FGC-52X, and AN/FGC-57.



TM5815-244-35-CI-50

Figure 32.1. Block diagram, condition P. (Added)

Page 27, paragraph 17. Add the following after subparagraph o:

p: Patch Panel Condition P. Patch panel condition P (fig. 32.1) connects the transmitter-distributor and the keyboard-transmitter in a send only circuit with line 1 or line 2 as determined by the line switch key. The page printing mechanism and the tape receiver are connected to line 3. Connect the patch panel as indicated in the chart in a above to set up condition P.

- (1) TT-178/FG and TT-179/FG (fig. 17).

Patch panel plugs	Patch panel condition														P		
	A	B	C	D	E	F	G	H	I	J	K	L	M	N		O	
PRINTER RECEIVE P35																	J38
PRINTER SEND P36																	J37
TAPE DIST P37																	J41
REPERF P38																	J46
MONITOR 1 P39																	J44
MONITOR 2 P40																	J45
LINE TEST P41																	J36
AUTO LINE RET IN P42																	J42
AUTO LINE RET OUT P43																	J43
LINE 1 P44																	J39
LINE 2 P45																	J40
LINE 3 P46																	J35
LINE 4 P47																	J47
D. C. TEST P48																	J48

- (2) All models except TT-178/FG and TT-179/FG (fig. 18).

Patch panel plugs	Patch panel condition														P		
	A	B	C	D	E	F	G	H	I	J	K	L	M	N		O	
PRINTER RECEIVE P203																	J214
PRINTER SEND P204																	J218
TAPE DIST P213																	J209
REPERF P214																	J202
MONITOR 1 P206																	J207
MONITOR 2 P205																	J208

Patch panel plugs	Patch panel condition														P		
	A	B	C	D	E	F	G	H	I	J	K	L	M	N		O	
LINE TEST SW P209																	J204
AUTO LINE RET IN P212																	J212
AUTO LINE RET OUT P210																	J210
LINE 1 P207																	J206
LINE 2 P208																	J205
LINE 3 P202																	J203
LINE 4 P201																	J201
D. C. TEST P211																	J211

Page 138, paragraph 105, chart. Delete the last two items and substitute:

Item	Federal Stock No.
Grease -----	9150-K60-4294 (temp)
Oil, lubricating -----	9150-K60-4297 (temp)
Lubricant, plastic parts-----	9150-K60-4293 (temp)

Page 140, paragraph 107d, line 1. Delete "(KS7470)."

Page 144. Delete paragraph 113 and substitute:

113. Recommended Lubricants

The recommended lubricants are—

a. Oil, lubricating 1-pint can, Federal stock No. 9150-K60-4297 (temp).

b. Grease, 1-pound container, Federal stock No. 9150-K60-4294 (temp).

c. Lubricant, plastic parts, Federal stock No. 9150-K60-4293 (temp).

Paragraph 114, chart. Add the following note below the chart:

Note. The above intervals between lubrication checks apply to teletypewriter equipment in which felt washers are used only as part of friction clutch assemblies. Equipments that include lubricating felts at additional lubrication points require less frequent lubrication at those particular lubrication points. Lubricate the felts only when necessary; avoid oversaturation. Refer to paragraph 527.1 for felt lubricating washer data.

Page 145, paragraph 118b, chart. Delete the chart and substitute:

Fig. No.	Item No.	Name of part	Method and quantity
157	16	Carriage-return driving and driven gears	Apply sparingly around teeth.
158	11	Main shaft driving gears (inside cover)---	Work grease around gear and cover gear teeth liberally.
159	2	Carriage rack driving gears-----	} Apply sparingly around gear teeth.
159	6	Function shaft driven gear-----	
159	8	Square shaft driving gear-----	
159	21	Function shaft driving gear-----	
159	23	Carriage-feed worm gear-----	
159	26	Carriage-return shaft drive gears-----	
159	27	Transmitter shaft drive gears-----	} Thin film on cam surfaces.
162	3	Clutch yoke cam -----	
164	4	Ribbon drive gears-----	Apply sparingly around gear teeth.
164	12	Guide rail -----	
166	4	Carriage-feed and return driving rack----	Apply sparingly to rack teeth.

Page 146, paragraph 118. Delete subparagraphs *d*, *e*, and *f* and substitute:
d. Oilholes. Apply oil at the following oilholes:

Fig. No.	Item No.	Name of part	Method and quantity
159	14	Code-ring cage -----	At least 5 drops in hole on top of central bearing sleeve (underneath stop bars).
159	22	Carriage-feed driven gear-----	At least 5 drops in hole in hub.
166	7	Type selecting arm bearing cap-----	At least 5 drops in hole in bearing cap.

e. Sleeve Bearings. Apply oil at the following bearings:

Fig. No.	Item No.	Name of part	Method and quantity
157	10	Square shaft bearings-----	Several drops at either end of both bearings.
157	11	Platen frame pivot bearings-----	Several drops between pivot and bearings.
157	17	Carriage rack drive shaft bearing-----	Several drops at both ends of bearing.
158	6	Printing bail blade shaft bearings-----	} Several drops at either end of both bearings.
159	20	Transfer lever shaft-----	
160	6	Cam stop lever post-----	Several drops at either end.
164	1	Platen shaft bearings-----	Several drops at either end of both bearings.

f. Moving Parts. Apply oil at the following places:

Fig. No.	Item No.	Name of part	Method and quantity
157	1	Stop bar shift blade-----	Apply sparingly to latching surface.
157	3	Felt washer (function shaft)-----	Saturate.
157	4	Square shaft -----	Thin film all sides, entire length.
157	5	Carriage-feed pawl, ratchet wheel and felt washer.	Apply sparingly to teeth; 2 drops at each pawl pivot. ^a
157	6	Felt washer (horizontal carriage-return link).	Saturate.
157	7	Carriage-return operating mechanism----	2 drops at each pivot point. ^a
157	8	Manual carriage-return mechanism-----	Apply sparingly to all pivots and rubbing surfaces.
157	9	Felt washers (on square shaft and on print bail blade shaft.	Saturate.

See footnote at end of table.

Fig. No.	Item No.	Name of part	Method and quantity
157	12	Carriage-return sliding clutch drum-----	Apply sparingly to teeth and annular grooves, 2 or 3 in each group of spline balls inside clutch.
157	13	Carriage-return safety clutch plates-----	Several drops around periphery of each washer.
157	15	Decelerating cam -----	Thin film on working surface.
157	18	Carriage-return clutch latch lever-----	2 drops on pivots; thin film on working surfaces. ^a
157	19	Carriage-feed clutch lever-----	2 drops at pivot; thin film at each end. ^a
157	20	Felt washer (by the carriage driving gear).	Saturate.
157	21	Margin bell clapper and pawl-----	1 or 2 drops at each pivot point and at tip of pawl.
157	22	Carriage-feed clutch -----	Add sparingly to clutch teeth.
157	23	Carriage-feed sliding clutch drum-----	Add sparingly to rubbing surfaces.
157	24	Platen lower-case latch-----	1 drop at pivot, apply sparingly to latching surface. ^a
157	25	Code-ring locking bail shaft-----	1 drop at blade and cam follower lever.
157	26	Function bellcrank pivots-----	Several drops between levers and washers. ^a
157	27	Function sensing levers-----	Add sparingly to rubbing surfaces.
158	1, 2	Paper guide link-----	1 drop at each end.
158	3	Function selecting arm-----	Apply sparingly to all working surfaces.
158	4	Stop bar shift lever-----	1 drop at pivot.
158	5	Felt washer (on function selecting arm bearing).	Saturate.
158	7	Felt washer (stop bar shift lever pivot) --	Saturate.
158	8	Stop bar shift link-----	Thin film.
158	9	Paper roller latch-----	1 drop at pivot.
158	10	Motor stop actuating lever and signal bell clapper pivots.	2 drops at each pivot point.
158	12	Function cam follower-----	Apply sparingly to cam groove and bearing of roller. ^a
158	13	Felt washer (on carriage-feed link)-----	Saturate.
158	14	Unshift and carriage-feed levers and felt washer.	2 drops at each pivot. Saturate felt washer.
158	15	Support lever -----	2 drops at each pivot. ^a
158	16	Function punch bars-----	Several drops between bars and guide block.
158	17	Platen latch -----	2 drops at pivot; thin film on working surface, each end. ^a
158	18	Aperture gate -----	2 drops in notch; several drops between gate and guide block.
159	1	Printing bail blade and felt washers-----	Thin film both sides, along entire edge. Saturate felt washers.
159	3	Clutch spring -----	Apply sparingly to clutch spring.
159	4	Function shaft sliding clutch drum-----	At least 5 drops in hole on either side. ^a
159	5	Function driven gear-----	Several drops at bearing and clutch teeth.
159	7	Felt washer (on function driven gear)---	Saturate.
159	9	Delaying lever -----	1 drop at pivot. ^a
159	10	Line feed and figures connecting links----	2 drops at each end of both links.
159	11	Line feed and figures bellcrank pivots----	Several drops at each pivot. ^a
159	12	Line feed and figures cam follower pivots--	2 drops each.
159	13	Delaying latch -----	1 drop at pivot; apply sparingly to latching surface. ^a
159	15	Code rings -----	Thin film all along inner and outer working surfaces of each code bar.
159	16	Line feed and figures cam followers-----	Apply sparingly to rollers, pivots, and all rubbing surfaces.


See footnote at end of table.

Fig. No.	Item No.	Name of part	Method and quantity
159	17	Line feed, figures, and sensing lever restoring cams.	Thin film on all exposed surfaces.
159	22	Felt washer (next to carriage-feed driven gear).	Saturate.
159	24	Clutch latch -----	Apply sparingly to roller and latching surfaces.
159	25	Carriage-return blocking mechanism-----	1 or 2 drops at pivot; apply sparingly to latch surfaces.
159	28	Print cam follower-----	Apply sparingly to cam groove and bearing of roller and to spring hook.
159	29	Felt washers on function shaft (on each side of bearing block).	Saturate.
160	1	Selector levers, bearing, and separating washers.	Apply sparingly to all rubbing and bearing surfaces. ^a
160	2	Transmitter contact E4 pivot-----	2 or 3 drops between arm and pivot studs.
160	3	Sensing lever locking bail-----	1 or 2 drops on bail surface and between lever and comb.
160	4	Transmitter camshaft -----	Thin film on all cam lobes and stop teeth.
160	5	Cam stop lever-----	1 or 2 drops at pivot; apply sparingly to latching surfaces. ^a
160	7	Locking lever latch stud-----	2 or 3 drops at pivot points; thin film on latching surface. ^a
160	8	Actuating link -----	2 drops at pivot point.
160	9	Function blocking bar spring-----	1 drop at each end; light film on spring surface.
160	10	Shunt switch arm springs-----	1 drop at each end; light film on spring surface.
160	11	Switch arm -----	1 or 2 drops at pivot point.
161	1	Stop bars in code-ring cage-----	2 drops at each end of all 35 stopbars.
161	2	Plate eccentric pivot-----	1 or 2 drops at pivot points.
161	3	Code-ring locking shaft-----	1 drop at each pivot.
161	4	Detent wheel -----	Several drops at lever point; thin film on detent wheel teeth.
161	5	Single-double line feed lever-----	1 drop at pivot and detent surface. ^a
161	6	T-lever -----	2 drops on bearing surface.
161	7	Code-ring locking bail latching surface---	Thin film on latching surface.
161	8	T-levers and separating washers-----	Apply sparingly to all rubbing and bearing surfaces. ^a
161	9	Y-levers and Y-lever detent separating washers.	Apply sparingly to all rubbing and bearing surfaces. ^a
161	10	Selector lever guide-----	Apply sparingly to all rubbing surfaces.
161	11	Selector magnet armature knife edge---	Apply sparingly.
161	12	Selector levers, pivot bearings and separating washers.	Apply sparingly to all rubbing surfaces. ^a
161	13	Orientation lever pivot and rangefinding cam.	1 or 2 drops. Thin film on cam surface. ^a
161	14	Grooved pin in end of selector camshaft--	Several drops between pin and camshaft.
161	15	Selector cams and stop plate-----	Thin film on working surfaces.
161	16	Transfer lever latch-----	2 drops on pivot; thin film on latching surface. ^a
161	17	Felt washer (on pivot post)-----	Saturate.
161	18	Transfer lever restoring cams-----	1 drop on cam surface.
161	19	Transfer lever roller-----	Apply sparingly to working surfaces.
161	20	Antibounce clutch -----	Several drops in clutch.
161	21	Felt washer (on stop arm shaft)-----	Saturate.
162	1	Link arm assembly-----	2 drops at pivot. Thin film all along notched edge of each bar.
162	2	Keyboard counter cam followers-----	2 drops at pivot.
162	4	Sensing levers -----	Apply sparingly at working surfaces at each end of pivot. ^a

See footnote at end of table.


Fig. No.	Item No.	Name of part	Method and quantity
162	5	Ratchet pawl -----	} 2 drops at pivot.
162	6	Line indicator drive shaft pivots -----	
162	7	Tabulator lever ^a -----	
163	1	Line indicator drive shaft antibounce plate	} 1 drop on each pin.
163	2	Tabulator lever -----	
164	2	Line feed pawl ^a -----	
164	3	Sprocket feed pins -----	1 drop at pivot; apply sparingly to latching surfaces.
164	5	Beam detent -----	Apply sparingly to clutch teeth.
164	6	Ribbon feed clutch -----	Apply sparingly to bearings, cam surfaces, and gear teeth at both ends.
164	7	Ribbon drive shaft -----	1 or 2 drops at each bearing and pin.
164	8	Ribbon sensing levers -----	Apply sparingly to annular groove, teeth, and driving jaws.
164	9	Ribbon spool driving gears -----	1 or 2 drops at bearings, top and bottom.
164	10	Ribbon spool drive shafts -----	Apply sparingly to rolling surfaces.
164	11	Ball bearing and guide rail -----	Apply sparingly to all pivots and rubbing surfaces.
164	13	Manual letters mechanism -----	2 drops at each pivot. ^a
164	14	Carriage-return bellcrank and vertical link	1 drop at pivot. ^a
164	15	Armature shaft -----	1 drop at each pivot.
165	1	Key levers -----	Thin film all along notched edge of each bar. 2 or 3 drops in each groove.
165	2	Code bars and studs -----	1 drop each.
165	3	Spacebar pivots -----	1 drop in each key lever guide slot.
165	4	Front key lever guide -----	1 drop at handle pivots.
166	1	Ribbon shaft lock -----	Thin film on sliding surfaces.
166	2	Ribbon guide -----	2 or 3 drops at each pivot; apply sparingly to gear teeth.
166	3	Hinge pin -----	1 or 2 drops at pivots.
166	5	Ribbon lifter bellcrank -----	1 or 2 drops at each guide plate.
166	6	Connecting bars guide plate -----	Apply sparingly between arm and claw. ^a
166	8	Type selecting arm -----	1 or 2 drops at each pivot. ^a
166	9	Ribbon lifter bracket -----	Thin film on sliding surfaces.
166	10	Ribbon lifter pivot bearing -----	1 or 2 drops at pivot point and working surface.
167	1	Cam follower -----	2 drops at pivot.
167	2	Tabulator shaft pivot -----	Light coat on entire working surface.
167	3	Ratchet wheel -----	1 or 2 drops at pivots; light coat on the entire length of shaft.
167	4	Indicator carriage drive shaft -----	1 or 2 drops at pivot and working surface. ^a
167	5	Indicator return latch -----	1 or 2 drops on roller and pivot points.
168	1	Indicator carriage -----	1 or 2 drops at pivot point and working surface.
168	2	Tabulator locking lever -----	1 or 2 drops at each end.
169	1	Governor adjustment lever -----	Apply sparingly to entire thread.
169	2	Governor adjustment screw -----	Apply sparingly to gear teeth.
169	3	Motor governor adjustment gear -----	2 or 3 drops in governor hub opening.
169	4	Governor worm -----	1 or 2 drops at pivot point and working surface.
170	1	Transmitter lever post pivot -----	1 or 2 drops on pin.
170	2	Lockup lever roller -----	Slight film on working surface.
170	3	Cam arm -----	2 drops at pivot.
171	1	Keyboard control lever hub -----	Thin film on detent surfaces.
171	2	Detent lockup lever -----	2 drops at pivots.
171	3	Lockup lever eccentric stud -----	

^a On teletypewriters with lubricating felt washers installed, lubricate the associated felt washer to the point of saturation only.




- | | |
|---|---|
| 1 Stop bar shift blade | 14 Keyboard transmitter friction clutch |
| 2 Carriage-feed friction clutch | 15 Decelerating cam |
| 3 Felt washer (on function shaft) | 16 Carriage-return driving and driven gears |
| 4 Square shaft | 17 Carriage rack drive shaft bearing |
| 5 Carriage-feed pawl and ratchet wheel | 18 Carriage-return clutch latch lever |
| 6 Felt washer (on horizontal carriage-return link) | 19 Carriage-feed clutch lever |
| 7 Carriage-return operating mechanism | 20 Felt washer (next to carriage-feed driving gear) |
| 8 Manual carriage-return mechanism | 21 Margin bell clapper and pawl |
| 9 Felt washers (on square shaft and print bail blade shaft) | 22 Carriage-feed clutch |
| 10 Square shaft bearings | 23 Carriage-feed sliding clutch drum |
| 11 Platen frame pivot bearings | 24 Platen lowercase latch |
| 12 Carriage-return sliding clutch drum | 25 Code-ring locking bail shaft |
| 13 Carriage-return safety clutch plates | 26 Function bellcrank pivots |
| | 27 Function sensing levers |

Figure 157. Carriage and platen of page printing mechanism removed to show lubrication points. (Superseded)



- | | |
|---|--|
| 1 Paper guide link | 10 Motor stop actuating lever and signal bell clapper pivots |
| 2 Paper guide link | 11 Main shaft driving worm (inside cover) |
| 3 Function selecting arm | 12 Function cam follower |
| 4 Stop bar shift lever | 13 Felt washer (on carriage-feed link) |
| 5 Felt washer (on function selecting arm bearing) | 14 Unshift and carriage-feed levers |
| 6 Printing bail blade shaft bearings | 15 Support lever |
| 7 Felt washer (stop bar shift lever pivot) | 16 Function punch bars |
| 8 Stop bar shift link | 17 Platen latch |
| 9 Paper roller latch | 18 Aperture gate |


Figure 158. Page printing mechanism, side view, showing lubrication points. (Superseded)



TM5815-200-35-C2-9

- | | | | |
|----|---|----|--|
| 1 | Printing bail blade and felt washers | 16 | Line feed and figures cam followers |
| 2 | Carriage rack driving gear | 17 | Line feed, figures, and carriage-return sensing lever restoring cams |
| 3 | Clutch spring | 18 | Selector friction clutch |
| 4 | Felt washer (on the function shaft sliding clutch drum) | 19 | Square shaft driving friction clutch |
| 5 | Function shaft driven gear ratchet teeth | 20 | Transfer lever shaft bearings |
| 6 | Function shaft driven gear teeth | 21 | Function shaft driving gear |
| 7 | Felt washer (on function shaft driven gear) | 22 | Felt washer (next to carriage-feed driven gear) |
| 8 | Square shaft driving gear | 23 | Carriage-feed worm gear |
| 9 | Delaying lever | 24 | Clutch latch |
| 10 | Line feed and figures shift connecting links | 25 | Carriage-return blocking mechanism |
| 11 | Line feed and figures bellcrank pivots | 26 | Carriage-return shaft drive gears |
| 12 | Line feed and figures cam follower pivots | 27 | Transmitter shaft drive gears |
| 13 | Delaying latch | 28 | Print cam follower |
| 14 | Code-ring cage | 29 | Felt washers (function shaft, on each side of bearing blocks) |
| 15 | Code rings | | |

Figure 159. Page printing mechanism, rear view, showing lubrication points. (Superseded)



- | | |
|---|--|
| <ul style="list-style-type: none"> 1 Stop bars in code ring 2 Platen eccentric pivot 3 Code-ring locking shaft 4 Detent wheel 5 Single-double line feed lever 6 T-levers 7 Code-ring locking bail latching surface 8 T-levers and separating washers 9 Y-lever and Y-lever detent separating washers 10 Selector lever guide comb 11 Selector magnet armature knife edge | <ul style="list-style-type: none"> 12 Selector levers, pivot bearings and separating washers 13 Orientation lever pivot and ranging cam 14 Grooved pin in end of selector camshaft 15 Selector cams and stop plate 16 Transfer lever latch 17 Felt washer (on pivot post) 18 Transfer lever restoring cam 19 Transfer lever roller 20 Antibounce clutch 21 Felt washer (on stop arm shaft) |
|---|--|

Figure 161. Page printing mechanism, selector side, showing lubrication points. (Superseded)

Page 161, paragraph 119, subparagraph *b*, chart, "Item No." column, line 6. Change "7" to: 9.

Subparagraph *d*, chart, "Name of part" column, line 15. Add: and separating washers^a.

In the "Method and quantity" column, add superscript "a" at the end of lines 4, 5, and 12.

Page 162, paragraph 119*d*, chart, "Method and quantity" column. Add a reference footnote "a" at the end of lines 1, 6, 7, 11, 14, 21, 22, 29, 35, 36, 37, 44, 45, 54, and 55.

Page 163, paragraph 119d. Delete that portion of the chart which relates to figures 176 and 181 and substitute the following:

Fig. No.	Item No.	Name of part	Method and quantity
176	1	Sliding drum clutch (on receiving multi-solenoid function shaft).	2 drops in hole on drum ^a .
176	2	Reciprocating and restoring cam follower.	Apply sparingly to roller pivots, and all rubbing surfaces.
176	3	Stop arm shaft support plate-----	1 drop each side of collar ^a .
176	4	Latch lever pivot-----	2 drops of oil on pivot ^a .
176	5	Clutch release lever-----	Slight film of oil on all bearing surfaces.
176	6	Transfer lever shaft bearings-----	1 drop between collars and bearings on transfer lever shaft ^a .
176	7	Clutch latch -----	2 drops on pivot; thin film on latching surface.
176	8	Transfer lever shaft bearings-----	1 drop between collars and bearings on transfer lever shaft ^a .
181	1	Clutch magnet armature-----	1 or 2 drops at pivot and working ends.
181	2	Sensing lever comb-----	1 or 2 drops in each comb slot.
181	3	Felt washer (on sensing lever springs)---	Saturate.
181	4	Tape feed retracting lever-----	1 or 2 drops at pivot and working ends.
181	5	Code sensing levers-----	Apply sparingly at working surfaces and at pivot.
181	6	Start-stop lever -----	1 or 2 drops at pivot and working points ^a .
181	7	Tape feed lever-----	1 or 2 drops at pivot and working points ^a .
181	8	Transmitter-distributor camshaft-----	Thin film on all cam lobes and stop lever cam teeth.
181	9	Selector levers, bearing shoes, and flat washers.	Apply sparingly to all rubbing and bearing surfaces ^a .
181	10	Transmitter contact bail pivot-----	2 or 3 drops between arm and pivot studs ^a .
181.1	1	Felt washer (on detent lever-stud)-----	Saturate.


After the last entry to figure 183. Add:

Fig. No.	Item No.	Name of part	Method and quantity
183.1	1	Arm pivot stud-----	1 drop at each working point of stud ^a .
	2	Arm roller -----	1 or 2 drops on roller.
183.2	1	Register arm -----	2 drops of oil at pivot point and working end ^a .

In the "Method and quantity" column, line 16 and "Name of part" column, lines 28, 31, and 33, add a reference to footnote "a" at the end of the line.

Add the following footnote below the chart:

^a On teletypewriter with lubricating felt washers installed, lubricate the associated felt washer to the point of saturation only.



- | | |
|---|---------------------------------|
| 1 Sliding drum clutch (on receiving multisolenoid function shaft) | 5 Clutch release lever |
| 2 Reciprocating and restoring cam follower | 6 Transfer lever shaft bearings |
| 3 Stop arm shaft support plate | 7 Clutch latch |
| 4 Latch lever pivot | 8 Transfer lever shaft bearings |
| | 9 Motor driven gear set |

Figure 176. Perforator main chassis, rear view, showing lubrication points. (Superseded)




Figure 181. Transmitter-distributor, right side view, showing lubrication points. (Superseded)

- | | |
|--|---|
| 1 Clutch magnet armature | 6 Start-stop lever |
| 2 Sensing lever comb | 7 Tape feed lever |
| 3 Felt washer (sensing levers springs) | 8 Transmitter-distributor camshaft |
| 4 Tape feed retracting lever | 9 Selector levers, bearing shoes and flat washers |
| 5 Code sensing lever | 10 Transmitter contact bail pivot |

Figure 181—Continued.





Figure 181.1. Transmitter-distributor, partial right side view, showing lubrication point (TT-270/FG and TT-272/FG). (Added)



- | | |
|---------------------------|---------------------------|
| 1 Tape-out lever | 4 Lower switch bail lever |
| 2 Tape feed claw | 5 Tight-tape lever |
| 3 Start-stop lever detent | 6 Upper switch bail lever |

Figure 182. Transmitter-distributor, left side view, showing lubrication points. (Superseded)




Figure 183.1. Tape puller, lubrication points. (Added)

Page 184. Add the following note to figure 185:

Note. Later models of the equipment include two felt washers 61477. One appears between items 23 and 24 and the other between items 22 and 26.

Page 194, paragraph 137, subparagraph a(3). After the last sentence add: Catch the felt washer (51), when supplied, as it is released by the stud.

Subparagraph a(6). After the last sentence add: Remove the felt washer (52), when supplied, from the selector lever pivot post.

Page 196, figure 191, legend, item 2. Add: (56561A on TT-117A/FG, TT-118/FG, TT-119A/FG, TT-269/FG and TT-271/FG).

Item 3. Add: (61318A on TT-269/FG and TT-271/FG).

Page 200, paragraph 140a, subparagraph (8). After the second sentence add: Catch the three felt washers (36), when supplied, as they fall free of the locking lever latch stud.

Subparagraph (12). After "(19)" add: and felt washer (18), when supplied.






Figure 183.2. Code actuated switch frame, lubrication point. (Added)



TM2246-C7-16

- | | | | |
|----|--|----|--------------------------------------|
| 1 | Setscrew, 10210 | 26 | Selector lever |
| 2 | Sensing lever pivot stud, 51562 | 27 | Bearing shoe |
| 3 | Flat washer, 53526 | 28 | Flat washer, 50147 |
| 4 | Flat washer, 51047 | 29 | Selector lever |
| 5 | Sensing lever, 51573A (includes items 7, 9, 11, and 13) | 30 | Bearing shoe |
| 6 | Flat washer, 50147 | 31 | Flat washer, 50147 |
| 7 | Sensing lever | 32 | Selector lever |
| 8 | Flat washer, 50147 | 33 | Bearing shoe |
| 9 | Sensing lever | 34 | Flat washer, 50147 |
| 10 | Flat washer, 50147 | 35 | Selector lever |
| 11 | Sensing lever | 36 | Bearing shoe |
| 12 | Flat washer, 50147 | 37 | Flat washer, 50147 |
| 13 | Sensing lever | 38 | Flat washer, 56252 |
| 14 | Selector lever spring, 50902 | 39 | Setscrew, 10210 |
| 15 | Sensing lever locking bail spring, 51575 | 40 | Selector lever pivot post, 54673 |
| 16 | Self-locking hexagonal nut, 10500 | 41 | Machine screw, 10003 |
| 17 | Sensing lever locking bail bearing, 51557 | 42 | Lockwasher, 10429 |
| 18 | Sensing lever locking bail, 51567 | 43 | Selector lever spring bracket, 54672 |
| 19 | Spacing collar, 51555 | 44 | Screw, 10008 |
| 20 | Selector lever, 51598A (includes items 23, 26, 29, 32, and 35) | 45 | Lockwasher, 10430 |
| 21 | Bearing shoe, 50019A (includes items 24, 27, 30, 33, and 36) | 46 | Adjusting plate, 55869 |
| 22 | Flat washer, 50147 | 47 | Screw, 10002 |
| 23 | Selector lever | 48 | Lockwasher, 10429 |
| 24 | Bearing shoe | 49 | Stop selector lever latch, 55870 |
| 25 | Flat washer, 50147 | 50 | Selector levers comb, 51558 |
| | | 51 | Felt washer, 61466 |
| | | 52 | Felt washer, 61467 |

Figure 190. Keyboard transmitter sensing and selector levers, exploded view. (Superseded)




TM2246-C7-17

- | | | | |
|----|---|----|--|
| 1 | Locking lever latch spring, 51544 | 19 | Cam stop lever, 54686A |
| 2 | Setscrew, 10210 | 20 | Repeat lever pivot stud, 51568 |
| 3 | Repeat blocking lever spring, 50944 | 21 | Flat washer, 50414 |
| 4 | Retainer ring, 10949 | 22 | Repeat lever, 52914 |
| 5 | Locking lever latch stud, 51564 | 23 | Clamping screw, 10003 |
| 6 | Repeat blocking lever, 51569 (59477) ^a | 24 | Lockwasher, 10421 |
| 7 | Plain hexagonal nut, 10507 | 25 | Clamping screw, 10003 |
| 8 | Universal bar adjusting screw, 50658 | 26 | Lockwasher, 10421 |
| 9 | Locking lever latch, 51570A (59475A) ^a | 27 | Switch arm shaft, 10919 |
| 10 | Self-locking hexagonal nut, 10500 | 28 | Washer, 56598 |
| 11 | Stop latch cam follower, 55562 | 29 | Switch cam follower, 56566A |
| 12 | Cam stop lever spring, 51575 | 30 | Washer, 56598 |
| 13 | Clamping screw, 10006 | 31 | Switch arm, 56568A |
| 14 | Clamp nut, 50174 | 32 | Spacer, 52988 |
| 15 | Flat washer, 10459 | 33 | Plain hexagonal nut (10507) ^a |
| 16 | Switch cam lever, 56564 | 34 | Flat washer (10409) ^a |
| 17 | Lockwasher, 10409 | 35 | Repeat blocking lever adjusting screw (10233) ^a |
| 18 | Felt washer, 61482 | 36 | Felt washer, 61468 |

^a Reference designations in parentheses are applicable to models equipped with an adjustable repeat blocking latch.

Figure 193. Transmitter camshaft locking mechanism, exploded view. (Superseded)



TM 2246-C7-18

- | | | | |
|----|--|----|--------------------------------------|
| 1 | Machine screw, 10032 | 18 | Switch arm spacer, 55878 |
| 2 | Lockwasher, 10430 | 19 | Switch arm, 55894 |
| 3 | Keyboard switch cover, 55889 | 20 | Switch arm spacer, 55878 |
| 4 | Shunt switch arm connector, 55885A | 21 | Switch arm, 55894 |
| 5 | Socket mounting stud, 55898 | 22 | Switch arm spacer, 55878 |
| 6 | Flat washer, 10467 | 23 | Switch arm, 55894 |
| 7 | Lockwasher, 10430 | 24 | Switch arm spacer, 55878 |
| 8 | Machine screw, 10004 | 25 | Switch arm, 55894 |
| 9 | Lockwasher, 10429 | 26 | Switch arm spacer, 55878 |
| 10 | Shunt switch arm spring | 27 | Switch arm, 55894 |
| 11 | Shunt switch arm | 28 | Switch arm centering sleeve, 55895 |
| 12 | Shunt switch arm spring mounting bracket, 55903A
(includes items 10 and 11) | 29 | Self-locking hexagonal nut, 10500 |
| 13 | Shunt switch arm comb, 55855 | 30 | Machine screw, 10001 |
| 14 | Setscrew, 10210 | 31 | Tabulator lever adjusting arm, 55901 |
| 15 | Switch arm mounting post pivot, 55828 | 32 | Tabulator lever, 55900A |
| 16 | Retainer ring, 10959 | 33 | Felt washer, 61478 |
| 17 | Flat washer, 50552 | 34 | Felt washer, 61478 |


Figure 194. Simultaneous transmitter mechanism, exploded view. (Superseded)

Page 203, paragraph 141a(9), line 3. After "remove" add: the felt washers (33 and 34), when supplied, and

Page 205, figure 195 legend, item 25. After "55910A" add: (61698A, TT-269/FG and TT-271/FG).

Page 211, figure 199 legend, item 5. Add:
(61745A on TT-269/FG and TT-271/FG).

Item 8. Add: (61744 on TT-269/FG and
TT-271/FG).



- | | |
|---|---|
| 1 Machine screw, 10024 | 27 Retainer ring, 51099 |
| 2 Flat washer, 10464 | 28 Platen pressure roller shaft, 54968 |
| 3 Lockwasher, 10431 | 29 Platen pressure roller, 50161A |
| 4 Retainer ring, 10949 | 30 Platen pressure roller operating shaft, 55530A |
| 5 Retainer ring, 10949 | 31 Paper guide spring, 52169 |
| 6 Connecting link, 50215 | 32 Pivot screw, 55139 |
| 7 Platen lever latch spring, 53149 | 33 Setscrew, 10201 |
| 8 Platen lever latch, 54951 | 34 Setscrew, 10201 |
| 9 Retainer ring, 10949 | 35 Retainer ring, 10949 |
| 10 Retainer ring, 10949 | 36 Stripper spring, 55143 |
| 11 Connecting link, 50215 | 37 Paper guide shaft, 55152 (59820 ^a) |
| 12 Bracket link, 53138A | 38 Paper guide, 55144A (57016A, TT-118/FG only) |
| 13 Platen spacing detent spring, 51851 | 39 Sleeve, 55041 |
| 14 Flat washer, 51768 | 40 Paper stripper, 55151 |
| 15 Platen spacing detent, 53202A | 41 Paper stripper, 55151 |
| 16 Flat washer, 51768 | 42 Paper guide, 55141A (57077A, TT-118/FG only) |
| 17 Platen detent spring, 51851 | 43 Hinge pin, 55146 |
| 18 Retainer ring, 10960 | 44 Platen trough spring, 54967 |
| 19 Line spacing detent, 50108A | 45 Paper trough guide, 54962 |
| 20 Plain round nut, 10537 | 46 Platen trough, 55136A |
| 21 Lockwasher, 10429 | 47 Paper guide adjusting lever, 60084A ^a |
| 22 Platen detent eccentric stud, 52931 | 48 Lockwasher, 10421 ^a |
| 23 Setscrew, 10201 | 49 Screw, 10106 ^a |
| 24 Pressure roller lever, 54954A | 50 Felt washer, 61472 |
| 25 Pressure roller operating shaft screw, 50238 | 51 Felt washer, 61474 |
| 26 Retainer ring, 51099 | |

^a Additional reference designations used with all equipment except TT-117/FG and TT-119/FG.

Figure 202. Platen trough assembly, exploded view. (Superseded)

Page 218, paragraph 152a. After subparagraph (6) add:


- (6.1) Remove the retainer ring (33) that holds the platen shift link (29, fig. 219) to the stud on the platen shift arm (19, fig. 203).

Subparagraph (10), line 4. After "(23)" add: felt washer (31), when supplied. Line 5. After "(25)" add: flat washer (34).

Subparagraph (12), line 3. After "(28)" insert: and felt washer (32), when supplied.

Paragraph 153a. After subparagraph (1) add:

- (1.1) Remove the felt washer (50), when supplied, from the hub of the platen shaft-bearing on the platen trough (46).



TM 2246-C7-20

Figure 203. Platen frame assembly, exploded view. (Superseded)

Page 220, paragraph 153a(8). After the sentence add: Remove the felt washer (51), when supplied.

Page 225. Add the following note to figure 207:

Note. Later models of the equipment include a felt lubrication washer, 61476, between items 3 and 12.

Page 229, paragraph 161b(1), chart. Delete the chart and substitute the following:

Type bar and connecting bar sequence chart				
No. stamped in bar	Connecting bar ref. No.	Type bar ref No. (standard)	Type bar ref No. (weather)	Type bar symbol (LTRS)
1	50022	62211	62237	Z
2	50023	62212	62238	J
3	50024	62213	62213	X
4	50025	62214	62239	V
5	50026	62215	62240	B
6	50027	62216	62241	C
7	50028	62217	62217	P
8	50029	62218	62218	M
9	50030	62219	62242	F
10	50031	62220	62220	R
11	50032	62221	62221	O
12	50033	62222	62222	I

Type bar and connecting bar sequence chart				
No. stamped in bar	Connecting bar ref. No.	Type bar ref No. (standard)	Type bar ref No. (weather)	Type bar symbol (LTRS)
13	50034	62223	62223	T
14	50035	62224	62224	E
15	50036	62225	62243	A
16	50037	62261	62261	S
17	50038	62260	62244	H
18	50039	62228	62245	N
19	50040	62229	62246	L
20	50041	62230	62247	D
21	50042	62231	62231	U
22	50043	62232	62248	G
23	50044	62233	62233	Y
24	50045	62234	62234	W
25	50046	62235	62249	K
26	50047	62236	62236	Q
27	50048	None	62250	None

Page 233, figure 212 legend, item 18. Change "20513" to 20514.

Page 235, figure 213, legend, item 7. Change "10307" to: 10090.

Add the following note:

Note. Later models of the equipment include a felt lubrication washer, 61480, between items 10 and 11.

- | | | | |
|----|------------------------------------|----|---------------------------------------|
| 1 | Setscrew, 10211 | 18 | Lockwasher, 10431 |
| 2 | Plain hexagonal nut, 10524 | 19 | Platen shift arm, 53134A |
| 3 | Spacing collar, 55174 | 20 | Setscrew, 10209 |
| 4 | Eccentric pivot, 55173 | 21 | Setscrew, 10209 |
| 5 | Machine screw, 10015 | 22 | Platen shaft, 54955 |
| 6 | Lockwasher, 10431 | 23 | Single-double line feed lever, 51762A |
| 7 | Platen latching arm, 50214 | 24 | Detent wheel, 52807 |
| 8 | Platen locking stud, 50762 | 25 | Shaft collar, 50209 |
| 9 | Retainer ring, 10969 | 26 | Line feed pawl spring, 50333 |
| 10 | Self-locking hexagonal nut, 10501 | 27 | Retainer ring, 10969 |
| 11 | Machine screw, 10008 | 28 | Line feed pawl, 50165 |
| 12 | Flat washer, 10467 | 29 | Line feed lever, 53137A |
| 13 | Platen blocking arm, 53095A | 30 | Platen support frame, 53305A |
| 14 | Machine screw, 10008 | 31 | Felt washer, 61471 |
| 15 | Lockwasher, 10430 | 32 | Felt washer, 61473 |
| 16 | Platen blocking arm bracket, 52307 | 33 | Retainer ring, 10949 |
| 17 | Machine screw, 10005 | 34 | Felt washer, 61473 |

Figure 203—Continued.



TM 2246-C7-21

Figure 214. Selector and Y-levers, exploded view. (Superseded)


Page 237, paragraph 165a, subparagraph (5), line 3. After "(52)" add: Remove the felt washer (55), when supplied. Line 6. After "alternately" add: felt washer (56), when supplied.

Subparagraph (7), line 4. After "(35)" add: felt washer (57), when supplied.

Page 238, paragraph 166a(3). After the last sentence add: Remove the felt washer (43), when supplied, from the T-lever pivot stud.

-
- | | | | |
|----|---|----|--|
| 1 | Selector lever spring, 50902 (5 reqd) | 29 | Flat washer, 50148 |
| 2 | Anchor post, 50325 | 30 | Y-lever |
| 3 | Plain hexagonal nut, 10509 | 31 | Collar, 51416 |
| 4 | Y-lever detent spring, 55009 (5 reqd) | 32 | Selector lever, 51068A (consists of set of 5) |
| 5 | Plain hexagonal nut, 10504 | 33 | Self-locking hexagonal nut, 10513 |
| 6 | Lockwasher, 10434 | 34 | Eccentric bearing, 51046 |
| 7 | Centering sleeve, 55007 | 35 | Stop lever 53613 (62020A on TT-269/FG and TT-271/FG) |
| 8 | Thrust washer, 55001 (consists of set of 5, items 8, 10, 12, 14, and 16) | 36 | Flat washer, 50053 |
| 9 | Y-lever detent, 55004 (consists of set of 5, items 9, 11, 13, 15, and 18) | 37 | Bearing, 50019A (consists of set of 5, items 37, 39, 41, 43, and 45) |
| 10 | Thrust washer | 38 | Flat washer, 50147 |
| 11 | Y-lever detent | 39 | Bearing |
| 12 | Thrust washer | 40 | Flat washer, 50147 |
| 13 | Y-lever detent | 41 | Bearing |
| 14 | Thrust washer | 42 | Flat washer, 50147 |
| 15 | Y-lever detent | 43 | Bearing |
| 16 | Thrust washer | 44 | Flat washer, 50147 |
| 17 | Flat washer, 55076 | 45 | Bearing |
| 18 | Y-lever detent | 46 | Collar, 51416 |
| 19 | Setscrew, 10209 | 47 | Y-lever detent pivot, 55008 |
| 20 | Spacing collar, 55006 | 48 | Y-lever detent spring bracket, 55002 |
| 21 | Flat washer, 50148 | 49 | Setscrew, 10211 |
| 22 | Y-lever, 53540A (consists of set of 5, items 22, 24, 26, 28, and 30) | 50 | Selector lever pivot stud, 53268 |
| 23 | Flat washer, 50148 | 51 | Setscrew, 10247 |
| 24 | Y-lever | 52 | Y-lever pivot stud, 53269 |
| 25 | Flat washer, 50148 | 53 | Setscrew, 10211 |
| 26 | Y-lever | 54 | Y-lever eccentric stop, 50152 |
| 27 | Flat washer, 50148 | 55 | Felt washer, 61478 |
| 28 | Y-lever | 56 | Felt washer, 61469 |
| | | 57 | Felt washer, 61479 |

Figure 214—Continued.



TM 2246-C7-22

- | | | | |
|----|--|----|---|
| 1 | Transfer lever spring, 50903 | 25 | Machine screw, 10010 |
| 2 | Self-locking hexagonal nut, 10500 | 26 | Shaft collar, 53973 |
| 3 | Flat washer, 50414 | 27 | Shaft collar, 53973 |
| 4 | T-lever, 56766A (includes items 4, 6, 8, 10, and 12) | 28 | Spring stud, 50649 |
| 5 | Flat washer, 50148 | 29 | Self-locking hexagonal nut, 10501 |
| 6 | T-lever | 30 | Transfer lever roller stud, 56185A |
| 7 | Flat washer, 50148 | 31 | Taper pin |
| 8 | T-lever | 32 | Transfer lever assembly 52394A (includes items 31 and 33) |
| 9 | Flat washer, 50148 | 33 | Transfer lever shaft |
| 10 | T-lever | 34 | Spring, 50904 |
| 11 | Flat washer, 50148 | 35 | Retainer ring, 10949 |
| 12 | T-lever | 36 | Transfer lever latch, 50020A |
| 13 | Plain hexagonal nut, 50651 | 37 | Transfer lever latch stud, 52319 |
| 14 | Lockwasher, 10404 | 38 | Machine screw, 10003 |
| 15 | T-lever pivot stud, 50650 | 39 | Flat washer, 50839 |
| 16 | Machine screw, 10008 | 40 | Lockwasher, 10429 |
| 17 | Plain hexagonal nut, 10504 | 41 | Spring post eccentric, 56076 |
| 18 | Lockwasher, 10434 | 42 | Shim: 0.002-in., 57072; 0.003-in., 57073 |
| 19 | Machine screw, 10000 | 43 | Felt washer, 61480 |
| 20 | Ball bearing, 10754 | 44 | Felt washer, 61488 |
| 21 | Clutch latch, 50535 | 45 | Felt washer, 61489 |
| 22 | Machine screw, 10010 | 46 | Felt washer, 61467 |
| 23 | Shaft collar, 53973 | | |
| 24 | Machine screw, 10010 | | |

Figure 215. Transfer lever shaft, exploded view. (Superseded)

Page 239, paragraph 166a, subparagraph (9). After the last sentence add: Catch the felt washers (44 and 45), when supplied, as they fall free of the shaft.

Subparagraph (13). After the last sentence add: Remove the three felt washers (46), when supplied.

Delete paragraph 167 and substitute:

167. Disassembly and Reassembly of Printer Bail Blade Shaft (fig. 216)


a. Disassembly.

- (1) Remove the page printer from the printer base (par. 128a).
- (2) Remove the transfer lever shaft (par. 166a).
- (3) Remove the two setscrews (41, fig. 221) that hold the print cam (42) to the function shaft (46); slide the print cam to the selector side of the page printer. Be careful not to lose the bushing (7, fig. 216) on the cam follower stud.
- (4) Unhook the print cam follower spring (1) from the print cam follower (4) and from the spring post on the printer frame.
- (5) Remove the two screws and lockwashers that hold the middle bearing cap to the frame assembly; remove the middle bearing cap by sliding it toward the selector side of the page printer.
- (6) Remove the print bail blade shaft (2), print bail blade (3), and print cam follower (4) by moving the shaft toward the selector side of the page printer, free of the bearing. Remove the felt washers (5 and 6), when supplied, from the print bail blade shaft.
- (7) Remove the bushing (7), locknut (8), and stud (9) from the print cam follower.
- (8) Remove the machine screw (10), plain washer (11), and nut (12) that hold the print cam follower (4) to the print bail blade shaft and remove the print cam follower.

- (9) Remove the two felt washers (13), when supplied, from the print bail blade shaft.
- (10) Remove the three machine screws (14), lockwashers (15), and washers (16) that hold the print bail blade to the print bail blade shaft and remove the blade.

b. Reassembly.

- (1) Position the print bail blade (3) on the print bail blade shaft (2). Fasten it with the three machine screws (14), lockwashers (15), and washers (16).
- (2) Install the two felt washers (13), when supplied, and print cam follower (4) on the print bail blade shaft (2); secure with a machine screw (10), plain washers (11), and nut (12).
- (3) Position the stud (9) on the print cam follower (4) and secure it with a locknut (8). Install the bushing (7) on the stud.
- (4) Install the felt washers (5 and 6), when supplied, on the print bail blade shaft.
- (5) Install the end of the shaft with the cam follower on it in the bushing in the function side of the page printer frame.
- (6) Position the bearing cap on the opposite end of the print bail blade shaft; secure the bearing cap to the frame with two screws and lockwashers.
- (7) Attach the print cam follower spring (1) to the print cam follower (4) and the spring post on the page printer frame.
- (8) Slide the print cam to engage the print cam follower; secure the cam to the function shaft with two setscrews.
- (9) Install the transfer lever shaft (par. 166b).
- (10) Adjust the print bail blade shaft (pars. 344 and 345).
- (11) Replace the page printer on the printer base (par. 128b).



TM2246-C7-23

- | | | | |
|---|----------------------------------|----|----------------------|
| 1 | Print cam follower spring, 50921 | 9 | Stud, 50886 |
| 2 | Print bail blade shaft, 50534 | 10 | Machine screw, 10006 |
| 3 | Print bail blade, 50533 | 11 | Plain washer, 10459 |
| 4 | Print cam follower, 50948 | 12 | Nut, 50174 |
| 5 | Felt washer, 61482 | 13 | Felt washer, 61481 |
| 6 | Felt washer, 61480 | 14 | Machine screw, 10004 |
| 7 | Bushing, 50843 | 15 | Lockwasher, 10429 |
| 8 | Locknut, 10501 | 16 | Washer, 10450 |


Figure 216. Print bail blade shaft assembly, exploded view. (Superseded)

Page 241, paragraph 169a, subparagraph (5). After the sentence add: Remove the felt washer (39), when supplied, from the platen latch pivot post.

Subparagraph (7). After the sentence add: Catch the two felt washers (40), when supplied, as they fall from the support lever.

Subparagraph (9). After the sentence add: Catch the two felt washers (41), when supplied, as they fall from the function cam follower pivot stud.

Delete subparagraph (11) and substitute:
 (11) Remove the two setscrews (19) that hold the shaft collar (21) to the pivot (20); remove the pivot. Catch the felt washer (42), when supplied, shaft collar, carriage-feed lever (22), spacer (23), unshift lever (24), and three felt washers (43), when supplied, as they fall from the pivot. Remove the felt washer (44), when supplied, from the pivot post on the carriage-feed lever.



TM2246-C7-24

- | | |
|--|---|
| 1 Self-locking hexagonal nut, 10501 | 24 Unshift lever, 52445 |
| 2 Mounting bracket stud, 55501 | 25 Function bracket, 52543A |
| 3 Lockwasher, 10431 | 26 Machine screw, 10004 |
| 4 Mounting bracket stud, 55502 | 27 Lockwasher, 10403 |
| 5 Lockwasher, 10431 | 28 Machine screw, 10304 |
| 6 Retainer ring, 10960 | 29 Lockwasher, 10429 |
| 7 Platen latch spring, 52501 | 30 Side plate, 50735 |
| 8 Retainer ring, 10949 | 31 Aperture gate, 50743A |
| 9 Platen latch, 50821 | 32 Signal bell punch bar, 50881 |
| 10 Supporting lever spring, 50915 | 33 Motor stop punch bar, 50755 ^a |
| 11 Retainer ring, 10949 | 34 Punch bar guide block, 51428 |
| 12 Pin, 53131 | 35 Machine screw, 51568 |
| 13 Cam follower roller, 50843 | 36 Blank punch bar torsion spring, 53649 (TT-118/FG only) |
| 14 Retainer ring, 10949 | 37 Blank punch bar, 53648 (TT-118/FG only) |
| 15 Function cam follower, 50822A | 38 Letters punch bar, 50755 (.625 inch in overall length) |
| 16 Self-locking hexagonal nut, 10501 | 39 Felt washer, 61492 |
| 17 Function cam follower pivot stud, 52553 | 40 Felt washer, 61475 |
| 18 Support lever, 50760 | 41 Felt washer, 61475 |
| 19 Setscrew, 10203 | 42 Felt washer, 61475 |
| 20 Pivot, 50829 | 43 Felt washer, 61475 |
| 21 Shaft collar, 50391 | 44 Felt washer, 61486 |
| 22 Carriage-feed lever, 53129A | |
| 23 Spacer, 51424 | |

^a On TT-118/FG, motor stop punch bar 53606 is used. This part is .687 inch in overall length.

Figure 218. Function mechanism, exploded view. (Superseded)

Page 243, paragraph 169b. Delete subparagraph (3) and substitute:

(3) Install the felt washer (44), when supplied, on the pivot post on the carriage-feed lever. Insert the pivot (20) in the drilled hole in the function bracket (25); install the unshift lever (24), three felt washers (43), when supplied, spacer (23), carriage-feed lever (22), shaft collar (21), and felt washer (42), when supplied, on the pivot. Insert the pivot all the way into the bracket and secure the shaft collar

to the pivot by installing the two setscrews (19).


Subparagraph (5), line 2. After "(15)" add: and two felt washers (41), when supplied.

Subparagraph (7), line 2. After "(18)" add: and two felt washers (40), when supplied.

Subparagraph (9), line 1. After "Position" add: the felt washer (39), when supplied, and

Page 244, paragraph 170a, subparagraph (2). After the sentence add: Remove the felt washer (38), when supplied.

Subparagraph (4), line 2. After "(5)" add: and felt washer (39), when supplied.



TM5815-200-35-C2-16

- | | |
|---|--|
| 1 Retainer ring, 10949 | 22 Connecting link, 51771 |
| 2 Delaying lever, 52960A | 23 Connecting link, 50474 |
| 3 Delaying latch spring, 50916 | 24 Line feed bellcrank, 53136A |
| 4 Retainer ring, 10960 | 25 Platen shift bellcrank spring, 51645 |
| 5 Delaying latch, 52963 | 26 Retainer ring, 10949 |
| 6 Machine screw, 10003 | 27 Platen shift cam follower, 51712A |
| 7 Lockwasher, 10429 | 28 Retainer ring, 10949 |
| 8 Flat washer, 10450 | 29 Platen shift link, 56676A |
| 9 Stop bar shift link bracket, 55730A | 30 Platen shift bellcrank, 53135A |
| 10 Adjustable bellcrank spring, 51755 | 31 Carriage-return bellcrank spring, 50906 |
| 11 Line feed and figures shift cam follower spring, 50901 | 32 Platen lower case latch spring, 50920 |
| 12 Retainer ring, 10949 | 33 Retainer ring, 10960 |
| 13 Line feed cam follower, 51714A | 34 Platen lower case latch, 52748 |
| 14 Self-locking hexagonal nut, 10500 | 35 Machine screw, 10025 |
| 15 Machine screw, 10003 | 36 Lockwasher, 10430 |
| 16 Flat washer, 10450 | 37 Bellcrank pivot bracket, 52303A |
| 17 Adjustable bellcrank, 53462 | 38 Felt washer, 61483 |
| 18 Retainer ring, 10949 | 39 Felt washer, 61483 |
| 19 Machine screw, 10002 | 40 Felt washer, 61668 |
| 20 Flat washer, 10458 | 41 Felt washer, 61668 |
| 21 Lockwasher, 10429 | 42 Felt washer, 61474 |
| | 43 Felt washer, 61483 |

Figure 219. Line feed and platen shift mechanism, exploded view. (Superseded)

Page 245, paragraph 170a, subparagraph (12). After the sentence add: Remove the felt washer (40), when supplied, from the platen shift bellcrank.

After subparagraph (15) add:

(15.1) Remove the retainer ring (33, fig. 203) that holds the platen shift link (29, fig. 219) to the stud on the platen shift arm (19, fig. 203).


Subparagraph (16), line 1. Change "(28)" to: (28, fig. 219).

Subparagraph (17). After the sentence add: Remove the felt washer (41), when supplied, from the bellcrank pivot bracket.

Subparagraph (20). After the sentence add: Catch the felt washer (42), when supplied, as it falls from the pivot post on the bellcrank pivot bracket. Remove the felt washer (43), when supplied, from the pivot post on the bellcrank pivot bracket.

Paragraph 171a, subparagraph (3), line 3. After "(2)" add: and felt washer (14), when supplied.

Subparagraph (6), line 4. After "(12)" add: and felt washer (15), when supplied,



TM 2246-C7-25

- 1 Function selecting arm, 50936
- 2 Function selecting arm spring, 50917
- 3 Machine screw, 10009
- 4 Function selecting arm claw, 50841A
- 5 Spring retainer, 56277
- 6 Square shaft bearing spring, 56279
- 7 Spring retainer, 56277
- 8 Ball bearing, 10753

- 9 Spacing collar, 56278
- 10 Setscrew, 10209
- 11 Square shaft driven gear, 50383
- 12 Sliding helical gear, 50565A
- 13 Square shaft, 50456
- 14 Felt washer, 61487
- 15 Felt washer, 61484

Figure 220. Square shaft assembly, exploded view. (Superseded)




Figure 221. Function shaft, exploded view. (Superseded)

Page 247, paragraph 173a, subparagraph (7), line 4. After "(32)" add: felt washer (49), when supplied,

Subparagraph (8), line 3. After "(37)" add: and felt washer (50), when supplied.

-
- | | | | |
|----|---|----|--|
| 1 | Machine screw, 10011 | 27 | Friction adjusting collar, 56832A ^a |
| 2 | Lockwasher, 10404 | 28 | Setscrew, 10209 |
| 3 | Machine screw, 10012 | 29 | Driving collar, 54927 |
| 4 | Lockwasher, 10430 | 30 | Ball bearing, 10757 |
| 5 | Machine screw, 10011 | 31 | Retainer ring, 10959 |
| 6 | Lockwasher, 10430 | 32 | Flat washer, 50515 |
| 7 | Machine screw, 10014 | 33 | Function driven gear, 50512 |
| 8 | Lockwasher, 10404 | 34 | Flat washer, 51847 |
| 9 | Machine screw, 10003 | 35 | Flat washer, 50515 |
| 10 | Lockwasher, 10429 | 36 | Retainer ring, 10959 |
| 11 | Flat washer, 10458 | 37 | Function shaft sliding clutch drum, 50516 |
| 12 | Transfer lever restoring cam, 53878 | 38 | Clutch spring, 50848 |
| 13 | Flat washer, 53885 | 39 | Setscrew, 10209 |
| 14 | Locking bail cam, 53881 | 40 | Flexible coupling disk, 51167A |
| 15 | Flat washer, 53885 | 41 | Setscrew, 10209 |
| 16 | Flat washer, 51552 | 42 | Print cam, 50753A |
| 17 | Ball bearing, 10756 | 43 | Setscrew, 10209 |
| 18 | Flat washer, 50552 | 44 | Function cam, 50752 |
| 19 | Setscrew, 10208 | 45 | Sleeve bearing, 50852 |
| 20 | Line feed and platen shift sensing cam, 51612 | 46 | Function shaft, 55522 |
| 21 | Friction plate, 56764 | 47 | Setscrew, 10209 |
| 22 | Square shaft driving gear, 56274A | 48 | Pulsing cam, 53772 |
| 23 | Friction plate, 56764 | 49 | Felt washer, 61491 |
| 24 | Friction clutch plate, 54929 | 50 | Felt washer, 61496 |
| 25 | Clutch pressure spring, 54933 | 51 | Felt washer, 61490 |
| 26 | Clamping screw, 10043 | 52 | Felt washer, 61490 |

^a Teletypewriters TT-117A/FG, TT-118/FG, and TT-119A/FG.

Figure 221—Continued.

Page 249, paragraph 173a, subparagraph (11). After the sentence add: and the felt washer (51), when supplied.

Subparagraph (13), line 1. After "(45)" add: and the felt washer (52) when supplied,

Page 251, figure 223, legend, item 28. Add: (61316 on TT-269/FG and TT-271/FG).

Page 253, figure 224. Add the following note:

Note. Later models of the equipment include a felt lubrication washer, 61485, between items 4 and 5.

Legend, item 34. Change "52959" to: 53530A (includes item 35). Item 35. Delete "52961A." Item 36. Change "50503 (56179a)" to: 56179.

Page 254, paragraph 177a. After subparagraph (16). Add:

(17) On page printers equipped with a stop bracket (63), remove the two screws (60, fig. 232) and lockwashers (59) that hold the stop bracket (63) to the



TM5815-200-35-C2-17

Figure 225. Function sensing lever group, exploded view. (Superseded)

1	Retainer ring, 10960	14	Flat washer, 50384
2	Connector link, 53161A	15	Carriage-return sensing lever, 52659A
3	Retainer ring, 10960	16	Flat washer, 50384
4	Horizontal carriage-return link, 50864	17	Figure shift sensing lever spring, 51754
5	Retainer ring, 10960	18	Figure shift sensing lever, 52749
6	Retainer ring, 10960	19	Spacing collar, 50505
7	Vertical carriage-return link, 50483	20	Tolerance takeup flat washer, 51100
8	Retainer ring, 10948	21	Felt strip, 61677
9	Carriage-return bellcrank, 52121A	22	Felt washer, 61483
10	Carriage-return bellcrank pivot, 52552	23	Felt washer, 61483
11	Flat washer, 50374	24	Felt washer, 61673
12	Line feed sensing lever spring, 51754	25	Felt washer, 61672
13	Line feed sensing lever, 53106	26	Felt washer, 61497

Figure 225—Continued.

code-ring cage guide (39). Remove the stop bracket.

Page 255, paragraph 178a. Delete subparagraph (3) and substitute:

- (3) Remove the retainer ring (1) from the pivot stud on the connector link (2). Disengage one end of the felt washer (21), when supplied, from the horizontal carriage-return link (4). Remove the connector link from engagement with the double-blocking lever (12, fig. 231) and from the horizontal carriage-return link (4, fig. 225). Remove the felt washer (21), when supplied, from the horizontal carriage-return link.


Subparagraph (6). After the sentence add: Remove the four felt washers (22, 23, 24, and 25), when supplied.

Subparagraph (13), line 2. After "(19)" add: the two felt washers (26), when supplied,

Page 259, figure 228, legend, item 12. Change "59620A" to: 52953.

Page 260, paragraph 183a, subparagraph (5). After the sentence add: Remove the two felt washers (17), when supplied, from the space pawl mounting bracket pivot stud.

Subparagraph (7). After the sentence add: Remove the felt washer (18), when supplied, from the carriage-feed clutch lever pivot stud.



TM 2246-C7-27

- 1 Retainer ring, 10960
- 2 Connector link, 51783
- 3 Carriage-feed link, 55504
- 4 Carriage-feed pawl spring, 50912
- 5 Machine screw, 10025
- 6 Lockwasher, 10430
- 7 Self-locking hexagonal nut, 10500
- 8 Flat washer, 10450
- 9 Carriage-feed pawl, 54490A
- 10 Flat washer, 50827
- 11 Space pawl mounting bracket, 55788A
- 12 Carriage-feed clutch lever spring, 50911
- 13 Retainer ring, 10949
- 14 Carriage-feed clutch lever, 50005A
- 15 Setscrew, 10204
- 16 Stud, 52318
- 17 Felt washer, 61673
- 18 Felt washer, 61480

Figure 230. Carriage-feed mechanism, exploded view. (Superseded)


Page 261, paragraph 184, subparagraph a(1). After the sentence add: Remove the felt washer (23), when supplied.

Subparagraph a(2). After the last sentence add: Remove the felt washer (24), when supplied, from the hub of the double-blocking lever (12).

Subparagraph a(3). After the sentence add: Catch the two felt washers (25), when supplied, as they fall from the carriage-return clutch latch lever.

Subparagraph b, after subparagraph (3) add:

- (3.1) Position the two felt washers (25), when supplied, inside the carriage-return clutch latch lever (15).



TM 5815-200-35-C2-11

Figure 231. Carriage-return operating mechanism, exploded view. (Superseded)

Page 262, paragraph 184b(8). After the first sentence add: Install the felt washer (24), when supplied, on the hub of the double-blocking lever (12). After the last sentence add: Install the felt washer (23), when supplied, on the end of the carriage-return clutch lever (22).


Page 265, paragraph 187, subparagraph a(5). After the sentence add: Remove the felt washer (37), when supplied.

Subparagraph b. After subparagraph (3) add:

(3.1) Install the felt washer (37) on the carriage-feed shaft.

1	Machine screw, 10008	13	Double-blocking lever spring, 50946
2	Lockwasher, 10430	14	Retainer ring, 10949
3	Machine screw, 10006	15	Carriage-return clutch latch lever, 50011
4	Clamp nut, 50174	16	Clutch latch mounting plate, 53163A
5	Flat washer, 10459	17	Machine screw, 10009
6	Throwout lever, 56283	18	Carriage-return clutch actuating lever, 56241A
7	Carriage-return clutch actuating lever spring, 56258	19	Setscrew, 10209
8	Machine screw, 10003	20	Shaft collar, 50209
9	Flat washer, 10458	21	Spring, 52259
10	Lockwasher, 10429	22	Carriage-return clutch lever, 56243A
11	Adjusting plate, 56237	23	Felt washer, 61485
12	Double-blocking lever 56265A	24	Felt washer, 61667
		25	Felt washer, 61474

Figure 231—Continued.



TM5815-200-35-C2-12

- | | | | |
|----|---|----|---|
| 1 | Machine screw, 10017 | 20 | Setscrew, 10208 |
| 2 | Lockwasher, 10405 | 21 | Drive shaft collar, 54928 |
| 3 | Machine screw, 10003 | 22 | Friction clutch spring, 54934 |
| 4 | Flat washer, 10450 | 23 | Friction clutch plate, 54931 |
| 5 | Lockwasher, 10429 | 24 | Friction plate, 56765 |
| 6 | Ball bearing, 10755 | 25 | Clutch driving disk, 51117 |
| 7 | Machine screw, 10003 | 26 | Friction plate, 56765 |
| 8 | Flat washer, 10459 | 27 | Setscrew, 10209 |
| 9 | Lockwasher, 10429 | 28 | Ratchet wheel, 50201 (60479A, TT-118/FG) |
| 10 | Bearing retainer, 55020 | 29 | Carriage-feed driving gear, 50884A (60478A TT-118/FG) |
| 11 | Self-locking hexagonal nut, 10500 | 30 | Flat washer, 50887 |
| 12 | Ball bearing, 10755 | 31 | Carriage-feed sliding clutch drum, 50331 |
| 13 | Flat washer, 51408 | 32 | Setscrew, 10209 |
| 14 | Adjusting nut, 51079 | 33 | Shaft collar (59447 on TT-117A/FG, TT-118/FG, and TT-119A/FG) |
| 15 | Setscrew, 10209 | 34 | Carriage-feed shaft, 50525 |
| 16 | Shaft collar, 50209 | 35 | Felt washer, 61494 |
| 17 | Carriage-feed driven gear, 54930A | 36 | Felt washer, 61495 |
| 18 | Clamping screw, 10052 (10043 on TT-117A/FG, TT-118/FG, and TT-119A/FG) | 37 | Felt washer, 61678 |
| 19 | Adjusting collar, 54926 (56832A on TT-117A/FG, TT-118/FG, and TT-119A/FG) | | |

Figure 234. Carriage feed shaft, exploded view. (Superseded)

Page 271, figure 237, legend, item 24. Add: (61317 on TT-269/FG and TT-271/FG).

Page 277. Add paragraphs 196.1 and 196.2 after paragraph 196.

196.1. Removal and Replacement of Transmitter-Distributor Pulsing Control Box (AN/FGC-52 and AN/FGC-52X) (fig. 240.1)

a. Removal.

- (1) Remove the transmitter-distributor pulsing control box plug (18) from the jack in the perforator base.
- (2) Remove the transmitter-distributor plug from the jack J301 (44) in the transmitter-distributor pulsing control box.
- (3) Remove the five machine screws (1) and lockwashers (2) that hold the cover assembly (79) to the base (6); remove the cover assembly.
- (4) Remove the two machine screws (3), lockwashers (4), and flat washers (5) that hold the base (6) on the table.

b. Replacement.

- (1) Install the base (6) on the table with the mounting holes towards the front and secure with the two machine screws, lockwashers, and flat washers (a(4) above).
- (2) Replace the cover assembly (79) by reversing the procedures in a(1) through (3) above.

196.2. Disassembly and Reassembly of Transmitter-Distributor Pulsing Control Box (AN/FGC-52 and AN/FGC-52X) (fig. 240.1)


a. Disassembly.

- (1) Remove the transmitter-distributor pulsing control box (par. 196.1).
- (2) Remove the hexagonal nut (7), leads (8 and 9), machine screw (10), and lockwasher (11).
- (3) Remove the hexagonal nut (12), lead (13), and lockwasher (14) from the binding post (53).
- (4) Remove the hexagonal nut (15), lead (16), and lockwasher (17) from the binding post (58).
- (5) Remove the strain relief (19) from the front of the transmitter-distrib-

utor pulsing control box. Disconnect the wire leads of the cable assembly (20) and tag the leads to facilitate re-assembly. Remove the cable assembly.

- (6) Disconnect the wire leads of the harness (21) and remove the harness.
- (7) Disconnect the leads of filter FL301 (26). Remove the hexagonal nut (22), lockwasher (23), and machine screw (24). Remove the cable clamp (25) and filter (26).
- (8) Release the tube clamp (31) and remove the mercury relay (27).
- (9) Remove the hexagonal nut (28), lockwasher (29), and machine screw (30). Remove the tube clamp (31).
- (10) Remove two machine screws (32) and two lockwashers (33). Remove the socket (34).
- (11) Remove the hexagonal nut (35), lockwasher (36), flat washers (37 and 38), resistor R301 (39), flat washer (40), fiber washer (41), and machine screw (42).
- (12) Remove the hexagonal nut (43) and jack J301 (44).
- (13) Remove the hexagonal nuts (45 and 46). Remove resistor R302 (48) and the lockwasher (47).
- (14) Remove the hexagonal nut (49), flat washers (50 and 51), insulator (52), and binding post (53).
- (15) Remove the hexagonal nut (54), flat washers (55 and 56), insulator (57), and binding post (58).
- (16) Remove the hexagonal nut (59), lockwasher (60), flat washers (61 and 62), resistor R303 (63), flat washer (64), insulator (65) and machine screw (66).
- (17) Remove the hexagonal nut (67), lockwasher (68) and the CHARACTER PULSE toggle switch S302 (69). Remove the hexagonal nut (70).
- (18) Remove the plain hexagonal nut (71), lockwasher (72), and switch S301 (73). Remove the hexagonal nut (77).

b. Reassembly. Reassemble the transmitter-distributor pulsing control box as indicated in figure 240.1; the sequence for assembling the parts is the reverse of the disassembly sequence.



TM2246-C7-3


Figure 240.1. Transmitter-distributor pulsing control box, exploded view. (Added)

- | | | | |
|----|--|----|--|
| 1 | Machine screw, 10252 | 39 | Resistor (R301), 20071 |
| 2 | Lockwasher, 10404 | 40 | Flat washer, 57311 |
| 3 | Machine screw, 10011 | 41 | Fiber washer, 51481 |
| 4 | Lockwasher, 10404 | 42 | Machine screw, 10130 |
| 5 | Flat washer, 10454 | 43 | Hexagonal nut |
| 6 | Base, 61875A | 44 | Jack (J301), 20262 (includes item 43) |
| 7 | Hexagonal nut, 10515 | 45 | Hexagonal nut |
| 8 | Terminal lug, 20807 | 46 | Hexagonal nut, 10529 |
| 9 | Lead, 20838 | 47 | Lockwasher, 10419 |
| 10 | Machine screw, 10252 | 48 | Resistor (R302), 20023 (includes item 45) |
| 11 | Lockwasher, 10404 | 49 | Hexagonal nut, 10515 |
| 12 | Hexagonal nut, 10507 | 50 | Flatwasher, 10463 |
| 13 | Lead, 20838 | 51 | Flat washer, 50515 |
| 14 | Lockwasher, 10404 | 52 | Insulator, 50909 |
| 15 | Hexagonal nut, 10507 | 53 | Binding post, 20877 |
| 16 | Lead, 20355 | 54 | Hexagonal nut, 10515 |
| 17 | Lockwasher, 10404 | 55 | Flat washer, 10463 |
| 18 | Plug (P301), 20419 | 56 | Flat washer, 50515 |
| 19 | Strain relief, 20913 | 57 | Insulator, 50909 |
| 20 | Cable assembly (includes items 8 and 18), 62036A | 58 | Binding post, 20877 |
| 21 | Harness, 62035A | 59 | Hexagonal nut, 10515 |
| 22 | Hexagonal nut, 10517 | 60 | Lockwasher, 10430 |
| 23 | Lockwasher, 10432 | 61 | Flat washer, 10463 |
| 24 | Machine screw, 10375 | 62 | Flat washer, 57311 |
| 25 | Cable clamp, 20526 | 63 | Resistor R303, 20072 |
| 26 | Filter (FL301) | 64 | Flat washer, 57311 |
| 27 | Mercury relay, 20317 | 65 | Insulator, 51481 |
| 28 | Hexagonal nut, 10512 | 66 | Machine screw, 10130 |
| 29 | Lockwasher, 10415 | 67 | Hexagonal nut |
| 30 | Machine screw, 10357 | 68 | Lockwasher, 10414 |
| 31 | Tube clamp, 20543 | 69 | Toggle switch, 20121 (includes items 67, 68, and 70) |
| 32 | Machine screw, 10111 | 70 | Hexagonal nut |
| 33 | Lockwasher, 10429 | 71 | Hexagonal nut |
| 34 | Socket, 20275 | 72 | Lockwasher, 10414 |
| 35 | Hexagonal nut, 10515 | 73 | Toggle switch, 20117 (includes items 71, 72, and 74) |
| 36 | Lockwasher, 10430 | 74 | Hexagonal nut |
| 37 | Flat washer, 10463 | 75 | Cover Assembly, 62039A |
| 38 | Flat washer, 57311 | | |

Figure 240.1—Continued.

Paragraph 197a(1) and b(3). After "base" add: (or transmitter-distributor pulsing control box on the TT-270/FG and TT-272/FG).

Page 280, figure 242 legend, item 6. Add: (59711 on TT-270/FG and TT-272/FG).



TM2246-C7-28


- | | | | |
|---|-----------------------------------|----|---------------------------------|
| 1 | Plain hexagonal nut, 10504 | 8 | Machine screw, 10003 |
| 2 | Plain hexagonal nut, 10504 | 9 | Lockwasher, 10429 |
| 3 | Retainer ring, 10969 | 10 | Machine screw, 10398 |
| 4 | Retainer ring, 10969 | 11 | Lockwasher, 10429 |
| 5 | Tape-out lever pivot shaft, 52718 | 12 | Code sensing lever guide, 52861 |
| 6 | Tape-out lever spring, 53156 | 13 | Felt washer, 61474 |
| 7 | Tape-out lever, 52824 | | |

Figure 243. Tape-out sensing mechanism, exploded view. (Superseded)

Page 281, paragraph 200, subparagraph a(4), line 7. After "(6)" add: felt washer (13), when supplied.

Subparagraph b(2), line 1. After "(7)" add: felt washer (13), when supplied.

Page 283, paragraph 201a, subparagraph (9). After the sentence add: Catch the two felt washers (24), when supplied, as they fall from the start-stop lever.



TM 2246-C7-29

- 1 Retainer ring, 10949
- 2 Tight-tape lever, 52810
- 3 Retainer ring, 10949
- 4 Upper switch bail lever, 52811
- 5 Self-locking hexagonal nut, 10500
- 6 Machine screw, 10385
- 7 Machine screw, 10359
- 8 Flat washer, 10459
- 9 Machine screw, 10003
- 10 Lockwasher, 10429
- 11 Start-stop switch (S17), 20108
- 12 Wiring harness, 53339
- 13 Electrical clamp, 20507
- 14 Retainer ring, 10949


- 15 Start-stop lever, 52863
- 16 Retainer ring, 10949
- 17 Retainer ring, 10949
- 18 Pin, 52872
- 19 Lower switch bail lever, 52812
- 20 Start-stop lever detent spring, 53149
- 21 Retainer ring, 10499
- 22 Start-stop lever detent, 50404 (57206A on TT-270/FG and TT-272/FG).
- 23 Felt washer, 61474
- 24 Felt washer, 61474
- 25 Felt washer, 61477
- 26 Felt washer, 61474

Figure 244. Transmitter-distributor operating levers, exploded view. (Superseded)

Page 282, paragraph 201a(3). After the sentence add: Catch the two felt washers (23), when supplied, as they fall from the tight-tape lever.

Subparagraph (10), line 2. After "(17)" add: and felt washer (25), when supplied.

Subparagraph (12), line 1. After "(21)" add: the felt washer (26), when supplied.




TM2277-C2-13

- | | | | |
|----|--|----|--|
| 1 | Code sensing lever spring, 53152 | 13 | Code sensing lever stud, 52835 |
| 2 | Tape feed retracting lever spring, 53154 | 14 | Tape feed retracting lever, 52829A |
| 3 | Plain hexagonal nut, 10509 | 15 | Sensing lever restoring bail, 52858 |
| 4 | Plain hexagonal nut, 10509 | 16 | Code sensing lever, 52843A (includes items 17, 18, 20, 21) |
| 5 | Code sensing lever spring post, 50325 | 17 | Code sensing lever |
| 6 | Tape feed claw spring, 53153 | 18 | Code sensing lever |
| 7 | Setscrew, 10209 | 19 | Tape feed claw, 52836 |
| 8 | Retainer ring, 10957 | 20 | Code sensing lever |
| 9 | Retainer ring, 10957 | 21 | Code sensing lever |
| 10 | Retainer ring, 10957 | 22 | T-shaped felt washer, 61460 |
| 11 | Retainer ring, 10957 | | |
| 12 | Retainer ring, 10957 | | |

Figure 245. Transmitter-distributor code sensing levers, exploded view. (Superseded)

Page 284, paragraph 203a, subparagraph (4). After the last sentence add: Remove the felt washer (39), when supplied, from the spacer collar.

Subparagraph (7). After the sentence add: Catch the two felt washers (40), when supplied, as they fall from the tape feed lever.



TM 2277-C2-14

- | | | | |
|----|---|----|---|
| 1 | Selector lever spring, 50902 | 22 | Camshaft stop lever, 53613 (62020 on TT-270/FG and TT-272/FG) |
| 2 | Retainer ring, 10949 | 23 | Sleeve bearing, 52834 |
| 3 | Flat washer, 50147 | 24 | Setscrew, 10210 |
| 4 | Selector lever, 51598A (includes items, 7, 10, 13, 16 and 19) | 25 | Selector lever stud, 52840 |
| 5 | Bearing shoe, 51644A | 26 | Tape feed lever spring, 53149 |
| 6 | Flat washer, 50147 | 27 | Retainer ring, 10949 |
| 7 | Selector lever | 28 | Tape feed lever, 52845 |
| 8 | Bearing shoe | 29 | Setscrew, 10210 |
| 9 | Flat washer, 50147 | 30 | Tape feed lever stud, 52842 |
| 10 | Selector lever | 31 | Machine screw, 10003 |
| 11 | Bearing shoe | 32 | Lockwasher, 10429 |
| 12 | Spacer collar, 52833 | 33 | Machine screw, 10002 |
| 13 | Selector lever | 34 | Lockwasher, 10429 |
| 14 | Bearing shoe | 35 | Stop selector lever latch, 55870 |
| 15 | Flat washer, 50147 | 36 | Selector lever comb, 52841 (62019 on TT-270/FG and TT-272/FG) |
| 16 | Selector lever | 37 | Plain hexagonal nut, 10509 |
| 17 | Bearing shoe | 38 | Anchor post, 50325 |
| 18 | Flat washer, 50147 | 39 | Felt washer, 61479 |
| 19 | Selector lever | 40 | Felt washer, 61474 |
| 20 | Bearing shoe | | |
| 21 | Flat washer, 50147 | | |

Figure 246. Transmitter-distributor selector levers, exploded view. (Superseded)

Page 286, paragraph 205, subparagraph a(6), line 2. Change "washer" to: **washers**.

Delete subparagraph a(9) and substitute:


- (9) Remove the felt washer (19), when supplied, from the post (18). Remove the retainer ring (16) and transmitter contact bail (9) from the post. Remove the setscrew (17) and the post (18).

Subparagraph b. Delete subparagraph (1) and substitute:

- (1) Install the post (18) in the frame and secure it with the setscrew (17). Install the transmitter contact bail (9) on the post and secure it with the retainer ring (16). Install the felt washer (19), when supplied, on the post.

Page 287, figure 247, legend, Item 5. Add:
(61403 on TT-270/FG and TT-272/FG).

Figure 252, legend, item 15. Change
"10545" to: 10454.



- | | |
|---------------------------------------|--|
| 1 Machine screw, 10001 | 11 Lockwasher, 10403 |
| 2 Lockwasher, 10403 | 12 Transmitter contact terminal, 51597 |
| 3 Transmitter contact cover, 52808A | 13 Stationary contact (E6), 51588A |
| 4 Machine screw, 10009 | 14 Electrical wire, 51610 |
| 5 Lockwasher, 10403 | 15 Contact holder mounting, 51595A |
| 6 Transmitter contact bail spring | 16 Retainer ring, 10949 |
| 7 Machine screw, 10301 | 17 Setscrew, 10209 |
| 8 Lockwasher, 10403 | 18 Post, 52839 |
| 9 Transmitter contact bail E6, 51582A | 19 Felt washer, 61476 |
| 10 Machine screw, 10301 | |

Figure 248. Transmitter-distributor contacts, exploded view. (Superseded)

Item 9. Add: (61322 on TT-270/FG and TT-272/FG).

Page 291, figure 249 legend, item 29. Add:
(62018A on TT-270/FG and TT-272/FG).


Page 295, figure 252. Add the following note to figure 252.

Note. Later models of the equipment include a felt lubrication washer, 61478, between items 12 and 18.

Page 299, figure 255. Add the following note to figure 255.

Note. Later models of the equipment include a felt lubrication washer, 61482, between items 11 and 18.

Page 313, paragraph 225a(4). After the sentence add: Remove the two felt washers (54), when supplied.



TM2246-C7-33

Figure 264. Ribbon supply group, exploded view. (Superseded)

Page 315, paragraph 225a, subparagraph (11). After the last sentence add: Remove the felt washer (55), when supplied.

Delete subparagraph (12) and substitute:
(12) Remove the setscrew (24) that holds the sensing lever shaft (25) in the ribbon feed mounting bracket (50). Remove the felt washers (56 and 57),


when supplied. Remove the sensing lever shaft.

Subparagraph (13). After the sentence add: Remove the felt washer (58), when supplied, from the ribbon spool shaft.

Subparagraph (17), line 4. After "levers" add: and felt washers (48 and 59), when supplied.

1	Ribbon spool	30	Ribbon roller shaft, 52601
2	Machine screw, 10397	31	Machine screw, 10008
3	Lockwasher, 10431	32	Lockwasher, 10430
4	Machine screw, 10028	33	Retainer ring, 10969
5	Lockwasher, 10430	34	Left-hand ribbon reversing arm, 52705
6	Ribbon feed cam follower spring, 52602		Right-hand ribbon reversing arm, 52704
7	Retainer ring, 10949	35	Spring washer, 53427
8	Ribbon feed cam follower, 56234	36	Contact plunger spring, 51593
9	Flat washer, 50827	37	Spring washer, 53427
10	Setscrew, 10210	38	Retainer ring, 10969
11	Eccentric stud, 52585	39	Left-hand ribbon feed lever, 52605
12	Retainer ring, 10969		Right-hand ribbon feed lever, 52607
13	Ribbon retainer lever spring, 52603	40	Ribbon feed pawl shaft, 52609
14	Ribbon retainer shaft, 53178	41	Reversing arm shaft, 52703
15	Ribbon retainer lever, 57062	42	Driving link lever, 52622
16	Ribbon feed detent lever spring, 52604	43	Roller bracket, 52598
17	Sensing lever spring, 52603	44	Machine screw, 10397
18	Machine screw, 10001	45	Lockwasher, 10431
19	Lockwasher, 10429	46	Ribbon feed brace, 52581
20	Left-hand holding clip bracket, 56226A	47	Stud, 57063
	Right-hand holding clip bracket, 56228A	48	Felt washer, 61478
21	Left-hand sensing lever, 52597	49	Lockwasher, 10430
	Right-hand sensing lever, 52596	50	Ribbon feed mounting bracket, 52512A
22	Left-hand ratchet feed detent lever, 52610A	51	Setscrew, 10201
	Right-hand ratchet feed detent lever, 52611A	52	Ribbon retainer lever collar, 57061
23	Left-hand ribbon feeding detent wheel, 52591A	53	Left-hand sensing lever retracting lever, 57059
	Right-hand ribbon feeding detent wheel, 52590A	54	Felt washer, 61474
24	Setscrew, 10210	55	Felt washer, 61476
25	Sensing lever shaft, 52595	56	Felt washer, 61478
26	Setscrew, 10210	57	Felt washer, 61478
27	Ribbon spool shaft, 56231A	58	Felt washer, 61476
28	Retainer ring, 10949	59	Felt washer, 61478
29	Ribbon roller, 52608		

Figure 264—Continued.



TM 2246-C7-34

Figure 265. Front support assembly, exploded view. (Superseded)

Page 317, paragraph 227a(7). After the sentence add: Catch the two felt washers (27), when supplied, as they fall from the detent lever.


Page 318, paragraph 227, subparagraph a(11), line 7. After "wheel" add: felt washers (28 and 29), when supplied.

Subparagraph b(1), line 1. After "(26)" add: the two felt washers (28 and 29), when supplied,

Subparagraph b(5), line 1. After "(11)" add: and the two felt washers (27), when supplied.

1	Machine screw, 10035-01	36	Feed pawl assembly, 52331A
2	Lockwasher, 10405	37	Self-locking hexagonal nut, 10501
3	Machine screw, 10063	38	Feed pawl pivot, 52329
4	Lockwasher, 10430	39	Retainer ring, 10960
5	Bearing block	40	Retainer ring, 10960
6	Dowel	41	Code and feed hole punch lever stop pin, 52327
7	Machine screw, 10010	42	Self-locking hexagonal nut, 10525
8	Lockwasher, 10430	43	Pivot stud, 52409
9	Machine screw, 10025	44	Flat washer, 52446
10	Lockwasher, 10430	45	Code hole punch lever, 52346
11	Chad tube, 55760A	46	Flat washer, 52446
12	Machine screw, 10009	47	Code hole punch lever, 52346
13	Lockwasher, 10430	48	Flat washer, 52446
14	Tape chute, 52489A	49	Feed punch lever, 52347
15	Print hammer lever spring, 52163	50	Flat washer, 52446
16	Register lever spring, 56158	51	Code hole punch lever, 52346
17	Setscrew, 10211	52	Flat washer, 52446
18	Retainer ring, 10949	53	Code hole punch lever, 52346
19	Print and register levers shaft, 52486	54	Flat washer, 52446
20	Flat washer, 52651	55	Code hole punch lever, 52346
21	Print hammer lever, 52436A	56	Flat washer, 22446
22	Flat washer, 52651	57	Cam roller, 52354
23	Self-locking hexagonal nut, 10501	58	Plain hexagonal nut, 10526
24	Print hammer eccentric stop, 52485	59	Eccentric stud, 52365
25	Type wheel register lever, 52432	60	Punch arm assembly, 52337A
26	Self-locking hexagonal nut, 10525	61	Retainer ring, 10971
27	Flat washer, 10464	62	Setscrew, 10210
28	Self-locking hexagonal nut, 10525	63	Punch arm pivot post, 52345
29	Adjusting plate, 52493	64	Register and print levers spring post
30	Self-locking hexagonal nut, 10501 (TT-178/FG and TT-179/FG only)	65	Spring post
31	Eccentric stop, 52485 (TT-178/FG and TT-179/FG only)	66	Front support frame, 55130A (includes items 3, 4, 5, 6, 64, 65 and items 1, 2, 3, and 4 of figure 272).
32	Support plate, 52321A	67	Felt washer, 61670
33	Flat washer, 52651	68	Felt washer, 61670
34	Feed pawl spring, 55164	69	Felt washer, 61472
35	Retainer ring, 10960	70	Felt washer, 61483

Figure 265—Continued.




TM 2246-C7-35

- | | |
|--------------------------------------|--------------------------------------|
| 1 Back space pawl spring, 52192 | 16 Tape retainer spring, 52422 |
| 2 Self-locking hexagonal nut, 10500 | 17 Machine screw, 10004 |
| 3 Pawl eccentric screw, 52643 | 18 Retainer mounting bracket, 56298A |
| 4 Back space pawl, 52709 | 19 Tape guide, 52519 |
| 5 Back space lever spring, 52193 | 20 Tape tear wire, 56164 |
| 6 Back space pivot stud, 52644 | 21 Lockwasher, 10429 |
| 7 Collar, 52645 | 22 Setscrew, 10201 |
| 8 Back space lever, 52654 | 23 Setscrew, 10201 |
| 9 Detent lever spring, 52166 | 24 Ratchet wheel, 52442A |
| 10 Retainer ring, 10949 | 25 Detent wheel, 52384 |
| 11 Detent lever, 52445A | 26 Tape feed sprocket, 52377 |
| 12 Self-locking hexagonal nut, 10501 | 27 Felt washer, 61681 |
| 13 Eccentric stud, 52342 | 28 Felt washer, 61475 |
| 14 Retainer ring, 10969 | 29 Felt washer, 61681 |
| 15 Tape retainer assembly, 52126A | |

Figure 266. Tape feed mechanism, exploded view. (Superseded)

Page 320, paragraph 229a, subparagraph (2). After the sentence add: Remove the felt washer (25), when supplied.

Subparagraph (5), line 7. After "collars" add: and felt washer (26), when supplied,



TM 2246-C7-36

Figure 268. Type wheel group, exploded view. (Superseded)

- 1 Cotter pin, 10806
- 2 Flat washer, 50320
- 3 Ribbon guide, 52416A
- 4 Flat washer, 50320
- 5 Machine screw, 10006
- 6 Nut plate, 50174
- 7 Flat washer, 10459
- 8 Typewheel upper bellcrank lever, 52482
- 9 Machine screw, 10006
- 10 Nut plate, 50174
- 11 Flat washer, 10459
- 12 Typewheel bellcrank lever spring, 52161
- 13 Typewheel lower bellcrank lever, 52480

- 14 Setscrew, 10203
- 15 Setscrew, 10203
- 16 Reciprocating lever shaft, 52414
- 17 Shaft collar, 50391
- 18 Shaft collar, 50391
- 19 Machine screw, 10305
- 20 Typewheel clamp plate mounting disk, 52407
- 21 Typewheel, 55132 (59916, TT-181/FG only)
- 22 Typewheel hub assembly, 55134A
- 23 Setscrew, 10210
- 24 Typewheel post, 52418
- 25 Felt washer, 61490
- 26 Felt washer, 61479

Figure 268—Continued.

Page 322. Add the following note to figure 269:

Note. Later models of the equipment include a felt lubrication washer, 61476, between items 4 and 9.


Page 323, paragraph 231a, subparagraph (9). After the sentence add: Remove the felt washer (67), when supplied.

Subparagraph (11), line 5. After "plate" add: felt washer (68), when supplied.

Subparagraph (14). After the sentence add: Remove the felt washer (69), when supplied.

Subparagraph (19), line 1. After "(61)" add: and felt washer (70), when supplied.

Page 324, paragraph 231c, subparagraph (1). After the first sentence add: Install the felt washer (70), when supplied, on the punch arm pivot post.



TM 2246-C7-37

Figure 273. Y-levers and selector levers, exploded view. (Superseded)

- | | | | |
|----|---|----|--|
| 1 | Y-lever detent spring, 55009 | 37 | Y-lever pivot post stud, 53269 |
| 2 | Y-lever detent spring, 55009 | 38 | Setscrew, 10247 |
| 3 | Y-lever detent spring, 55009 | 39 | Y-lever stop, 50152 |
| 4 | Y-lever detent spring, 55009 | 40 | Retainer ring, 10929 |
| 5 | Y-lever detent spring, 55009 | 41 | Selector lever spring, 50902 |
| 6 | Plain hexagonal nut, 10504 | 42 | Selector lever spring, 50902 |
| 7 | Lockwasher, 10434 | 43 | Selector lever spring, 50902 |
| 8 | Y-lever detent, 55004 | 44 | Selector lever spring, 50902 |
| 9 | Spacer, 55076 | 45 | Selector lever spring, 50902 |
| 10 | Detent spacer, 55001 | 46 | Selector lever spring, 50902 |
| 11 | Y-lever detent, 55004 | 47 | Self-locking hexagonal nut, 10500 |
| 12 | Detent spacer, 55001 | 48 | Selector camshaft lever eccentric, 50146 |
| 13 | Y-lever detent, 55004 | 49 | Selector camshaft locking lever, 50014 |
| 14 | Detent spacer, 55001 | 50 | Flat washer, 50053 |
| 15 | Y-lever detent, 55004 | 51 | Selector lever, 51068A (includes items
54, 57, 60 and 63) |
| 16 | Detent spacer, 55001 | 52 | Bearing, 51604A (includes items 55, 58, 61, and 64) |
| 17 | Y-lever detent, 55004 | 53 | Flat washer, 50147 |
| 18 | Detent spacer, 55001 | 54 | Selector lever |
| 19 | Y-lever detent eccentric sleeve, 55007 | 55 | Bearing |
| 20 | Y-lever detent pivot, 55008 | 56 | Flat washer, 50147 |
| 21 | Y-lever detent spring bracket, 55002 | 57 | Selector lever |
| 22 | Setscrew, 10209 | 58 | Bearing |
| 23 | Setscrew, 10209 | 59 | Flat washer, 50147 |
| 24 | Y-lever retaining collar, 55006 | 60 | Selector lever |
| 25 | Flat washer, 50148 | 61 | Bearing |
| 26 | Selector Y-lever, 53540A (includes items
28, 30, 32, and 34) | 62 | Flat washer, 50147 |
| 27 | Flat washer, 50148 | 63 | Selector lever |
| 28 | Selector Y-lever | 64 | Bearing |
| 29 | Flat washer, 50148 | 65 | Selector lever pivot post collar, 51416 |
| 30 | Selector Y-lever | 66 | Setscrew, 10211 |
| 31 | Flat washer, 50148 | 67 | Selector lever pivot stud, 53268 |
| 32 | Selector Y-lever | 68 | Plain hexagonal nut, 10509 |
| 33 | Flat washer, 50148 | 69 | Selector lever spring post, 50325 |
| 34 | Selector Y-lever | 70 | Felt washer, 61478 |
| 35 | Selector lever pivot post collar, 51416 | 71 | Felt washer, 61469 |
| 36 | Setscrew, 10210 | 72 | Felt washer, 61479 |

Figure 273—Continued.

Subparagraph (6), line 1. After "Position" add: the felt washer (69), when supplied, and.

Subparagraph (9), line 2. After "(33)" add: felt washer (68), when supplied.


Subparagraph (11), line 2. After "(22)" add: felt washer (67), when supplied.

Page 328. Add the following note to figure 272:

Note. Later models of the equipment include a felt lubrication washer, 61480, between items 18 and 20.

Page 331, paragraph 236a, subparagraph (5), line 3. After "collar" add: and felt washer (70), when supplied. After the second sentence add: Remove the felt washer (71), when supplied.

Subparagraph (9), line 4. After "(49)" add: and felt washer (72), when supplied.



TM 2246-C7-38

- | | | | |
|----|---|----|---|
| 1 | Machine screw, 10010 | 25 | Plain hexagonal nut, 50651 |
| 2 | Shaft collar, 53973 | 26 | Lockwasher, 10404 |
| 3 | Function clutch latch screw, 52176 | 27 | T-lever pivot stud, 50650 |
| 4 | Machine screw, 10000 | 28 | Transfer lever spring post, 50649 |
| 5 | Plain hexagonal nut, 10504 | 29 | Self-locking hexagonal nut, 10501 |
| 6 | Lockwasher, 10434 | 30 | Transfer lever roller stud, 56185 |
| 7 | Clutch latch arm, 50535 | 31 | Taper pin |
| 8 | Ball bearing, 10754 | 32 | Transfer lever shaft, 54745A (includes items 31 and 33) |
| 9 | Machine screw, 10010 | 33 | Transfer lever |
| 10 | Machine screw, 10010 | 34 | Machine screw, 55511 |
| 11 | Shaft collar, 53973 | 35 | Flat washer, 50839 |
| 12 | Shaft collar, 53973 | 36 | Lockwasher, 10429 |
| 13 | Transfer lever spring, 55674 | 37 | Transfer lever spring post eccentric, 56076 |
| 14 | Self-locking hexagonal nut, 10500 | 38 | Transfer lever trip latch spring, 50904 |
| 15 | Flat washer, 50414 | 39 | Retainer ring, 10949 |
| 16 | T-lever, 56766A (includes items 18, 20, 22, and 24) | 40 | Transfer lever trip latch, 50020A |
| 17 | Flat washer, 50148 | 41 | Transfer lever latch pivot stud, 52319 |
| 18 | T-lever | 42 | Shim: 0.002-in., 57072; 0.003-in., 57073 |
| 19 | Flat washer, 50148 | 43 | Felt washer, 61488 |
| 20 | T-lever | 44 | Felt washer, 61489 |
| 21 | Flat washer, 50148 | 45 | Felt washer, 61680 |
| 22 | T-lever | 46 | Felt washer, 61467 |
| 23 | Flat washer, 50148 | | |
| 24 | T-lever | | |


Figure 274. Sequential transfer lever shaft, exploded view. (Superseded)

Page 332, paragraph 237a(7), line 4. After "(11 and 12)" add: and felt washers (43 and 44), when supplied.

Page 333, paragraph 239. Change reference after heading from "(fig. 272)" to (fig. 275).

Subparagraph (5), line 5. At end of sentence add: and the felt washer (43), when supplied.


Page 334, paragraph 239a(8), last line. After "(16 and 17)" add: and felt washers (43 and 44), when supplied.



TM 2246-C7-39

- 1 Machine screw, 10010
- 2 Shaft collar, 53973
- 3 Function clutch latch screw, 52176
- 4 Machine screw, 10000
- 5 Plain hexagonal nut, 10504
- 6 Lockwasher, 10434
- 7 Clutch latch arm, 50535
- 8 Ball bearing, 10754
- 9 Machine screw, 10041
- 10 Nut plate, 50174
- 11 Flat washer, 10459
- 12 Clutch release lever, 59977 (56032, TT-178/ FG and TT-179/FG)
- 13 Transfer lever spring, 50903
- 14 Machine screw, 10010
- 15 Machine screw, 10010
- 16 Shaft collar, 53973
- 17 Shaft collar, 53973
- 18 Self-locking hexagonal nut, 10500
- 19 Flat washer, 50414
- 20 T-lever, 56766A (includes items 22, 24, 26, and 28)
- 21 Flat washer, 50148
- 22 T-lever
- 23 Flat washer, 50148
- 24 T-lever
- 25 Flat washer, 50148
- 26 T-lever
- 27 Flat washer, 50148
- 28 T-lever
- 29 Plain hexagonal nut, 50651
- 30 Lockwasher, 10404
- 31 T-lever pivot stud, 50650
- 32 Transfer lever spring post, 50649
- 33 Self-locking hexagonal nut, 10501
- 34 Transfer lever roller stud, 56185
- 35 Taper pin
- 36 Transfer lever shaft, 54740A (includes items 37 and 37)
- 37 Transfer lever
- 38 Machine screw, 10003
- 39 Flat washer, 50839
- 40 Lockwasher, 10429
- 41 Transfer lever spring post eccentric, 56076
- 42 Shim: 0.002-in., 57072; 0.003-in., 57073
- 43 Felt washer, 61488
- 44 Felt washer, 61489
- 45 Felt washer, 61480

Figure 275. Simultaneous transfer lever shaft, exploded view. (Superseded)



TM 2246-C7-40

Figure 281. Typewriter reciprocating mechanism, exploded view. (Superseded)

Page 335, paragraph 239c(2), line 5. After "(16 and 17)" add: and the felt washers (43 and 44), when supplied.

Page 338. Add the following note to figure 277.

Note. Later models of the equipment include a felt lubrication washer, 61496, between items 4 and 5.

Page 341. Add the following note to figure 279.

Note. Later models of the equipment include a felt lubrication washer, 61496, between items 10 and 11.


Page 343, paragraph 246a(2). After the sentence add: Remove the two felt washers (47), when supplied.

Figure 280, legend, item 21. Add: (61326A on TT-270/FG and TT-272/FG).

Page 344, paragraph 246a(9). After the last sentence add: Remove the felt washer (48), when supplied.

1	Code-ring locking bail cam follower spring, 53569	25	Flat washer, 52402
2	Machine screw, 10006	26	Typewheel reciprocating spring lever, 52405
3	Anchor nut, 50174	27	Sleeve bearing, 52401
4	Flat washer, 10459	28	Flat washer, 52402
6	Code-ring locking bail cam follower, 52657	29	Spring pin, 52403
7	Machine screw, 10004	30	Typewheel reciprocating drive lever, 52362
8	Flat washer, 10458	31	Flat washer, 53261
9	Lockwasher, 10429	32	Flat washer, 52413
10	Code-ring locking bail, 52653	33	Spring, 52168
11	Retainer ring, 10949	34	Figures-letters shift lever, 52406
12	Code-ring locking bail shaft, 52291	35	Flat washer, 53261
13	Letters-figures shift latch lever, 52411	36	Self-locking hexagonal nut, 10525
14	Retainer ring, 10949	37	Typewheel shift lever stud, 52417
15	Typewheel reciprocating transfer lever, 52478	38	Bell sensing lever spring, 52173
16	Self-locking hexagonal nut, 10525	39	Shift cam follower spring, 52172
17	Flat washer, 52430	40	Letters sensing lever spring, 52169
18	Typewheel reciprocating transfer lever eccentric stud, 52399	41	Figures sensing lever spring, 52171
19	Typewheel reciprocating lever spring, 52167	42	Machine screw, 10076
20	Setscrew, 10209	43	Lockwasher, 10430
21	Shaft collar, 50209	44	Machine screw, 10025
22	Retainer plate, 53652	45	Lockwasher, 10430
23	Drive pin, 52404	46	Function plate, 52419A
24	Typewheel reciprocating drive lever, 52362	47	Felt washer, 61477
		48	Felt washer, 61471

Figure 281—Continued.



TM 2246-C7-41

Figure 282. Function sensing mechanism, exploded view. (Superseded)

- 1 Machine screw, 10012
- 2 Lockwasher, 10430
- 3 Stop arm shaft support plate, 56732A
- 4 Setscrew, 10209
- 5 Stop arm shaft driven gear, 52344
- 6 Thrust bearing, 50374
- 7 Typewheel reciprocating cam follower, 52477A
- 8 Sensing lever spacer, 52649
- 9 Setscrew, 10203
- 10 Signal bell clapper, 52682
- 11 Bell sensing lever, 52638A
- 12 Sensing lever spacer, 52649
- 13 Figures sensing lever, 52483
- 14 Sensing lever spacer, 52649
- 15 Letters sensing lever, 52484
- 16 Sensing lever spacer, 52649
- 17 Plain hexagonal nut, 10512
- 18 Flat washer, 50414
- 19 Lockwasher, 10429
- 20 Restoring lever eccentric, 52664
- 21 Cam lever assembly, 52459A
- 22 Laminated spacer, 52679
- 23 Felt washer, 61471

Figure 282—Continued.

Page 348. Add the following note to figure 283:

Note. Later models of the equipment include a felt lubrication washer, 61485, between items 6 and 7.

Page 353, figure 286, legend, item 67. Change "20223a" to: 20220a.

Item 127. Change "54652 (54653a)" to: 54652A (54653A*).

Page 357, figure 287, legend. Change item 7 to: Cable assembly, 56315A, TT-178/FG and TT-179/FG; 59899A, all other models (both assemblies include plug 20441).

Add the following below the legend:

Note. The following legend applies to figure 287 and lists the TT-178A/FG, TT-179A/FG, TT-181/FG, TT-270/FG, and TT-272/FG:

- 1 FL205, 54568
- 2 P227, 54084A
- 3 CR201, 54578A
- 4 R214, 20059; R205, 20028; R202, 20032
- 5 C206, 20219
- 6 59897A (synchronous motor); 59913A, TT-178A/FG (series-governed motor)
- 7 P235, 59899
- 8 TB204, 20370
- 9 20382
- 10 59983A
- 11 TB201, 59981A
- 12 S211, 54584
- 13 S204, 54585
- 14 S213, 20119
- 15 S210, 54588
- 16 S203, 54589
- 17 20713
- 18 R216, R1628 (series-governed motor)
- 19 C209, 20214
- 20 FL208, 54581 (series-governed motor)
- 21 J231, 20264
- 22 CR202, 54578A
- 23 56101
- 24 TB203, 59926A
- 25 J228, 20267
- 26 R212, 20028; R213, 20029
- 27 56101
- 28 S212, 20115

Page 358, paragraph 263. Delete the last sentence.

Page 359, paragraph 264. Below the heading. Add:

Note. Perform the adjustment in paragraph 301.1 before proceeding with the following adjustment.

Page 361. Add paragraph 270.1 after paragraph 270.

270.1. Stop Bar Bracket Adjustment (fig. 293.1)

Note 1. Perform the adjustment in paragraph 285 before proceeding with the following adjustment.

Note 2. On weather communication equipments only, an electrical contact is mounted on the stop bar bracket. This does not alter the requirements and method of performing this adjustment.

a. Requirements.

- (1) The stop bar bracket should be positioned so that the line feed and carriage-return function stop bars do not come out of the code-ring cage slots when the automatic carriage-return and line feed linkage is in the operated position.
- (2) The stop bar bracket should not bind the line feed and carriage-return function stop bars. Binding may cause a failure in shifting of the code rings.

b. Method of Checking.

- (1) Manually actuate the automatic carriage-return and line feed linkage with the unit in the stopped position and the "T" code selection set up in the code rings. Move the free end of the line feed stop bar toward the stop bar bracket. Attempt to slide the line feed stop bar away from the code rings and out of the code-ring cage. At the same time, push in on the line feed stop bar located next to the line feed fulcrum. Check to see that the line feed stop bar does not come off the stop bar shift blade. Use the same procedure to check the carriage-return function stop bar.
- (2) Make sure no binding exists between the narrow end of the line feed and carriage-return function stop bars and the stop bar bracket when the unit is in the stopped position and the "T" code selection is set up in the code rings.

c. Adjustment. Loosen the two mounting screws and position the stop bracket to meet the requirements. If the requirements cannot be met, recheck the fulcrum adjustment (par. 285) and the automatic carriage-return and line feed adjustments (pars. 274, 313, 314, 315, 336, 337, 338, and 343). When the requirements are met, tighten the mounting screws. Recheck the requirements.





Figure 293.1. Stop bar bracket adjustment (standard symbol communications equipment). (Added)

Page 362, paragraph 273, note, line 3. After "272" add: and 298.

Page 364. Delete paragraph 277 and substitute:

277. Code-Ring Locking Bail Cam Follower Adjustment (fig. 300)

a. Requirement.

- (1) The locking bail collar blade should operate freely between the letters and J-stop bars without touching either stop bar.
- (2) There should be 0.010-inch minimum clearance between the cam follower lever and the figures function stop bar when the cam follower is on the high part of the locking bail cam and the figures stop bar is selected.

b. Adjustment.

- (1) With the function shaft in the stop position (fig. 300), loosen the mounting screw that holds the cam follower.

Position the cam follower until the locking bail collar blade operates freely between the letters and the J-stop bars. Tighten the mounting screw. Set up repeated letters and J-code group on the code rings and check the requirements visually.

- (2) The code-ring locking lever blade should be positioned equidistant from the letters and J-stop bar, but it may have to be positioned closer to either the letters or J-stop bar to maintain the requirement. Check related adjustments (par. 300).

Paragraph 278. Below the heading add the following note:

Note. Perform the adjustments in paragraphs 300, 301, 302, 264, 279, and 280 before proceeding with the adjustment below.




Figure 300. Code-ring locking bail cam follower adjustment. (Superseded)

Page 366, paragraph 281b. After the last sentence add: Check related adjustments (pars. 284, 292, and 295).

Delete paragraph 283 and substitute.

283. Y-Levers Detent End Play Adjustment (fig. 305)

a. Requirements.

- (1) End play of the Y-lever detents must not be great enough to prevent the Y-lever detents from engaging their associated Y-levers by at least 25 percent of the Y-lever detent thickness.
- (2) Y-lever detents should have a minimum of 0.002 inch end play.

b. Method of Checking.

- (1) Check the engagement requirement (a(1) above) visually by moving the Y-lever detents back and forth.
- (2) Check the end play requirement (a(2) above) with a feeler gage.

c. Adjustment. Remove the hexagonal nut and lockwasher. Slide the Y-lever detent eccentric sleeve and detent assembly from the Y-lever detent pivot. If the end play of the Y-lever detents is less than 0.002 inch, peel the laminated washer to size as required in a(2) above. If the end play of the Y-lever detents is so great that requirement in a(1) above is not met, add another laminated washer (55076), peeled to a size so the requirement in a(1) above will be met. Replace the parts on the pivot, tighten the nut, and recheck the requirement. Do not insert peeled laminated washers less than 0.006 inch thick. Make sure peeled laminated washers are flat and free of burrs before inserting.




Figure 305. Y-levers detent end play adjustment. (Superseded)

Page 367, paragraph 284. Delete the designation (1) from subparagraph a and delete subparagraph (2).

Subparagraph b, lines 2 and 3. Change "both requirements are met" to: **the requirement is met.**

Figure 306. Delete the two callouts "30 to 60 GRAMS TO START LEVER MOVING."

Paragraph 285. Below the heading. Add the following note:

Note. Perform the adjustment in paragraph 343 before proceeding with the following adjustment.

Page 368, paragraph 287a, line 2. Change ".015-inch" to: **0.027- to 0.033-inch gap.**

Figure 309. Change callout ".015" to: **.027-.033.**

Page 369. Delete paragraph 288 and substitute.

288. Selector Magnet Pole Faces and Armature Alignment (fig. 310)

Note. Remove selector magnet bracket from the teletypewriter (par. 163a(1)) before making this adjustment.

a. Requirements.

- (1) Clearance between the pole face of the selector magnet and the toffets on the armature should be 0.004 inch.
- (2) The pole faces of the selector magnet and the toffets on the armature should be parallel within 0.002 inch.
- (3) When positioned for mark or space, the armature should not touch the armature adjusting screws.

b. Method of Checking.

- (1) Use two 0.004-inch feeler gages and check the requirements in a(1) and (2) above.
- (2) Position the armature for mark or space. Check the requirement in a(3) above visually.

c. Adjustments.

- (1) Loosen the setscrews behind the selector magnet. Loosen the two machine screws that secure the selector magnet to the selector magnet bracket. Insert 0.004-inch feeler gages between the pole faces of the selector magnet and the toffets on the armature. Position the selector magnet to meet requirements in a(1) and (2) above.

Tighten the setscrews and two machine screws.

- (2) Position the armature for mark, then for space. Adjust the armature adjusting screws so that the armature does not touch them. Tighten the adjusting screw lock. Check related adjustments (pars. 289 and 290).

Page 370. Delete paragraph 289 and substitute.

289. Selector Magnet Armature Positioning Adjustment (fig. 311)

a. Requirements.

- (1) With the end play of the armature taken up in either direction, the step


Page 371, paragraph 290b. After the last sentence add: (On equipments with selector magnet brackets that have locking tabs, loosen or tighten the leaf spring stop screws by

- (2) The pole faces and toffets on the armature must be aligned.

b. Method of Checking.

- (1) Take up the end play of the armature in either direction. Visually check the requirement in a(1) above.
- (2) Visually check the requirement in a(2) above.

c. Adjustment. Loosen the setscrew and position the armature shaft to meet the requirements. Tighten the setscrew and recheck the requirement (b above).



TM5815-200-35-C2-19

Figure 311. Selector magnet armature positioning adjustment. (Superseded)

in the armature blade should not interfere with the No. 1 selector lever while maintaining 100 percent engagement with the stop lever.

loosening or tightening the locking tab machine screws.)

Page 372, paragraph 292. Delete subparagraph b and substitute:

b. Method of Checking.

- (1) With the motor on, select the blank code group. Insert a 0.006-inch feeler gage between the Y-levers and the Y-lever eccentric stop. Select the letters code group and check the requirement.
- (2) With the motor on, select the blank code group. Insert a 0.002-inch feeler gage between the Y-levers and the Y-lever eccentric stop. Select the letters code group and check the requirement.

Page 373, paragraph 293a, line 1. Change ".018" to: 0.015.

After subparagraph a. Add:

a.1. Method of Checking. Position the selector camshaft so that the selector levers are not operated. Place the armature in mark position and check the requirement with feeler gages.

Paragraph 294, subparagraph a, line 6. After "drum." Add: and the function driven gear is shifted as far as possible toward the sliding clutch drum.

After subparagraph a. Add:

a.1. Method of Checking. Make sure the teletypewriter is in the stop position. Hold the function driven gear as far as possible toward the function shaft sliding clutch drum and insert a flat feeler gage between the gear and the sliding clutch drum. Repeat the check when the opposite finger of the sliding clutch drum is engaged by the clutch latch.

Subparagraph b. Delete the first sentence and substitute: Loosen the clamping screw in the shaft collar next to the clutch latch. Loosen the clamping screw in the clutch latch.

Paragraph 295a, line 1. Change ".008- to .012" to: 0.015- to 0.020.

Figure 318. Change the callout ".008"-.012"" to: 015"-020".

Page 374. Delete paragraph 298 and substitute.

298. Selector Camshaft Clutch Load Adjustment (fig. 320)

a. Requirements.

- (1) There should be a 0.005- to 0.025-inch clearance between the friction clutch disk and the bearing of the clutch fork.

- (2) It should require a pull from 48 to 54 ounces to hold the stop plate away from the stop lever with the motor on.

b. Method of Checking.

- (1) Insert a flat feeler gage between the friction clutch and the bearing of the selector friction clutch fork to determine the clearance.
- (2) Place the hook end of the spring scale on the stop plate retainer of the selector camshaft. Pull on the spring scale until the stop plate moves away from the stop lever. Read the scale.

c. Adjustment.

- (1) Loosen the two setscrews in the friction clutch disk and position the disk until the requirement in a(1) above is met. Tighten the two setscrews.
- (2) Loosen the clamping screws of the friction clutch adjusting collar and turn the collar to meet the requirement in a(2) above. Tighten the clamping screws.





Figure 320. Selector camshaft clutch load adjustment. (Superseded)

TM5815-206-35-115




Figure 320.1. Type selecting arm claw end play adjustment. (Added)




Figure 320.2. Carriage rear support bracket adjustment. (Added)

Page 375. Add paragraphs 298.1 and 298.2 after paragraph 298.

298.1. Type Selecting Arm Claw End Play Adjustment (fig. 320.1)

Perform this adjustment only when replacing bearings, spacer, or carriage frame.

a. Requirements. Clearance between the carriage frame and the type selecting arm claw bearing should not exceed 0.005 inch. The claw assembly must rotate freely.

b. Method of Checking. Remove the bearing cap and place the type selecting arm assembly in its bearing seat on the type bar carriage. Move the type selecting arm assembly back and forth to see that the claw assembly rotates freely at all positions of the type selecting arm assembly. Push on the gear toward the type selecting arm to take up all the end play. Check

the maximum clearance with a feeler gage. Make sure the claw assembly rotates freely.

c. Adjustments. Assemble the parts on the claw assembly and include a full laminated washer (50551). Tighten the hexagonal nut from 35 to 40 inch-pounds torque. Place the claw assembly in the carriage frame and check the requirement in *a* above; use the method of checking in *b* above. If the requirement in *a* above is not met, disassemble the claw assembly. Peel the 0.002-inch thick laminations from the laminated washer to meet the requirement in *a* above.

298.2. Carriage Rear Support Bracket Adjustment (fig. 320.2)

a. Requirement. Backlash between the square shaft sliding helical gear and the claw driving helical gear should be at a minimum.

b. Method of Checking. Attempt to rotate the claw driving gear back and forth. Move the square shaft sliding helical gear to various positions. Check the requirement at each position.

c. Adjustment. Move the carriage frame to the left-hand margin. Loosen the carriage rear support bracket mounting screws. Move the rear of the carriage up or down to meet the requirement. Tighten the mounting screws and recheck the requirement. Check the related adjustment (par. 322).

Paragraph 299. Below the heading. Add:

Note. Perform the adjustment in paragraph 322 before proceeding with the following adjustment.

Page 376. Delete paragraph 300 and substitute.

300. Code-Ring Locking Bail Shaft Adjustment (fig. 322)

a. Requirements.

- (1) There should be a 0.010- to 0.020-inch clearance between the code-ring locking bail and the code-ring projections (A, fig. 322) when the function shaft is in the stopped position.
- (2) There should be a 0.002- to 0.005-inch end play in the code-ring locking bail shaft (B, fig. 322).


b. Method of Checking.

- (1) With the function shaft in the stopped position, place the No. 1 code ring so that it projects directly opposite the locking edge of the code-ring locking bail. Check the requirement with a feeler gage.
- (2) Insert a flat feeler gage between the collar of the code-ring locking lever and the code bar cage plate to determine the end play.


c. Adjustments.

- (1) Loosen the setscrews in the code-ring locking lever collar. Rotate the code-ring locking bail shaft until the requirement in a(1) above is met.
- (2) Position the collar to obtain the requirement in a(2) above. Tighten the setscrews in the code-ring locking lever collar.

Paragraph 301, heading. Change "(fig. 322)" to: (fig. 322.1).




A



B


TM5815-200-35-44

Figure 322. Code-ring locking bail shaft and locking bail adjustments. (Superseded)



TM5815-200-35-45

Figure 322.1. Code-ring locking bail adjustment. (Added)



TM5815-200-35-C2-8

Figure 322.2. T-lever end play adjustment. (Added)

Page 377. Add paragraph 301.1 after paragraph 301.

301.1. T-Lever End Play Adjustment
(fig. 322.2)

- a. Requirement. End play of the T-levers on the T-lever stud should not exceed 0.003 inch.
- b. Method of Checking. Measure the clearance between the first T-lever and the flat washer, with the end play of the T-levers taken up toward the transfer lever.

c. Adjustment. Remove the hexagonal nut, flat washer, and first T-lever. Add or remove shims (57072 and 57073), to meet the requirement. Replace the bottom T-lever, flat washer, and hexagonal nut. Tighten the hexagonal nut and recheck the requirement.

Paragraph 302, subparagraph *a.* After the sentence. Add: The decelerating cam is positioned as shown in C, figure 326 on all models except the AN/FGC-26. On the AN/FGC-26, the dimension should be $2\frac{7}{32}$ inches $\pm\frac{1}{16}$ inch.

Subparagraph *b.* After the last sentence add: Check related adjustments (pars. 350 and 351).

Page 378. Add paragraph 304.1 after paragraph 304.

304.1. Decelerating Cam and Carriage-Feed Clutch Positioning Adjustment (fig. 326)

a. Requirement. With the carriage at the left-hand margin, the top of the decelerating cam should be centered, $\pm\frac{1}{16}$ -inch, with the adjacent hole in the carriage-return driven gear. Check this requirement visually.

b. Method of Checking. Turn on the motor. Return the carriage to the left-hand margin. Check the requirement visually, then turn off the motor.

c. Adjustment.

- (1) Loosen the carriage rack machine screw far enough to disengage the rack from the carriage rack driving gear. Move the carriage to the right-hand margin.
- (2) Loosen the machine screws that hold the carriage-return latch tripping arm and rotate the arm as far clockwise as possible (C, fig. 326).
- (3) Loosen one of the two setscrews that holds the carriage-feed shaft collar to the carriage-feed shaft (fig. 327). Turn the shaft so that the other setscrew is straight up. Remove the double-blocking lever spring and manually disengage the carriage-feed clutch. Rotate the carriage rack driving gear until the decelerating cam is positioned as close as possible to the requirement. Reengage the carriage-feed clutch and replace the double-blocking lever spring. The

mechanism is now positioned for easy adjustment.


- (4) Loosen the other setscrew in the carriage-feed shaft collar. Hold the carriage-feed ratchet firmly against the carriage-feed pawl and rotate the collar until the decelerating cam is positioned to meet the requirement. Tighten the setscrews.
- (5) Make the adjustment described in paragraph 305.
- (6) Make the adjustments described in paragraphs 302 and 304.
Delete paragraph 305 and substitute.

305. Carriage-Return Latch Tripping Arm Adjustment (fig. 326)


a. Requirement. The carriage-return latch tripping arm should trip the carriage-return latch (A, fig. 326) just as the decelerating cam reaches the position shown in C, figure 326, and the carriage-feed clutch is aligned to mesh properly.

b. Method of Checking. Space the carriage out 10 or more spaces and turn off the motor. Press the carriage-return key and turn the motor by hand until the carriage nears the left-hand margin. When the carriage-return latch tripping arm touches the carriage-return latch (B, fig. 326), turn the motor slowly. See that the carriage-feed clutch teeth mesh properly and the decelerating cam is positioned as shown in C, figure 326.


c. Adjustment. Loosen the clamping machine screw in the clutch throwout lever (fig. 329) before proceeding with this adjustment. With the carriage-feed clutch and the decelerating cam in the position shown in C, figure 326, loosen the two machine screws that hold the carriage-return latch tripping arm and position the latch tripping arm so that it is in contact with the carriage-return latch (A, fig. 326). Tighten one machine screw and recheck the adjustment. If the carriage-return latch is tripped too soon, position the carriage-return latch tripping arm clockwise. If the carriage-return latch is tripped too late, position the carriage-return latch tripping arm counterclockwise. Tighten both machine screws. Check related adjustment (par. 312).



A



B




C

TM5815-200-35-114

Figure 326. Decelerating cam and carriage-feed clutch positioning adjustment. (Superseded)

Page 379, figure 328. Below the callout "COLLAR" insert a callout indicating a maximum of 0.010-inch clearance between the ball bearing and the collar.



TM2246-C7-43

Figure 328.1. Carriage-return safety clutch and play adjustment. (Added)

Paragraph 307. Below the heading add:

Note. Perform the adjustment in paragraph 308 before proceeding with the following adjustment.

Delete subparagraph *a* and substitute:

a. Requirement. The clearance between the collar and the ball bearing should not exceed the maximum of 0.010 inch when the shoulder on the carriage rack drive shaft is tight against the ball bearing.

Subparagraph *c*. Delete the last sentence and substitute: Hold the carriage rack drive shaft in this position, and measure the clearance between the ball bearing and the collar with a 0.005-inch feeler gage; remove the gage.

After paragraph 307 add:

307.1. Carriage-Return Safety Clutch End Play Adjustment (fig. 328.1)

Note. Perform the following adjustment only when the carriage-return shaft assembly has been removed.

a. Requirement. There should be from 0.001- to 0.010-inch end play of the carriage-return safety clutch assembly on the carriage-return shaft.

b. Method of Checking. Attempt to move the carriage-return safety clutch assembly back and forth along the carriage-return shaft. Check the end play between the driven member and the driving member. If no end play is present, check the carriage-return safety clutch assembly for free rotation.

c. Adjustment. Remove the carriage-return safety clutch from the carriage-return shaft. Install or remove any combination of the 0.005 (52117) and 0.010 (52118) spacers until the requirement is met. Reassemble the safety clutch on the shaft and check the requirement. Reshim if necessary.

Page 380, paragraph 308b(1). After the last sentence add: Make adjustment as described in paragraph 310 before tightening the clamping screw on the carriage-return clutch actuating lever.

Delete paragraph 309 and substitute.

309. Carriage-Return Horizontal Link Adjustment (fig. 330)

Note. Perform the adjustment in paragraph 310 before proceeding with the following adjustment.

a. Requirement. The carriage-return clutch should be fully engaged before the carriage-return sensing lever strikes the lowest portion of the restoring cam, and the carriage-feed clutch should not bounce when characters other than carriage-return are selected.

b. Method of Checking. Press the space bar and the repeat key. While the carriage is moving to the right, watch the carriage-feed clutch. The clutch should remain fully closed while the carriage is moving. With the carriage at least one or more spaces from the left-hand margin, turn off the motor. Select any key, except carriage-return, trip the transfer lever latch, and turn the motor by hand until the carriage-return sensing lever contacts the carriage-return stop bar. Rotate the double-locking lever so that it just touches the carriage-return actuating lever.

c. Adjustment. Select any character, except carriage-return. Trip the transfer lever latch and rotate the motor by hand until the carriage-return sensing lever contacts the carriage-return stop bar. Detach and adjust the horizontal carriage-return link so that when it is fitted over the stud on the carriage-return bellcrank, the double-blocking lever is just touching the carriage-return clutch actuating lever.

Paragraph 310, Subparagraph *a.* Delete "There should be .001- to .005-inch clearance" and substitute: There should be some clearance, not exceeding 0.005 inch.

Delete subparagraph *c* and substitute the following:

c. Adjustment. Disconnect the carriage-feed clutch lever spring and the horizontal carriage-return link. Manually hold the carriage-return clutch members closed. Loosen the carriage-return clutch actuating lever clamping screw and rotate the lever to meet the requirement. Hold the carriage-return clutch actuating lever down against the shaft collar and tighten the clamping screw. Reconnect the carriage-feed clutch lever spring, and make the adjustment described in paragraph 309. Check related adjustments (pars. 312, 315, and 317).

Page 381. Delete paragraph 311. Delete figure 332.

Paragraph 312, heading. Below the heading. Add:

Note. Perform the adjustment in paragraph 315 before proceeding with the following adjustment.

Subparagraph *c.* After the second sentence add: Check the related adjustment (par. 308) before tightening the clamping screw.

Page 382, paragraph 314a, line 1. Change ".005- to .015" to: **0.010- to 0.020.**

Paragraph 315a, line 1. Change ".025- to .035" to: **0.015- to 0.025.**

Figure 335, callout. Change "005" to .015"" to: **0.010" to 0.010".**

Figure 336, callout. Change ".025" to .035"" to: **0.015" to 0.025"**

Page 387. Add paragraph 324.1 after paragraph 324.

324.1. Platen Trough End Play Adjustment (fig. 344.1)

a. Requirement. Hold the platen trough and the platen shaft to the left. Clearance between the platen trough and the platen should be from 0.002 to 0.005 inch.

b. Adjustment. Loosen the two setscrews that hold the platen to the platen shaft. Position the platen to meet the requirement. Tighten the setscrews. Recheck the requirement.




Figure 344.1. Platen trough end play adjustment.
(Added)

Page 389. Delete paragraph 326 and substitute:

326. Sprocket Feed Pin Load Adjustment (fig. 346)

a. *Requirement.* It should require from 30 to 60 ounces of torque to protract or retract the pinwheel pins.

b. *Method of Checking.* Insert the L-shaped end of a spring scale in one of the slots of the

remove shims (55169) to meet the requirement. Reassemble the platen as described in paragraph 155b. Check related adjustments (pars. 328, 325, 337, 336, and 335).

Paragraph 328a(1), line 3. Change "9/32" to: 9/16.

Page 391. Add paragraph 332.1 after paragraph 332.

332.1. Letters Shift Lever Shaft End Play Adjustment (fig. 352.1)




Figure 350. Platen shift preliminary adjustment.
(Superseded)

sprocket cam plate. Turn the platen crank to protract and retract the sprocket feed pins.

c. *Adjustment.* Remove the platen as described in paragraph 155a. Remove the retainer rings (5 and 13, fig. 205). Install or


a. *Requirement.* The letters shift lever and the platen latch should be in visual alignment. The carriage-feed lever and the support lever should be in visual alignment. There should

be clearance up to a maximum of 0.005 inch between the collar and the carriage-feed lever.

b. Adjustment. Hold the letters shift lever so that it is parallel with the function bracket

stop screw and the lower surface of the platen frame.

c. Adjustment. Loosen the clamping screw on the platen blocking arm, position the platen blocking arm to meet the requirement, tighten



TM5815-206-35-124

Figure 352.1. Letters shift lever shaft end play adjustment. (Added)

while the adjustment is being made or measured. Hold the letters shift lever shaft against the function bracket and loosen the setscrews in the collar. Position the collar to meet the requirement. Tighten the setscrews.

Page 392. Delete paragraph 334 and substitute:

334. Platen Blocking Arm Adjustment (fig. 354)

a. Requirement. There should be from 0.010- to 0.020-inch clearance between the platen stop screw and the lower surface of the platen frame when the platen is moved to the letters shift position and then pushed upward manually.

b. Method of Checking. Move the platen to the letters shift position. Check to be sure that the platen blocking arm is latched by the platen lower case latch. Push upward on the platen and insert a flat feeler gage between the platen

the clamping screw, and recheck the requirement.

After paragraph 334 add:

334.1. Platen Blocking Arm Adjustment (fig. 354.1)

a. Requirement. There should be from 0.005 to 0.020-inch clearance between the figures shift sensing lever and the platen lower case latch when other than the figures or letters combination is selected and when figures shift sensing lever drops off the high portion of its restoring cam and is blocked by the figures stop bar.

b. Method of Checking. Select a combination other than letters or figures. Trip the transfer lever latch by hand. Rotate the motor until the figures shift sensing lever drops off the high portion of its restoring cam and is blocked by the figures stop bar. Measure the clearance between the figures shift sensing lever and the platen lower case latch.

c. *Adjustment.* Loosen the mounting screws of the platen blocking arm bracket. Move the platen blocking arm bracket until the require-

of 40 ounces applied to the upper arm of the line feed lever should not pre-




Figure 354. Platen blocking arm adjustment. (Superseded)




Figure 354.1. Platen blocking arm bracket adjustment. (Added)

ment is met. Tighten the mounting screws. Recheck the requirement.

Paragraph 335. Below the heading add:

Note. Perform the adjustment in paragraph 336 before proceeding with the following adjustment.

Delete subparagraph a(1) and substitute:

- (1) While the teletypewriter is receiving line feed code groups, a forward pull

vent the line feed mechanism from turning the platen one line space when the single-double line feed lever is in the single-line feed position, or two line spaces when the single-double line feed lever is in the double-line feed position.




Figure 355. Line feed bellcrank and line feed connecting link adjustments. (Superseded)




Figure 355.1. Line feed detent adjustment. (Added)
Delete paragraph 336 and substitute:

336. Line Feed Bellcrank Adjustment (fig. 355)

Note. Perform the adjustment in paragraph 337 before proceeding with the following adjustment.

a. Requirement. Clearance between the roller on the line feed cam follower and the line feed cam should be at least 0.010 inch, when the line feed sensing lever is released and pulled to the low part of its restoring cam.

b. Method of Checking. Select the line feed code group. Trip the transfer lever latch and turn the motor by hand until the line feed sensing lever is pulled to the low part of its restoring cam. The roller on the line feed cam

follower should move under the line feed cam. Pull the line feed cam follower toward the rear of the unit. Check the requirement with a feeler gage at both low points of the line feed cam.

c. Adjustment. Loosen the screw and locknut on the line feed bellcrank. Position the adjustable arm of the bellcrank to meet the requirement. Tighten the locknut and recheck the requirement at both low points of the line feed cam. Check the related adjustment (par. 335).

Page 393. Delete paragraph 337 and substitute:

337. Line Feed Detent Adjustment (fig. 355.1)

a. Requirement. The line feed pawl should seat fully into one of the notches of the detent wheel when the single-double line feed lever is in the double-line feed position and the line feed connecting link is moved slowly toward the rear of the teletypewriter.

b. Method of Checking. Move the line feed connecting link manually toward the rear of the teletypewriter and check the requirement as the line feed pawl moves into a notch in the detent wheel.

c. Adjustment. Loosen the nut that holds the detent eccentric stud to the platen trough. Turn the eccentric stud until the requirement is met. Tighten the nut and recheck the requirement. Check the related adjustment (par. 335).

Paragraph 338. Below the heading add:

Note. Perform the adjustment in paragraph 356 before proceeding with the following adjustment.

Subparagraph *a.* Designate the existing material after the heading "(1)" and add the following:

- (2) When the letters shift button is depressed, clearance between the tip of the platen latch and the projection on the aperture gate should be at least 0.015 inch.
- (3) When the platen is in the figures position, the platen latch should disengage each time the button is pressed.

a.1. Method of Checking.

- (1) Put the manual letters shift mechanism in the unoperated position. Check the requirement.
- (2) Put the platen in the figures position. Press the shift button. Position the tip of the platen latch horizontal with the projection on the aperture gate. Check the requirement.
- (3) Put the platen in the figures position. Press the shift button. The platen should drop to the letters position.


Delete paragraph 340 and substitute:

340. Carriage-Feed Shaft Driving Collar Adjustment
(fig. 358)

a. Requirement. The friction clutch assembly should be compressed against the carriage-feed ratchet with a 1- to 1½-pound pressure.

b. Adjustment. Loosen the setscrews in the driving collar. Apply a 1¼-pound pressure on the end of the carriage-feed shaft and against the drive collar; tighten the setscrews.

After paragraph 340 add:



TM2246-C7-46

Figure 356. Manual unshift lever link adjustment.
(Superseded)

Subparagraph *b.* Designate the existing material after the heading "(1)" and add the following:

- (2) If necessary, to meet requirements in *a*(2) and (3) above, form the tip of the letters shift lever that touches the platen latch.

Paragraph 339*a.* Delete subparagraph *a* and substitute:

a. Requirement. The end of the ratchet wheel and the end of the flat on the shaft should be visually flush.

Figure 357. Delete the callout ".010" TO .020".

340.1. Carriage-Feed Driving Gear End Play Adjustment
(fig. 358.1)

a. Requirement. There should be a 0.001- to 0.005-inch clearance between the flat washer and the shoulder on the carriage-feed shaft when the carriage-feed driving gear is held tight against the ball bearing.

b. Method of Checking. Push the carriage-feed clutch drum back and hold the carriage-feed driving gear tight against the ball bearing. Check the clearance with a feeler gage.

c. Adjustment. Loosen the self-locking hexagonal nut on the rear of the carriage-feed

shaft. Rotate the adjusting nut clockwise or counterclockwise until the requirement is met. Tighten the self-locking hexagonal nut and recheck the clearance.

gear should be centered with the carriage-feed worm on the main shaft.

b. *Adjustment.* Loosen the setscrews in the




Figure 358. Carriage-feed shaft drive collar adjustment. (Superseded)




Figure 358.1. Carriage-feed driving gear end play adjustment. (Added)

Page 394. Delete paragraph 341 and substitute:

341. Carriage-Feed Driven Gear Adjustment (fig. 359)

a. *Requirement.* The carriage-feed driven

shaft collar. Push the carriage-feed driven gear forward until it is tight against the carriage-feed worm. Measure the distance Y as shown.

Pull the carriage-feed driven gear rearward until tight and measure the distance X as shown. Divide the difference of the measurement by two, and add it to distance X. Use this dimension and position the carriage-feed driven gear. Slide the shaft collar against the carriage-feed driven gear and tighten the setscrews in the shaft collar.




Figure 359. Carriage-feed driven gear adjustment. (Superseded)

Add paragraphs 341.1 and 341.2 after paragraph 341.

341.1. Feed Pawl End Play Adjustment (fig. 359.1)

a. Requirement. Clearance between the feed pawl and the spacer on the feed pawl stud, while the feed pawl is held against the self-locking hexagonal nut, should be a maximum of 0.004 inch, without binding.

b. Method of Checking. Disconnect the feed pawl spring and the carriage-feed link from the feed pawl. Rotate the feed pawl manually and check for binding. Hold the feed pawl toward the self-locking hexagonal nut. Check the 0.004-inch maximum clearance with a feeler gage.

c. Adjustment. Disconnect the feed pawl spring and the carriage-feed link from the feed pawl. Remove the self-locking hexagonal nut, washer, and feed pawl from the bracket. Peel the spacer to meet the requirement, or insert a new spacer. Reassemble the feed pawl, washer, and self-locking hexagonal nut. Recheck the requirement. Connect the feed pawl spring and the carriage-feed link.

341.2. Feed Pawl Alignment (fig. 359.2)

a. Requirement. The feed pawl should be centered on the ratchet, and should engage the teeth of the ratchet squarely.

b. Method of Checking. Check the requirement visually.

c. Adjustment. Loosen the two machine screws that hold the feed pawl bracket to the chassis. Position the feed pawl bracket to meet the requirement. Tighten the machine screws and recheck the requirement. Check related adjustments (pars. 323 and 304).




Figure 359.1. Feed pawl end play adjustment. (Added) Paragraph 342a, line 2. Change "40" to: 44.

Figure 360. Change the callout "40 TO 48 OZ" to: 44 TO 48 OZ.




Figure 359.2. Feed pawl adjustment. (Added)

Page 395, paragraph 344. Below the heading add:

Note. Perform the adjustment in paragraph 345 before proceeding with this adjustment.

After paragraph 344 add:

344.1. Print Bail End Play Adjustment (fig. 363.1)

a. *Requirement.* When the print bail assembly is held toward the printer side casting, clearance between the print bail assembly and the bearing in the printer center function shaft bearing cap should not exceed 0.005 inch, with no binding.

b. *Method of Checking.* Take up the end play of the print bail assembly toward the printer side casting. Measure the clearance.

c. *Adjustment.* Loosen the sockethead clamping screw in the print cam follower. Position the print bail assembly to meet the requirement. Tighten the sockethead clamping screw. Recheck the requirement. Check the requirements of the related adjustment (par. 344).




Figure 363.1. Print bail end play adjustment. (Added)

Page 400. Delete paragraph 355 and substitute:

355. Margin Signal Bell and Bracket Adjustment (fig. 371)

a. *Requirements.*

- (1) The margin signal bell should ring when the carriage is 66 spaces from the left-hand margin (70 spaces on weather machines).
- (2) There should be a clearance of 0.020 to 0.025 inch between the margin bell pawl and the pawl tripping arm when the carriage is 66 spaces from the left-

hand margin (70 spaces on weather machines).

b. *Method of Checking.*

- (1) Turn the motor on and space the carriage 65 spaces from the left-hand margin (69 spaces on weather machines). Press any of the character keylevers once; the margin bell should ring.
- (2) With the carriage 66 spaces from the left-hand margin (70 spaces on weather machines), move the margin bell clapper up and down to determine the closest point between the margin bell pawl and the pawl tripping arm. Check the clearance at the closest point.

c. *Adjustment.*

- (1) Loosen the two nuts that hold the pawl tripping arm to the carriage-rack driving gear, position the arm to meet the requirement (a(1) above), and tighten the nuts.
- (2) Loosen the machine screws that hold the margin bell bracket to the page printer frame. Position the bracket to meet the requirements (a(2) above) and tighten the screws.




Figure 371. Margin signal bell and bracket adjustment. (Superseded)

Figure 372. Change the callout ".040" TO 060"" to: ".002" TO .010". Change "MOTOR STOP ACTUATING LEVER" to: **MOTOR STOP FUNCTION LEVER.**

Delete paragraph 356 and substitute:

356. Motor Stop Contacts Bracket Adjustment (fig. 372)

Note. This adjustment does not apply to teletypewriters which are adjusted to make the motor stop function inoperative.

a. Requirement. There should be a 0.002- to 0.010-inch clearance between the motor stop function lever and the damper leaf spring when the platen is in the letters shift position and movement of the motor stop function lever is taken up in the direction of the damper leaf spring.

b. Adjustment. Place the platen in the letter shift position. Loosen the bracket mounting screws, position the switch bracket to obtain the required clearance, and tighten the screws. Recheck the requirement.

After paragraph 356 add:

356.1. Motor Stop Disabling Adjustment (fig. 372.1)

Note. This adjustment should be performed only to make the motor stop function inoperative.

a. Requirement. The motor should continue operating when an H-code group is received while the teletypewriter is in the figures shift position.

b. Adjustment. Loosen the two bracket mounting screws, position the switch bracket to obtain the greatest possible clearance between the damper leaf spring and the motor stop function lever, and tighten the mounting screws. Recheck the requirement.

Page 401. Delete paragraph 358 and substitute:

358. Signal Bell Clapper Preliminary Adjustment (fig. 374)


a. Requirements.

- (1) With the teletypewriter in the stopped position, the clapper stud should be vertical.
- (2) With the teletypewriter in the stopped position, there should be a clearance not exceeding 0.050 inch between the signal bell clapper and the clapper stop.

b. Method of Checking. Remove the upper locknut and the signal bell. With the teletype-

writer in the stopped position, check the requirements. Perform the margin signal bell adjustment (par. 355) when reinstalling the signal bell.

c. Adjustment. Remove the upper locknut and the signal bell. Loosen the lower locknut and position the clapper stop to meet requirement in *a*(1) above. Tighten the lower locknut and recheck the requirement (*a*(1) above). Readjust if necessary. With the teletypewriter still in the stopped position, form the signal bell clapper to meet requirement in *a*(2) above. Replace the signal bell and locknut as described in paragraph 355.



TM5815-200-35-C2-29

Figure 374. Signal bell clapper preliminary adjustment. (Superseded)

Page 402. Delete paragraph 359b and substitute:

b. Adjustment. Loosen the upper locknut on the mounting stud. Position the signal bell so that the mounting stud is centered in the elongated hole. Tighten the locknut and check the requirements. If necessary, reposition the signal bell in any direction to meet the requirements. If the requirement in *a*(1) above cannot be met by repositioning the signal bell, decrease the clearance between the clapper and the clapper stop (par. 358).




Figure 375. Signal bell adjustment. (Superseded)

Page 403, paragraph 363a, line 3. Change ".003-inch" to: 0.005-inch.

Delete paragraph 364 and substitute:

364. Stop Selector Lever Latch and Transmitter Contact Adjustment (TT-117/FG, TT-117A/FG, TT-118/FG, TT-119/FG, and TT-119A/FG)
(fig. 380)

a. Requirements.

- (1) There should be a minimum break in the send circuit between successive marking impulses.
- (2) The stop selector lever latch should be adjusted to give a minimum break in the send circuit between the marking fifth intelligence impulse and the stop impulse. There should be a 0.005-inch minimum clearance between the stop selector lever and the stop selector lever latch when the stop selector lever is on the low part of its cam.

b. Method of Checking.

- (1) Use Distortion Test Set TS-383/GG to measure the signal transmitted by the teleprinter.

- (2) Connect a milliammeter in series with the send circuit. Press the LTRS key-lever and slowly turn the motor by hand. There should be slight, but minimum, breaks between the successive marking impulses.
- (3) Connect a milliammeter in series with the send circuit. Press the T-key-lever and turn the motor slowly by hand. There should be a slight, but minimum, break between the marking fifth intelligence and the stop impulse. With the stop selector lever on the low part of its cam, check the clearance between the stop selector lever and the stop selector lever latch with a feeler gage.

c. Adjustment.

- (1) Loosen the machine screws. Turn the motor on and push the REPEAT key and blank key. With a screwdriver in the notch of the selector lever latch and the latch bracket, move the selector lever latch to obtain the required stop signal length on a TS-383/GG. Move to the left to decrease and to the right to increase pulse length; tighten the screws and recheck the signal length.
- (2) Connect a milliammeter in series with the send circuit. Press the LTRS key-lever and slowly turn the motor by hand. Adjust (by turning) the mark stationary contact in or out until the requirement of a (2) above is met.
- (3) With the milliammeter connected in series with the send circuit, loosen the machine screws that hold the stop selector lever latch. Press the T-key-lever and slowly turn the motor by hand. Move the selector lever latch to the right or left until a slight but minimum break is obtained between the marking fifth intelligence impulse and the stop impulse. Move the selector lever latch to the right to decrease the break and to the left to increase the break. With the stop selector lever against the low part of its cam, check the clearance between the stop selector lever and the selector lever latch. If

the clearance is less than 0.005 inch, remake the adjustment described in paragraph 363. Reposition the selector lever latch to meet the requirement of *a*(2) above. Tighten the two machine screws and recheck the requirement.




Figure 390.1. Transmitter camshaft end play adjustment. (Added)

Page 409. After paragraph 374 add:

374.1. Transmitter Camshaft End Play Adjustment
(fig. 390.1)

a. Requirement. There should be 0.001- to 0.005-inch clearance between the clutch yoke hub and the adjacent ball bearing when the cam end of the transmitter camshaft is pressed toward the keyboard frame casting.

b. Adjustment. Loosen the setscrews in the clutch fork and insert a 0.003-inch feeler gage between the clutch yoke hub and the bearing. Press the transmitter camshaft and clutch fork toward each other; align the setscrews with the flats on the camshaft and tighten the setscrews. Remove the feeler gage. Recheck the requirement.

Page 410, paragraph 377*a*, line 2. Change ".010-inch" to: **0.020-inch**. Line 4. Change the comma to a period and delete "with maximum clearance of .025 inch between the ratchet wheel and line indicator drive shaft."

Subparagraph *b*. Delete the last sentence. Delete subparagraph *c* and substitute.

c. Adjustment. Loosen the setscrews and rotate the ratchet wheel until the requirement is met. Tighten the setscrews. Recheck the requirement.

Figure 393. Delete the callout ".025" MAX."




Figure 400.1. Indicator return spring tension adjustment, (Except TT-117/FG, and TT-119/FG). (Added)

Page 414. After paragraph 385 add:


385.1. Indicator Return Spring Tension Adjustment
(Except TT-117/FG, and TT-119/FG)
(fig. 400.1)

a. Requirement. The indicator carriage should return to the left-hand margin from only one space out when the carriage-return is selected.


b. Adjustment. With the indicator carriage all the way to the left, loosen the support stud retaining screw until the drive shaft support stud stops unwinding counterclockwise. Wind the support stud clockwise 22 turns ± 2 . Use the hole in the knurled surface of the support stud as a reference when counting turns. Tighten the support stud retaining screw; be careful not to let the drive shaft unwind. Recheck the requirement.

Paragraph 386*a*, line 4. Change "some clearance not more than .005 inch" to: **0.003- to 0.010-inch clearance**.

Figure 401. Change the callout ".005" to: **.003" to .010"**.



A




B


TM2246-C7-49

Figure 402. Lower pulse switch contact adjustment.
(Superseded)


AGO 5869A



A



B



C

TM2246-C7-85

Figure 402.1. Preliminary pulse switch adjustment.
(Added)




Figure 402.2. Lower pulse switch contact adjustment. (Added)

Page 415. Delete paragraph 387 and substitute:

387. Lower Pulse Switch Contact Adjustment (fig. 402)

a. Requirements.

- (1) There should be 30 to 45 grams pressure between the contacts.
- (2) There should be 0.028- to 0.037-inch clearance between the contacts closest to the plunger when the plunger is pushed against the bushing.
- (3) There should be 0.010- to 0.015-inch clearance between the contacts farthest from the plunger when the plunger is pushed against the bushing.

b. Adjustment.

- (1) Bend the spring contact to meet the requirement in a(1) above.
- (2) Remove or add shim washers under the head of the plunger as required.
- (3) Bend the spring contact to meet the requirement in a(3) above.

Add paragraphs 387.1 and 387.2 after paragraph 387.

387.1. Pulse Switch Preliminary Adjustment (fig. 402.1)

Note. This adjustment applies to teletypewriter sets supplied with keyboard contact assembly 61698A.

a. Requirements.

(1) Normally open contacts.

- (a) There should be $\frac{3}{32}$ -inch $\pm \frac{1}{64}$ clearance between the mounting plate and the inside movable contact (A, fig. 402.1). The contact buttons should just touch.

- (b) There should be 0.015- to 0.020-inch clearance between each of the two sets of normally open contacts.

(2) Normally closed contacts.

- (a) There should be $\frac{7}{32}$ -inch $\pm \frac{1}{64}$ clearance between the mounting plate and the inside movable contact (A, fig. 402.1). There should be 0.003- to 0.015-inch clearance between the buttons of the movable contacts.
- (b) It should require a pull of 30 to 45 grams to open each of the two sets of stationary contacts (A, fig. 402.1).
- (c) When the inside movable contact has been moved to a position $1\frac{7}{64}$ -inch $\pm \frac{1}{64}$ away from the mounting plate (B, fig. 402.1), there should be 0.015-inch minimum clearance between each of the two sets of stationary contacts. The outside movable contact should just touch the outside stiffener and there should be 0.003- to 0.015-inch clearance between the rivet heads (B, fig. 402.1).
- (d) It should require a maximum force of $3\frac{1}{2}$ ounces to move the normally open movable contacts against the outside stiffener (C, fig. 402.1).

b. Method of Checking.

(1) Normally open contacts.

- (a) Check the $\frac{3}{32}$ -inch dimension in a(1)(a) above with a 6-inch steel rule. Check the position of the contact buttons visually.
- (b) Check the requirement in a(1)(b) above with a feeler gage.

(2) Normally closed contacts.

- (a) Check the $\frac{7}{32}$ -inch dimension in a(2)(a) above with a 6-inch steel rule. Check the clearance between the buttons of the movable contacts with a feeler gage.
- (b) Check the requirement in a(2)(b) above with a gram scale.
- (c) Position the inside movable contact to meet the requirement in a(2)(c) above and check the clearance between each of the two sets of contacts with a feeler gage. Check the

position of the outside movable contact visually. Check the clearance between the rivets with a feeler gage.

- (d) Check the requirement with a spring scale.

c. Adjustments.

(1) *Normally open contacts.*

- (a) Form the inside movable contact to meet the $\frac{3}{32}$ -inch $\pm\frac{1}{64}$ requirement. Form the outside movable contact to meet the requirement for the contact buttons.
- (b) Form the stiffeners to position them against each normally open contact to meet the requirement.

(2) *Normally closed contacts.*

- (a) Form the inside movable contact to meet the $\frac{7}{32}$ -inch $\pm\frac{1}{64}$ requirement. Form the outside movable contact to meet the clearance requirement.
- (b) Form the stationary and movable contacts of each set equally to meet the requirement in a(2)(b) above. Recheck the requirement in a(2)(a) above.
- (c) Position the inside movable contact to meet the requirement in a(2)(c) above and form the stiffener of each of the two sets of stationary contacts to meet the clearance requirement. Form the outside stiffener to meet the requirement. It may be necessary to file the rivet heads to meet the clearance requirement. Recheck the requirements in a(2)(a) and (b) above.
- (d) Check the requirement of a(2)(d) above. If the reading exceeds the requirement, adjust the stationary contacts to meet the low figure of the tolerance given in a(2)(b) above. Check requirement in a(2)(a) above.

Note. After the switch is installed, perform related adjustments (pars. 387, 387.2, and 397).

387.2. Lower Pulse Switch Contact




Adjustment

(fig. 402.2)

Note. This adjustment applies to teletypewriter sets supplied with keyboard contact assembly 61698A.

a. Requirement. The outside movable contact should just touch the outside stiffener when the plunger is pushed tight against the bushing.

b. Adjustment. Remove or add shim washers under the head of the plunger as required.



TM2246-C7-51

Figure 404. Lower pulse switch adjustment. (Superseded)

Page 416. Delete paragraph 389 and substitute:

389. Lower Pulse Switch Adjustment (fig. 404)

Note. When adjusting teletypewriter sets procured subsequent to and including Order No. 42770-PC-59-C5-51, perform the adjustments described in paragraphs 387.1 and 387.2 before proceeding with the following instructions.

a. Requirements.

- (1) When the switch cam lever is held tight against its bearing and the switch cam follower is held against the switch cam lever, there should be a maximum of 0.010-inch end play in the switch arm shaft.
- (2) When the cam stop lever is resting on the locking lever latch there should be 0.010- to 0.015-inch clearance between the contacts farthest from the plunger.
- (3) When the contacts farthest from the plunger have just closed, there should be 0.013- to 0.027-inch clearance between the contacts closest to the plunger.

Note. Requirement (3) above does not apply to teletypewriter sets supplied with keyboard contact assembly 61648A.

b. Adjustments.

- (1) Loosen the switch arm clamping screw to meet the requirement in a(1) above.
- (2) Rotate the switch arm to meet the requirement in a(2) above. Tighten the switch arm clamping screw. Recheck the requirement in a(1) above.
- (3) Set the cam stop lever in the tripped position and actuate the plunger with the finger until the contacts farthest from the plunger have just closed. Check the gap of the contacts closest to the plunger. Bend stationary contact to meet the requirement in a(3) above.

Page 418 paragraph 396c, line 4. Change ".050'" to: .010-inch.

Figure 411. Change the callout ".050'" to: .010" TO .030".

Page 419. Delete paragraph 400 and substitute:

400. Transmitter Friction Clutch Adjustment (fig. 415)

a. Requirements.

- (1) There should be 0.005- to 0.025-inch clearance between the friction clutch disk and the bearing of the friction clutch yoke.
- (2) It should require 25 to 30 ounces to keep the friction clutch yoke from turning when the motor is running.

b. Method of Checking.

- (1) Insert a flat feeler gage between the friction clutch disk and the bearing of the friction clutch yoke to determine the clearance.
- (2) With the motor on, hook a spring scale on the yoke. Depress the spacebar and read the scale.

c. Adjustments.

- (1) Loosen the two setscrews in the friction clutch disk and position the disk until the requirement of a(1) above is met. Tighten the setscrews.
- (2) With the motor off, loosen the clamping screws in the friction adjusting collar. Turn the friction adjusting collar in or out to meet the requirement; tighten the clamping screws. Turn the motor on and recheck the tension.





Figure 415. Transmitter friction clutch adjustment.
(Superseded)



TM5815-200-35-C2-32


Figure 417.1. Dust cover guide adjustment. (Added)

Page 420. After paragraph 402. Add:

402.1. Dust Cover Guide Adjustment (fig. 417.1)

a. Requirement. The dust cover guides should just touch the inside of the dust cover.

b. Adjustment. Loosen the two screws on each dust cover guide. Push both of the guides out as far as they will go. Tighten the screws but leave them loose enough so that the dust cover guides can be moved. Put the dust cover on. This will position the guides into place. Remove the dust cover and tighten the screws. Recheck the requirement.



TM2225-59

Figure 421.1 Sequential T-lever pivot stud adjustment. (Added)

Page 422. Add paragraphs 407.1 and 407.2 after paragraph 407.

407.1. Sequential T-Lever End Play Adjustment (fig. 322.2)

a. Requirement. End play of the T-levers on the T-lever stud should not exceed 0.003 inch.

b. Method of Checking. Measure the clearance between the first T-lever and the flat washer, with the end play of the T-levers taken up toward the transfer lever.

c. Adjustment. Remove the hexagonal nut, flat washer, and first T-lever. Add or remove shims (57072 and 57073) to meet the requirement. Replace the bottom T-lever, flat washer, and hexagonal nut. Tighten the hexagonal nut and recheck the requirement.

407.2. Sequential T-Lever Pivot Stud Adjustment (fig. 421.1)

a. Requirement. The T-levers should engage the Y-levers an equal amount for both mark and space positions of the Y-levers.

b. Method of Checking. With the transfer lever latched, set the No. 1 Y-lever in a mark position. Trip the transfer lever so the T-levers engage the Y-levers. Visually check the amount of engagement. Reposition the transfer lever and the T-levers by turning the motor by hand. Set the No. 1 Y-lever in a space position, trip the transfer lever and visually check the amount of engagement.

c. Adjustment. Loosen the self-locking hexagonal nut on the rear of the T-lever pivot stud. Position the pivot stud until the requirement is met. Tighten the nut and recheck the adjustment. Note the normal direction of maximum eccentricity in figure 421.1.

Paragraph 408, chart. After the first item. Add:

Adjustment	Par. ref.	Fig. ref.
Y-lever retaining collar adjustment	296	291

Page 423 paragraph 410. After subparagraph *a* add:

a.1. Method of Checking.

- (1) With the motor on, select the blank code group. Insert a 0.006-inch feeler gage between the Y-levers and the Y-lever eccentric stop. Select the letters code group and check the requirement.

- (2) With the motor on, select the blank code group. Insert a 0.002-inch feeler gage between the Y-levers and the Y-lever eccentric stop. Select the letters code group and check the requirement.

Paragraph 411a, line 3. Change “.018-inch” to: **0.015**.

After subparagraph *a* add:

a.1. Method of Checking. Position the selector camshaft so that the selector levers are not operated. Place the armature in mark position and check the requirement with feeler gages.

After paragraph 411. Add:

411.1. Sequential Y-Lever Pivot Post Stud Positioning Adjustment (fig. 424.1)

a. Requirement. The Y-lever pivot post stud should be positioned in the normal direction of maximum eccentricity within $\pm 10^\circ$ as shown.

b. Adjustment. Loosen the Y-lever pivot post stud setscrew. Use the screwdriver slot in the Y-lever pivot post stud as reference to indicate the normal direction of maximum eccentricity. Position the post to meet the requirement. Tighten the setscrew. Check related adjustments (pars. 407.2, 412, 419, and 424).





Figure 424.1. Sequential Y-lever pivot post stud positioning adjustment. (Added)

Page 427. After paragraph 420 add:

420.1. Code Actuated Switch Function Camshaft Gear End Play Adjustment (fig. 431.1)

a. Requirement. There should be a 0.005-inch maximum clearance between the flat washer and the inner race of the ball bearing when the function camshaft gear is held against the retainer ring farthest from the clutch teeth.

b. Method of Checking. Hold the function camshaft gear against the retainer ring farthest from the clutch teeth and check the requirement with a feeler gage.

c. Adjustment. Disassemble the function shaft (par. 272a) to gain access to the function camshaft gear. Remove the retainer ring and install or remove any combination of the 0.010-inch thickness or 0.005-inch thickness (55034 or 55035) flat washers to meet the requirement. Reinstall the retainer ring. Make sure it is seated properly in the groove in the function shaft. Recheck the requirement. Reassemble the function shaft. Check related adjustments (pars. 421–425).




Figure 431.1. Code actuated switch function camshaft gear end play adjustment. (Added)

Page 428. Delete paragraph 422 and substitute:

422. Code Actuated Switch Function Shaft Clutch Adjustment (fig. 432)

a. Requirement. There should be 0.080- to 0.100-inch clearance between the clutch coupling and the sliding clutch drum when the slid-

ing clutch drum is fully engaged with the function camshaft gear.

b. Method of Checking. Check the requirement in *a* above with a feeler gage.

c. Adjustment. Trip the transfer lever trip latch and turn the motor by hand until the sliding clutch drum has fully engaged the function camshaft gear. Loosen the setscrews in the clutch coupling and shift the coupling in the proper direction to meet the requirement in *a* above. Tighten the setscrews and recheck the requirement.

Paragraph 423a, line 1. Change ".008- to .012-inch to: 0.008- to 0.017-inch.




Figure 432. Code actuated switch function shaft clutch adjustment. (Superseded)

Figure 433. Change the callout ".008"-.012" to: .088"-.017".

Page 429. After paragraph 426 add:

426.1. Selector Camshaft Drive Collar Adjustment (Except TT-178/FG and TT-179/FG)
(fig. 436.1)

Note. Perform this adjustment only when removal of selector camshaft is necessary.

a. Requirement. The end of the drive shaft collar should be flush (visual check) with the edge of the camshaft flat nearest the selector cam.

b. Adjustment. Loosen the machine screws on the friction clutch adjusting collar and back off the collar to relieve the spring tension. Re-

move the collar. Loosen the setscrews on the drive shaft collar and adjust to meet the requirement. Tighten the setscrews and reinstall the friction clutch adjusting collar. Perform related adjustment (par. 427).




Figure 436.1. Selector camshaft drive collar adjustment (except TT-178/FG and TT-179/FG). (Added)





Figure 436.2. Selector camshaft clutch load adjustment. (Added)

Page 430. Delete paragraph 427 and substitute:

427. Selector Camshaft Clutch Load

Adjustment

(fig. 436.2)

a. Requirements.

- (1) There should be 0.005- to 0.025-inch clearance between the friction clutch disk and the bearing of the friction clutch drive assembly.
- (2) It should require a pull of 48 to 54 ounces to hold the stop plate away from the stop lever with the motor on.

b. Method of Checking.

- (1) Insert a flat feeler gage between the friction clutch and the bearing of the friction clutch drive assembly to determine the clearance.


c. Adjustment.

- (1) Loosen the two setscrews in the friction clutch disk and position the disk until the requirement of a(1) above is met. Tighten the two setscrews.
- (2) Loosen the clamping screw of the friction clutch adjusting collar and turn the collar to meet the requirement in a(2) above. Tighten the clamping screw.

Page 431. Delete paragraph 430 and substitute:

430. Code-Ring End Play Adjustment

(fig. 437.1)



TM2225-42

Figure 437.1. Code-ring end play adjustment. (Added)

- (2) Place the hook end of the spring scale on the stop plate retainer of the selector camshaft. Pull on the spring scale until the stop plate moves away from the stop lever. Read the scale.

Note. Perform the adjustment in paragraph 297 before proceeding with the following adjustment.

a. Requirements.

- (1) There should be a 0.002- to 0.004-inch clearance between the code-ring collar and the ball retainer.

- (2) There should be a 0.002- to 0.010-inch clearance between the sleeve bearing and the code-ring cam follower locking lever.

b. Method of Checking.

- (1) Insert a flat feeler gage from the bottom of the code-ring cage between the code-ring collar and the ball retainer.
- (2) Insert a flat feeler gage from the bottom of the code-ring cage between the sleeve bearing and the code-ring cam follower locking lever.

c. Adjustment. Two setscrews secure the code-ring collar and the sleeve bearing to the shaft of the code-ring cage. One setscrew can be easily reached from the bottom side of the code-ring cage; the other can be reached between the top center stop bars and through the hole in the code-ring cage spacer.

- (1) Loosen the two setscrews and insert a 0.003-inch flat feeler gage between the ball retainer and the code-ring collar.
- (2) Hold the 0.003-inch flat feeler gage between the ball retainer and the code-ring collar while positioning the sleeve bearing to meet the requirement in a(2) above. Tighten the setscrews and recheck the clearance.




Figure 442.1 Multisolenoid Y-lever collar adjustment (except TT-178/FG and TT-179/FG). (Added)

Page 433. After paragraph 435. Add:

435.1. Multisolenoid Y-Lever Collar Adjustment (Except TT-178/FG and TT-179/FG).

(fig. 442.1)

a. Requirement.

- (1) There should be 0.002- to 0.005-inch clearance between the collar and the flat washer.
- (2) When the machine is equipped with a manual tape feed out link, position the collar for free movement of the manual tape feed out link.

b. Adjustment. Loosen the setscrew in the collar and position the collar to meet appropriate requirement above.





Figure 443.1. Multisolenoid Y-lever adjustment (except TT-178/FG and TT-179/FG). (Added)



TM2246-C7-56

Figure 444. Multisolenoid mounting bracket adjustment. (Superseded)

Page 434. After paragraph 436 add:

436.1. Multisolenoid Y-Levers Adjustment (Except TT-178/FG and TT-179/FG). (fig. 443.1)

a. Requirements.

- (1) In the mark position, there should be no clearance between the Y-levers and the straight pin.
- (2) In the space position, there should be no clearance between the Y-levers and the straight pin.

b. Adjustments.

- (1) Back out the mark adjusting screw of one of the multisolenoid plungers. Energize the multisolenoid in the mark position. This will place the Y-lever against the straight pin. Turn in the mark adjusting screw until the Y-lever begins to move away from the pin. Carefully back out the mark adjusting screw until the requirement in a(1) above is met. Repeat the adjustment for all five mark adjusting screws.
- (2) Back out the space adjusting screw of one of the multisolenoid plungers. Energize the multisolenoid in the space position. This will place the Y-lever against the straight pin. Turn in the space adjusting screw until the

Y-lever begins to move away from the pin. Carefully back out the adjusting screw until the requirement in a(2) above is met. Repeat the adjustment for all five space adjusting screws.

Note. Check multisolenoid operation in the teletypewriter by using an R-Y test message. If Y-lever bouncing is present, back out the associated mark or space adjusting screw slightly.

Delete paragraphs 437 and 438 and substitute:

437. Multisolenoid Mounting Bracket

Adjustment

(fig. 444)

a. *Requirement.* The multisolenoid bracket must be positioned on the perforator frame so the larger holes in the multisolenoid mounting bracket and the mounting holes in the frame are aligned.

b. *Adjustment.* Remove one of the three machine screws and lockwashers that hold the multisolenoid bracket to the perforator frame. Loosen the two remaining machine screws. Position the multisolenoid bracket visually to meet the requirement. Tighten the two machine screws and recheck the requirement. Readjust if necessary. Replace the machine screw and lockwasher.

438. Multisolenoid T-Lever Pivot Stud

Adjustment

(fig. 444.1)

a. *Requirement.* The T-levers should engage the Y-levers an equal amount for both mark and space positions of the Y-levers.

b. *Method of Checking.* With the transfer lever latched, set the No. 1 Y-lever in a mark position. Trip the transfer lever, causing the T-levers to engage the Y-levers. Visually check the amount of engagement. Reposition the transfer lever and the T-levers by turning the motor by hand. Set the No. 1 Y-lever in a space position, trip the transfer lever, and visually check the amount of engagement.

c. *Adjustment.* Loosen the self-locking hexagonal nut on the rear of the T-lever pivot stud. Position the pivot stud until the requirement is met. Tighten the nut and recheck the adjustment. Note the normal direction of maximum eccentricity in figure 444.

After paragraph 438. add:

438.1. Code-Ring Cage Adjustment (fig. 444.1)

a. Requirement. There should be no clearance between the code-ring tails and their corresponding stops in either marking or spacing positions.

b. Method of Checking. With the transfer lever latched, set the Y-levers for either the R- or Y-code combination. Then trip the transfer




Figure 444.1. Code-ring cage and T-lever pivot stud adjustment. (Added)

lever to cause the code rings to be positioned according to the Y-lever settings. Check the requirement visually.

c. Adjustment. Loosen the two code-ring cage mounting machine screws and position the code-ring cage to meet the requirement. Tighten the code-ring cage mounting machine screws. Recheck the requirement. If the position of the code-ring cage must be changed, check related adjustments (pars. 438, 440, 447, 455, 458, 459, 469, and 488).

Paragraph 440. Delete subparagraph *a* and substitute:

a. Requirement. There should be 0.005- to 0.010-inch clearance between the function sensing lever closest to its associated stop-bar when the cam lever is on the high part of its cam and none of the stop bars are in the selected position. Adjust the one that is closest to its stop bar.

Page 435, paragraph 440. After subparagraph *b* add:

Note. Ignore the clearance between the remaining sensing levers and associated stop bars, unless functional failures occur. Then replace the defective sensing lever or levers associated with the failure.

Paragraph 441. After subparagraph *a* add:

a.1. Method of Checking. Set up the proper code combination in the Y-levers. Trip the transfer lever latch and turn the motor by hand until the selected function sensing lever is adjacent to its function stop bar. Check the requirement with feeler gages.

Figure 446. At the top of the illustration, delete the two callouts ".015" TO .030". In the right center of the illustration, change the callout ".015" to .030" to: 0.010" TO 0.015".

Delete paragraphs 442 and 443 and substitute:

442. Simultaneous Transfer Lever Roller Stud Adjustment (fig. 448)

a. Requirement. There should be a 0.001- to 0.005-inch clearance between the transfer lever roller stud bearing and the transfer lever cam (as shown) when the T-levers and Y-levers are fully engaged.

b. Method of Checking. Select either the R- or Y-code group. Release the transfer lever and check the requirement with a feeler gage.

c. Adjustment. Select either the R- or Y-code group and release the transfer lever. Loosen the self-locking hexagonal nut and position the transfer lever roller stud in the normal direc-

tion of maximum eccentricity as shown. Turn the transfer lever roller stud in either direction until the requirement in *a* above is met. Tighten the nut and recheck the clearance.

443. Receiving Multisolenoid Function Shaft Driven Gear End Play Adjustment (fig. 449)

a. Requirement. There should be a 0.010-inch maximum clearance between the flat washer and the inner race of the ball bearing when the function shaft driven gear is held towards the casting.

b. Method of Checking. Hold the function shaft driven gear toward the casting and check the requirement with a feeler gage.

c. Adjustment. Disassemble the function shaft (par. 244a) clutch to gain access to the driven gear. Remove the retainer ring and install or remove any combination of the 0.010-inch or 0.005-inch flat washers (55034 or 55035) to meet the requirement. Reinstall the retainer ring. Make sure it is seated properly in the groove on the function shaft. Recheck the requirement. Reassemble the function shaft (par. 244b).




Figure 448. Simultaneous transfer lever roller stud adjustment. (Superseded)

Page 436. After paragraph 443 add:

443.1. Idler Gear Bracket Positioning Adjustment (fig. 449.1)

a. Requirement. There should be a minimum of backlash, without binding, between the idler

gear mounted on the idler gear bracket and the receiving multisolenoid function shaft gear.

b. Method of Checking. With the receiving multisolenoid function shaft in the stopped position, hold the idler gear stationary and, by hand, attempt to rotate the function shaft gear back and forth to check the requirement. Check the requirement in various positions of the gears.

c. Adjustment. Loosen the two machine screws that secure the idler gear bracket to the perforator frame and position the idler gear to meet the requirement. Tighten the machine screws and recheck the requirement. Readjust if necessary.




Figure 449. Receiving multisolenoid function shaft driven gear end play adjustment. (Superseded)




Figure 449.1. Idler gear bracket positioning adjustment. (Added)

After paragraph 445 add:

445.1. Receiving Multisolenoid Function Shaft Drum Clutch Adjustment (fig. 450.1)

a. Requirement. There should be 0.002- to 0.008-inch clearance between the sliding drum clutch finger and the clutch latch arm when in the stopped position.

b. Adjustment. With the machine in the stopped position, loosen the clamping screws on the friction adjusting collar and release the spring tension. Loosen the setscrews in the type wheel and function lever cam assembly. Turn the function shaft to meet the required clearance. Tighten the setscrews. Check both fingers of the drum clutch. For re-adjustment of the friction adjusting collar, perform the adjustment described in paragraph 457.




Figure 450.1. Receiving multisolenoid function shaft drum clutch adjustment. (Added)

Page 437. After paragraph 446 add:

446.1. Receiving Multisolenoid Function Shaft Keyed Collar Adjustment (fig. 450.2)

a. Requirement. The keyed collar should be positioned $\frac{1}{16}$ to $\frac{5}{64}$ inch from the edge of the flat on the function shaft.

b. Adjustment. Loosen the setscrews in the keyed collar and position the collar to meet the requirement. Make sure the setscrews are positioned properly over the flats on the shaft. Tighten the setscrews and recheck the requirement.

Paragraph 447a, line 2. Change “.012-inch” to: **0.017-inch**.

Figure 451. Change the callout “.008-.012 IN.” to: **.008-.017 IN.**

Paragraph 450a, line 2. Change “.020-inch” to: **0.017-inch**.

Page 438, figure 454. Change the callout “.007-.020 IN.” to: **.007-.017 IN.**

Paragraph 451c. After the sentence add: Tighten the machine screws and recheck the requirement.

Page 439, paragraph 454, subparagraph *a*. Designate the existing material after the heading: “(1)”. Line 1. Change “.002- to .004-inch” to: **0.001- to 0.005-inch**.

After subparagraph *a*(1) add:

(2) The type wheel reciprocating cam follower should be centered with the spring pin of the type wheel reciprocating drive levers.

Subparagraph *b*. Designate the existing material after the heading “(1)”, and add the following:

(2) Peel the laminated washer until the requirement is met or if necessary install a new washer peeled to meet the requirement. Remove burs from the laminated washer.

Add paragraphs 454.1 and 454.2 after paragraph 454.

454.1. Type Wheel Post Positioning Adjustment (fig. 457.1)

a. Requirement. The end of the type wheel post and the back of the front support frame should be flush within $\pm\frac{1}{64}$ inch (visual check).

b. *Adjustment.* Loosen the setscrew in the front support frame and position the type wheel post to meet the requirement. Tighten the setscrew and recheck the requirement.

454.2. Type Wheel Gears Backlash Adjustment (fig. 457.2)

a. *Requirement.* Backlash between the type wheel driving gear and the type wheel hub assembly gear should be at a minimum, without binding.

b. *Method of Checking.* Position a T-lever midway between its mark and space position. Rotate the stop arm shaft at least one revolution while checking the requirements at various selected positions of the type wheel driving gear.

c. *Adjustments.* Loosen the three machine screws that hold the front support frame to the perforator frame. Remove the two machine screws that hold the ribbon feed mounting bracket to the front support frame. Position the front support frame to meet the requirement. Tighten the three machine screws and recheck the requirement. Reinstall the two machine screws that hold the ribbon feed mounting bracket to the front support frame.




Figure 457. Type wheel shift levers end play adjustment. (Superseded)




Figure 457.1. Type wheel post positioning adjustment. (Added)




Figure 450.2. Receiving multisolenoid function shaft keyed collar adjustment. (Added)

Page 440, paragraph 458a, line 3. Change "fourth" to: **fifth**.

Subparagraph b(2), line 4. Change "fourth" to: **fifth**.

After the last sentence add: Check related adjustment (par. 459).

Figure 461. In the lower center of the illustration, change the callout "FOURTH" to: **FIFTH**.

Page 441, paragraph 459a, line 2. Change "fourth" to: **fifth**.

After the last sentence in subparagraph b add: All characters must print fully.

Paragraph 460a(1), line 1. Change ".040- to .050-inch" to: **0.040- to 0.005-inch minimum**.

Subparagraph *b*(3). After the sentence. add: Check related adjustment (par. 463).

After paragraph 460 add:

460.1. Type Wheel Driving Gear Positioning Adjustment (fig. 463.1)

a. Requirement. When the type wheel hub assembly is against the front support casting, the type wheel driving gear should be positioned on the stop arm shaft to clear (visual check) the ribbon guide.

b. Adjustment. Position a T-lever midway between its mark and space positions. Rotate the stop arm shaft to gain access to a setscrew in the type wheel driven gear hub; loosen the setscrew. Rotate the stop arm shaft to gain access to the other setscrew in the driven gear hub; loosen the setscrew enough to move the driven gear back and forth on the stop arm shaft. With the type wheel hub assembly against the casting, position the type wheel driving gear to meet the requirement. Tighten the setscrews and recheck the requirement.

Figure 462. In the callout, change "FOURTH" to FIFTH.

Figure 463. Change the callout "040"-050"" to: 0.40" TO 0.005" MIN.




Figure 457.2. Type wheel gears backlash adjustment. (Added)




Figure 463.1. Type wheel driving gear positioning adjustment. (Added)

Page 442. After paragraph 462 add:

462.1. Print and Register Cam Positioning Adjustment (fig. 465.1)

a. Requirement.

- (1) The cam followers of the print hammer lever and the type wheel register lever should be centered on their respective cams.
- (2) There should be no bind between the cam followers of the print hammer lever and the type wheel register lever and their respective separator washers.

b. Adjustments.

- (1) Loosen a setscrew in the print and register cam assembly. Rotate the function camshaft to gain access to the other setscrew; loosen the setscrew and position the cam assembly to meet the requirement in *a*(1) above. Tighten the setscrews.
- (2) The separator washers may be straightened with a pair of smooth long-nosed pliers or duckbill pliers to meet the requirement in *a*(2) above.

Page 443. Delete paragraph 465 and substitute:

465. Type Wheel and Print Hammer Legible Copy Adjustment (fig. 468)

a. Requirement. There should be 0.003- to 0.010-inch clearance between the type wheel and the print hammer when the type wheel register lever and the print hammer lever are

on the low part of their respective cams. The copy should be legible and free of smudge.

b. Adjustment. Loosen the self-locking hexagonal nut and adjust the print hammer eccentric stop until the requirement in *a* above is met. Tighten the self-locking hexagonal nut. Recheck the requirements. Readjust if necessary.




Figure 465.1. Print and register cam positioning adjustment. (Added)

Paragraph 467a(1), line 1. Change ".001- to .006-inch" to: 0.00- to 0.013-inch.

Figure 470. Change the callout ".001"-.006"" to: ".001"-.013".

Page 444, paragraph 468a, line 1. Change "lever" to: levers and the.

Subparagraph *b*. After the sentence add: Check related adjustment (par. 467).

Paragraph 469. Delete subparagraph *a* and substitute:

a. Requirement. There should be 0.015- to 0.025-inch clearance between the first code hole punch lever and its associated punch interference lever when the interference levers are in the space position.

Figure 472. Change the callout ".015"-.020"" to: ".015"-.025".




Figure 468. Type wheel and print hammer, legible copy adjustment. (Superseded)

Page 447. After paragraph 476 add:

476.1. Tape Retainer Assembly Adjustment (fig. 479.1)

a. Requirement. The surfaces on both sides of the clearance groove of the tape retainer assembly roller should exert equal pressure on the paper tape at the same time.

b. Method of Checking. Raise the roller by pressing down on the tape retainer assembly lever. While holding the detent lever away from the detent wheel, rotate the tape feed sprocket and slowly lower the tape retainer roller until it makes contact with the tape feed sprocket. Check the requirement visually.

c. Adjustment. Form the retainer mounting bracket to meet the requirement.

Paragraph 477, subparagraph *a*. Designate the existing material after the heading "(1)" and add the following:

- (2) When the requirement in (1) above has been met and the back space lever is depressed, the indicator should point directly at the previously typed character on the message tape.

Subparagraph *b*. Designate the existing material after the heading "(1)" and add the following:

- (2) Remove the retainer ring, paper guide lever, and paper guide lever spring from the paper guide lever pivot. Loosen the pivot and position the indicator to meet the requirement in *a*(2) above. Tighten the pivot and recheck the requirement. Reassemble the paper guide lever spring, paper guide lever, and retainer ring on the paper guide lever pivot.




Figure 479.1. Tape retainer assembly adjustment. (Added)

Page 449, figure 485. Change the callout “.001-.005 In.” to: **.015 MAX.**

Paragraph 482, subparagraph *a*, line 3. Change “.005-inch” to: **0.015-inch.**

Subparagraph *b*. Delete the note and substitute:

Note. The ribbon reversing arm should engage the empty spool sensing lever by at least the thickness of the sensing lever just before the ribbon reversing operation occurs.

Delete paragraph 483 and substitute.

483. Ribbon Feed Lever Adjustment (fig. 486)

a. Requirement. The ribbon feed lever should engage the ribbon feeding detent wheel a minimum of 75 percent. However, there should be some clearance between the feed lever and the bottom of the tooth in the ribbon feeding detent wheel.




Figure 480. Back space mechanism alignment.
(Superseded)

Note. The other ribbon reversing arm should be against its limiting tab as shown.

b. Method of Checking. Turn the motor off. Manually trip the transfer lever latch and turn the motor by hand until the feed lever engages the ribbon feeding detent wheel. Check the requirement visually.

c. Adjustment. If the feed lever does not meet the requirement, carefully bend the toggle limiting tab. Check both feed levers.

Page 450. After paragraph 485 add:

485.1. Manual Tape Feed-Out Shaft End Play Adjustment (fig. 488.1)

a. Requirement. There should be 0.001- to 0.005-inch end play of the manual tape feed-out shaft.

b. Method of Checking. Take up the end play of the shaft so that there is no clearance between the shaft collar and the front support plate. Check the clearance between the front support plate and the flat washer with a feeler gage.

c. Adjustment. Loosen the setscrews in the shaft collar. Insert a 0.003-inch feeler gage between the front support plate and the flat washer on the shaft. Position the collar to meet the requirement above. Tighten the setscrews and recheck the requirement.




Figure 486. Ribbon feed lever adjustment. (Superseded)




Figure 488.1. Manual tape feed-out shaft end play adjustment. (Added)

Page 452, paragraph 490, subparagraph a. Designate the existing material after the heading "(1)", and add the following:

- (2) There should be a minimum of $\frac{1}{8}$ -inch clearance between the alarm lever and the supply reel when the alarm lever is against its stop.

Delete subparagraph b and substitute the following:

b. Adjustment. Loosen the nut on the switch actuating stud and position the stud to meet the requirements. Tighten the nut and recheck the requirements.

After paragraph 490 add:

490.1. Supply Reel Assembly Adjustment (Except TT-178/FG and TT-179/FG)

a. Requirement.

- (1) There should be a $\frac{1}{32}$ -inch minimum clearance between the inside surface of the alarm lever tip and the periphery of the tape reel when the alarm lever is held by the detent.
- (2) The alarm lever should be free and pulled by the alarm lever spring when the alarm lever tip travels a maximum of $\frac{1}{16}$ inch (as shown) from the periphery of the tape reel.

b. Adjustment. Loosen the detent screw and position the detent to meet the requirements in a above. Tighten the screw and recheck the requirements.

Page 453, paragraph 492. Below the heading add:

Note. This adjustment applies to pulsing contacts that have either two or three buffers.

Subparagraph a(1), last line. Change "496" to: 495.

Subparagraph a(2), line 2. Change ".005 to .008 inch" to: 0.003- to 0.006-inch. Last line, Change "496" to: 495.

Add subparagraphs a(3) and (4) and a.1 after subparagraph a(2).

- (3) There should be clearance between the cam follower and the cam when the end of the cam follower is aligned with the notch on the cam (A, fig. 495).
- (4) There should be 0.015- to 0.020-inch clearance between the contacts farthest from the cam. The clearance between the contacts closest to the cam should be .005 inch less than the measured clearance between the contacts farthest from the cam (A, fig. 495).

a.1. Method of Checking.

- (1) With the machine in the stopped position, check the requirement in a(1) and (3) above visually.
- (2) Rotate the pulsing cam until the contacts farthest from the cam just close. Measure the clearance between the cam follower stop and the cam. Continue to rotate the cam until the cam

follower is on the high part of the cam. Measure the clearance between the cam follower stop and the cam. This clearance should meet the requirement in *a*(2) above. Check both cam sides.

- (3) With the machine in the stopped position, check the requirement in *a*(4) with a feeler gage. Also check both sets of normally closed contacts for continuity.

Subparagraph *b*. Delete subparagraph (1) and substitute.

- (1) With the machine in the stopped position, loosen the setscrew in the pulsing cam and rotate the pulsing cam to meet the requirements in *a*(1) and (3) above.

Subparagraph *b*(2), line 6. After "S20," insert: or S218. Lines 11 and 15. Change ".005 to .008 inch" to: 0.003- to 0.006-inch.

After subparagraph *b*(2) add:

- (3) Form the stationary contacts to meet the requirement in *a*(4) above.

Paragraph 493*a*. Below the heading add:

Note. Check to see that both sides of the cam meet the requirements.

Delete subparagraph (1) and substitute.

- (1) With the machine in the stopped position, the setscrew of the receiving multisolenoid pulsing cam should be aligned with the end of the cam follower. The contacts farthest from the cam should be open 0.010 to 0.015 inch (A, fig. 496).

After subparagraph (1) add:


- (1.1) When the contacts farthest from the cam have just closed, there should be a 0.008- to 0.012-inch clearance between the contacts nearest the cam (C, fig. 496).

Subparagraph (2), line 2. Change ".005 to .008": to 0.003 to 0.006 inch.

Page 454, paragraph 493. After subparagraph *b*(1) add:

- (1.1) Bend the contacts to meet the requirement in *a*(1.1) above.

Subparagraph (2), lines 10 and 14. Change ".005 to .008" to: 0.003 to 0.006.



TM2246-C7-64

Figure 493.1 Supply reel assembly adjustment, except TT-178/FG, and TT-179/FG. (Added)







Figure 495. Perforator latch pulsing cam adjustment. (Superseded)



TM2246-C7-75

Figure 496. Receiving multisolenoid pulsing cam adjustment. (Superseded)

Page 455. After paragraph 494 add:

494.1. Copy Light Director Adjustment (fig. 496.1)

a. Requirements.

- (1) The straight end of the copy light director should be positioned $\frac{1}{8}$ to $\frac{3}{8}$ inch away from the lamp.
- (2) The copy light director should be positioned parallel with the dust cover.

b. Method of Checking.

- (1) Check the requirement in a(1) above with a steel rule.
- (2) Check the requirement in a(2) above visually.

c. Adjustment. Loosen the two machine screws and position the copy light director in the clamps to meet the requirements. Tighten the machine screws and recheck the clearance.

Paragraph 497a, line 2. Change " $\frac{1}{32}$ -inch" to: $\frac{1}{8}$ -inch.

After paragraph 497 add:

497.1. Transmitter-Distributor Camshaft End Play Adjustment (fig. 499.1)

a. Requirement. There should be a 0.001- to 0.005-inch clearance between the flat washer and the adjacent ball bearing when the cam end of the transmitter-distributor is pressed toward the transmitter-distributor frame.

b. Adjustment. Loosen the setscrews in the friction clutch fork and insert a 0.003-inch feeler gage between the flat washer and ball bearing. Press the camshaft and the clutch fork toward each other. Align the setscrews with the flats on the camshaft and tighten the setscrews. Remove the feeler gages. Recheck the requirement.

Figure 499. Change the callout " $\frac{1}{64}$ - $\frac{1}{32}$ IN." to: $\frac{1}{64}$ - $\frac{1}{8}$ IN.




Figure 496.1. Copy light director adjustment. (Added)




Figure 499.1. Transmitter-distributor camshaft end play adjustment. (Added)

Page 457. After paragraph 500 add:

500.1. Transmitter-Distributor Comb Adjustment (fig. 502.1)

a. Requirement. There should be a minimum of 0.010-inch clearance between the code sensing levers and the code sensing lever comb and between the tape feed claw and the comb when the transmitter-distributor is in the stopped position.

b. Adjustment. Loosen the two mounting screws of the sensing lever comb and position the comb to meet the requirement. Tighten the two mounting screws and recheck the requirement.

Figure 503. Change the callout “.002-.004 IN” to: .003-.006 IN.

Paragraph 501a, line 1. Change “.002- to .004-inch” to: 0.003- to 0.005-inch.

Page 461. After paragraph 515 add:

515.1. Tape-Out Lever Alinement (fig. 516.1)

a. Requirement. The tape-out lever should be centered (visual check) between the third and fourth sensing levers, when the start-stop lever is in the FEED RETRACT position.

b. Adjustment. Remove the three machine screws and lockwashers that hold the top cover to the transmitter-distributor frame and remove the cover. Place the start-stop lever in the FEED RETRACT position. Loosen the two plain hexagonal nuts that position the tape-out lever shaft and reposition the shaft to meet the requirement above. Tighten the two hexagonal nuts and recheck the requirement. Position the top cover on the frame of the transmitter-distributor; hold with three machine screws and lockwashers. Perform related adjustments (pars. 515 and 516).

After paragraph 516 add:

516.1. Start-Stop Lever Adjustment (fig. 517.1)

a. Requirements.

- (1) With the start-stop lever in the stop position, there should be a minimum of 75 percent engagement (visual check) of the start-stop lever with the step on the transmitter-distributor front plate.
- (2) The start-stop lever should be moved into the FEED RETRACT position by first applying pressure to the left and then pushing downward into position.
- (3) The neoprene-covered end of the start-stop lever should not rub against the transmitter-distributor front cover.

b. Adjustments.

- (1) Remove the outside cover of the transmitter-distributor. Grasp the start-stop lever firmly with a pair of long-nosed pliers in the area shown (fig. 517.1) and with thumb and forefinger bend the neoprene end of the start-stop lever slightly until the requirements in *a*(1) and (2) above are met.
- (2) Trim the neoprene on the start-stop lever to meet requirement in *a*(3) above. Replace the outside cover and recheck the requirements.




Figure 502.1. Transmitter-distributor comb adjustment. (Added)






Figure 516.1. Tape-out lever alignment. (Added)




A. PARTIAL SIDE VIEW



B. FRONT VIEW

TM2277-C2-9

Figure 517.1. Start-stop lever adjustment. (Added)



TM 5815-200-35-C2-7

Figure 519. Motor governor contacts alignment (AN/FGC-25X and AN/FGC-52X).
(Superseded)

Page 463, paragraph 519, heading. Change "(AN-FGC-25X)" to: (Series-Governed Motors).

Page 464, paragraph 520, heading. Change "(AN-FGC-25X)" to: (Series-Governed Motors. Add paragraph 520.1 after paragraph 520).

520.1. Motor Mounting Adjustment (fig. 521.1)



a. Requirements.

- (1) The motor should be visually centered with the worm gear.
- (2) Backlash between the motor worm gear and the main shaft driven gear

should be at a minimum without binding.

b. Adjustment.

- (1) Remove the four machine screws and lockwashers that hold the motor to the perforator frame. Install or remove any combination of the 0.002-inch (51509) and 0.005-inch (51510) shims until the requirement in a(1) above is met. Replace the four machine screws and lockwashers; leave them loose enough so that the motor can slide back and forth.
- (2) Slide the motor back or forth to a position that meets the requirement in a(2) above. Tighten the four machine screws and recheck the requirement.



A

B

TM2246-C7-77

Figure 521.1. Motor mounting adjustment. (Added)

Page 469. After paragraph 527 add:

527.1. Felt Lubricating Washer Data
(fig. 156.1)

a. Type A Plain Round Washer.

Reference No.	A Outside diameter (in.)	B Inside diameter (in.)	C Thickness (in.)
61466	3/4	15/32	1/16
61467	5/8	3/8	1/8
61468	5/16	7/32	1/8
61469	33/64	3/8	1/8
61471	13/16	5/8	1/16
61472	9/16	3/8	1/4
61473	7/16	1/4	1/8
61474	7/16	3/16	1/8
61475	15/32	3/16	1/8
61476	1/2	3/16	1/16
61477	7/16	1/4	1/32
61478	7/16	5/16	1/8
61479	5/8	7/16	1/16
61480	5/8	3/8	1/16
61481	5/8	3/16	1/8
61482	9/16	3/8	1/16
61483	33/64	5/16	1/16
61484	1 1/8	3/8	1/8
61485	3/4	1/2	1/16
61486	15/32	9/32	1/16
61487	3/4	7/16	1/4
61488	3/4	9/16	1/16
61489	3/4	7/16	1/8
61490	5/8	5/16	1/16
61491	15/16	9/16	1/8

Reference No.	A Outside diameter (in.)	B Inside diameter (in.)	C Thickness (in.)
61492	1/2	5/16	1/32
61497	15/16	3/4	1/8
61667	5/8	3/8	1/4
61668	3/4	3/8	1/8
61669	3/4	3/8	1/4
61670	3/4	7/16	1/32
61672	15/32	5/16	1/32
61673	9/16	3/8	1/8
61678	15/16	1/2	1/8
61681	5/16	3/16	1/32

b. Type B Split Round Washer.


Reference No.	A Outside diameter (in.)	B Inside diameter (in.)	C Thickness (in.)
61494	1	1/2	1/4
61495	1 1/4	3/4	1/4

c. Type C Rectangular Washer.

Reference No.	A Outside diameter (in.)	B Inside diameter (in.)	C Thickness (in.)
61496	2 1/2	3/8	1/16
61677	15/16	1/2	1/16

d. Type D T-Shaped Washer.

Reference No.	Dim. A (in.)	Dim. B (in.)	Dim. C (in.)	Dim. D (in.)	Dim. E (in.)	Dim. F (in.)
61460	1 1/64	13/16	1/2	9/64	1/8	1/16 ± 0.007



TM5815-200-35-C2-1

Figure 548.1. Lubricating felt washer forms. (Added)

BY ORDER OF THE SECRETARIES OF THE ARMY AND THE AIR FORCE:

Official:
J. C. LAMBERT,
Major General, United States Army,
The Adjutant General.

G. H. DECKER,
General, United States Army,
Chief of Staff.

Official:
R. J. PUGH,
Colonel, United States Air Force,
Director of Administrative Services.

CURTIS E. LEMAY
Chief of Staff, United States Air Force.

DISTRIBUTION:

Active Army:

DASA (6)
USASA (2)
CNGB (1)
Tech Stf, DA (1) except CSigO (14)
Tech Stf Bd (1)
USCONARC (5)
USAARTYBD (1)
USAARMBD (2)
USAIB (1)
USARADB (2)
USAAVNBD (1)
USAABELCT SPWAR Bd (1)
USAATBD (1)
ARADCOM (2)
ARADCOM Rgn (2)
OS Maj Comd (3)
OS Base Comd (2)
LOGCOMD (2)
MDW (1)
Armies (2)
Corps (2)
Instl (2)
Ft Monmouth (63)
USATC AD (2)
USATC Armor (2)
USATC Engr (2)
USATC Inf (2)
USATC FA (2)
USAOMC (3)
Svc College (2)
Br Svc Sch (2) except USASCS (110)
GENDEP (2) except Atlanta
 GENDEP (None)
Sig Sec, GENDEP (5)
Sig Dep (12) except Sacramento (17)

WRAMC (1)
USA Trans Tml Comd (1)
Army Tml (1)
POE (1)
OSA (1)
USAEPG (2)
AFIP (1)
AMS (1)
Army Pictorial Cen (2)
EMC (1)
USA Strat Comm Comd (4)
USASA, WSMR (2)
USASSA (2)
USASSAMWO (1)
USA Sig Comm Agcy (2)
USARCARIB Sig Agcy (1)
USA SIG Msl Spt Agcy (13)
Sig Fld Maint Shops (3)
USA Corps (3)
Def Log Svc Cen (1)
JBUSMC (2)
Units org under fol TOE (2 cy ea
 UNOINDC)
 11-7
 11-16
 11-57
 11-97
 11-98
 11-117
 11-155
 11-157
 11-500 (Tms AA-AE) (4)
 11-557
 11-587
 11-592
 11-597

NG: None.

USAR: None.

For explanation of abbreviations used, see AR 320-50.