

# TMC SPECIFICATION

NO. S 1136  $\phi$

REV:  $\phi$

COMPILED:

RRH

CHECKED:

*RRH*

APPD:

*MMay*

SHEET

1

OF 3

TITLE:

Typed by mtp 8/31/66

MODIFICATION INSTRUCTIONS

TER-3500 AND TER-5000

# TMC SPECIFICATION

NO. S 1136-~~0~~REV: ~~0~~

COMPILED:

RRH

CHECKED:

APPD:

SHEET 2

OF 3

TITLE: MODIFICATION INSTRUCTIONS -- TER-3500 and TER-5000

Typed by mtp 8/31/66

## I. PURPOSE

To permit use of UG352/U connector with TER-3500 and TER-5000.

## II. LIST OF MATERIALS REQUIRED

<u>Item No.</u>	<u>Qty.</u>	<u>TMC Part No.</u>	<u>Description</u>
1	1	PM1328	Bracket
2	2	SCFP1032BN8	Screw, Machine
3	1	SCBP0832BN5	Screw, Machine
4	1	PM381	Rod, Spark

## III. DOCUMENTS REQUIRED

<u>Item No.</u>	<u>Qty.</u>	<u>TMC Number</u>	<u>Description</u>
5	1	MS3082	Mtg. Plate Dwg.

## IV. PROCEDURE

1. Remove MS3082, Mounting Plate, from the TER and modify to MS3082-~~2~~ per drawing, Item 5.
2. Use screws, Item 2, to mount bracket, PM1328, Item 1, in the new holes of MS3082.
3. Mount spark rod, PM381 (Item 4) in the new bracket, Item 1. Adjust spark rod to within 1/8" of the center conductor of the UG352/U, and tighten screw (Item 3).

