

# TMC SPECIFICATION

NO. S1363

REV:

COMPILED:

dw

CHECKED:

APPD:

SHEET

OF

TITLE: RCVR SCAN DSR-30 MOD.

RCVR SCAN DSR-30 MOD

S1363

# TMC SPECIFICATION

NO. S1363

REV:

COMPILED:

dw

CHECKED:

APPD:

SHEET

OF

TITLE: RCVR SCAN DSR-30 MOD.

AX5224 Z106, Z108

AX5223 Z101, Z103

- 1- Remove test socket from front panel and save hardware.
  - 2- Remove PC assembly and save all hardware.
  - 3- Remove front panel.
  - 4- Mount PC assembly by front screw only.
  - 5- Mount plate MS6855 to outside of scanner unit (use 6-32 undercut flat head screws  $\frac{1}{2}$ " long). Be sure to use spacers and locking nuts on other side of screws.
  - 6- Remove the wires from the test socket going to the interconnect plug.
  - 7- Solder the following wires to the interconnect board PC786 from the test socket.
- |                   |    |                   |
|-------------------|----|-------------------|
| TEST SOCKET PIN 3 | to | PC786-D (Wh/org.) |
| " " " 4           | "  | " -E (Wh/violet)  |
| " " " 8           | "  | " -F (Wh/green)   |
| " " " 9           | "  | " -G (Wh/blue)    |
- 8- Connect a wire from TP1 to PC786-A (Wh/grey).
  - 9- Connect the following wire from the rear of the connector pins and the interconnect board PC786.

|                     |    |                 |
|---------------------|----|-----------------|
| FSK Connector PIN 1 | to | PC786-1 brown   |
| " " " 2             | "  | " -2 red        |
| " " " 3             | "  | " -3 orange     |
| " " " 4             | "  | " -4 yellow     |
| " " " 5             | "  | " -5 green      |
| " " " 6             | "  | " -6 blue       |
| " " " 7             | "  | " -7 violet     |
| " " " 8             | "  | " -8 grey       |
| " " " 9             | "  | " -9 white      |
| " " " 10            | "  | " -10 wh/brown  |
| " " " 11            | "  | " -11 wh/red    |
| " " " 12            | "  | " -12 wh/orange |
| " " " 13            | "  | " -13 wh/green  |
| " " " 14            | "  | " -14 wh/blue   |
| " " " 15            | "  | " -15 wh/violet |
| " " " 16            | "  | " -R wh/grey    |

Z103 wire from J7 to PC786-L brown

Z106 add relay for pos 1 to apply ground for tune.