

28E AND 28H TRANSMITTER-DISTRIBUTOR UNIT
WIRING DIAGRAM

1. GENERAL

1.01 This section shows the wiring of the 28E and 28H transmitter-distributor units. These units are used with the 28 automatic send-receive set or self-contained transmitter-distributor set.




Figure 1 - 28E Transmitter-Distributor Unit




Figure 2 - 28H, 28H-1, 28H-2, 28H-3, and 28H-4 Transmitter-Distributor Units