DATE 2 18-64 SHEETOF		TMC SPECIFICATION NO. S -816		0
COMPILED	LB CHECKED	TITLE:	TER-100K-50U	
APPR	OVEDRA			

GENERAL

The TMC Model TER-100K-50/U is a dummy load capable of dissipating 100KW average power over the range of DC to 30 MC. The peak input should not exceed 200KW Pep.

The TER-100K consists of 7 (seven) 300 ohm 5 kilowatt  $\pm$  5% resistors. Each resistor is a special glass cylinder with a resistive element electrofused into the glass. The protective coating is a baked on silicon film. Electrical connections are made possible by fired-on silver bands.

Operation above 35KW requires cooling which is provided by 7 (seven) fans mounted in the base of the unit.

#### A. Mechanical Inspection

- 1. Inspect for any damage incurred during construction.
- 2. Inspect straps holding resistors; they must be tight enough on silver bands to prevent movement.
- 3. Check tightness of all hardware (nuts & screws).
- 4. Check fuse for proper value (2 amp).

## B. Electrical Inspection

- 1. Apply 110 VAC 60 CPS to AC connector and activate both front door interlocks.
- 2. Place AC Power switch and Remote switch to on position. TER 100K must not go on.
- 3. Leaving switches in on position, <u>Disconnect A.C.</u> line cord. Place jumper across Pins "E" and "F" on connector. By replacing AC line cord TER-100K must go on.
  - \* Repeat step 2&3 for both connectors.
- 4. Check each fan for proper rotation. This is indicative by the operation of each fan air switch. Improper rotation of any fan will cause its respective light to operate.
- 5. Remove each fan fuse in turn.

### Observe the following:

- (a) Relay K101 must de-energize. \* To check K101, remove AC power, place ohm-meter across terminals C & D. There must not be continuity. Connect AC power and energize TER-100K. The ohm meter must read continuity. Remove AC power, dis-connect ohm-meter and reapply AC power.
- (b) Fan indicator lamp must go on.
  - \* Replace each fuse after each check.
- Deactivate each front door interlock in turn K101 must de-energize.\* To check K101, repeat step (5a).

# C. Power Check

1. Connect the input of TER-100K to output of GPT-200K with 3 1/8 (inch) coaxial lead. Connect AC power to TER 100K and turn fans on. Tune transmitter to 8 Mc and drive to 25 KW for  $10\,\mathrm{minutes}$ .

DATE 2-18-64 SHEET 2 OF 3		ТМО	C SPECIFICATION NO. S -816	0
COMPILED	CHECKED	TITLE:	TER-100K-50U	<b>L</b>
APPF	ROVED			

- 2. Reduce drive and turn off high voltage. Visually inspect resistors for any signs of damage.
- 3. Repeat the above at 50KW power level.
- 4. If the above tests fail reject the resistor or resistors at fault and repeat the above tests.

#### D. Final Power Check

- 1. With fans operating drive transmitter to 100KW for five (5) minutes.
- 2. Record acceptance on check off sheet.

DATE SHEET_	2 <b>3</b>	-18-64 	TMC SPECIFICATION NO.	S -816
COMP	ILED	CHECKED	TER-100K-50U	
	APP	ROVED		
			CHECK OFF SHEET	
Α.		nanical Inspect		Accept
	1.	Mechanical con		-
	2.	Electrical con		
	3.	Hardware (nuts	s & belts)	Martine and the second and the secon
	4.	Fuses		***************************************
D	Fla	skada 1 To so so		
В.		ctrical Inspect	tion	
	1.	Remote Switch		· · · · · · · · · · · · · · · · · · ·
			Proper Rotation of Fans	
	3.	Relay Operation		-
	4.	Interlock Oper		The state of the s
	5.	Electrical Res	istance (42 ohms $\pm$ 5%)	ohms
с.	Powe	r Check		
	1.	25 KW		-
	2.	50 KW		****
n	Fina	1 Power Check		
~.		100kw		
	-•			
DAT	Έ			
TES				
		URING NUMBER		
	ROVED			

8444

REVI	SION	SHEET	r 	THE TECHNICAL MATERIEL CORP. MAMAR NECK NEW YORK	S-816 LIST NO.	0
DATE	REV.	SHEET	EMN #	. DESCRIPTIO		APP.
4/22/6	64	l of 3	3	O= ORIGINAL RELEASE FOR PROD	······································	,
						<del>                                     </del>
						<del> </del>
ļ						
ļ	<u> </u>					
		'				
		<u> </u>	1			
<u> </u>	1	<u> </u>	<u> </u>			
!						
		<u>                                     </u>	<u></u> '			
		!	1			
	1					
	<u></u>					
				·		
	<u></u>					
	<u></u>					
	Ĺ					
				I		İ
				1		i
				ı		
				1		
	I			1		i
				1		
				ı		